Form 8785
January, 1922

LIST
OF
PARTS

MACHINES

Nos. 44-1 to 44-3, 44-8, 44-9, 44-13, 44-17, 44-20, 44-22 to 44-24, 44-28, 44-29, 44-72, 44-74 and 44-75

THE SINGER MANUFACTURING COMPANY

Samuel R. Weitzer

TJ
1579
.S97
1922

8785—1

Digitized by the Internet Archive
in 2010 with funding from
Lyrasis Members and Sloan Foundation

http://www.archive.org/details/listofpartsmachi00sing

Form 8785
January, 1922

LIST

OF

PARTS



MACHINES

Nos. 44-1 to 44-3, 44-8, 44-9, 44-13, 44-17, 44-20, 44-22 to 44-24, 44-28, 44-29, 44-72, 44-74 and 44-75

THE SINGER MANUFACTURING COMPANY

Copyright, U. S. A.
1913, 1917, 1920, 1921 and 1922
by
The Singer Manufacturing Company
All Rights Reserved for all Countries

INDEX

PAGE

Attachments and Accessories 132
Belt Guard 132
Binders 133
Bobbin Winders 176
Box Plaiter Parts 146
Corders 147
Driving Attachment No. 16531 181
" " " 24073 184
Edge Folders on Shank 149
Feller 149
Finger Guard 149
Foot Lever Parts 184
" Lifter Parts 184
Guides 154
Hemmers 156
Hemstitcher 161
Iron Base 131
Knee Lifter Parts 186
Knife Grinder 188
Lap Seam Feller 161
Machine No. 44-1 9
" " 44-2 17
" " 44-3 24
" " 44-8 31
" " 44-9 39
" " 44-13 47
" " 44-17 56
" " 44-20 64
" " 44-22 72
" " 44-23 79
" " 44-24 86
" " 44-28 93
" " 44-29 101
" " 44-72 109
" " 44-74 117
" " 44-75 124
Numerical List of Parts 201
Obsolete Parts 194
Piping Attachments 167
Presser Feet 161
Quilters 167
Rufflers 167
Seamer 171

PAGE

Seaming Guide 175
Separating Blade (Hinged) 171
Spool Holder (Disc) 172
Stand No. 25265 189
" " 25279 190
" " 25284 191
Strip Folder (Foot) 153
" " on Shank 153
" Folders 151
Thread Unwinders 193
Throat Plates 172
Trimmings for End and Back Leaf Table 192
Tubular Trimming Attachment 172
Tucker 172
" (Long Arm) 174
" (Power) No. 26377 173
" " " 26687 174
Universal Felling Attachments 175
Welt Guide 176

INSTRUCTIONS FOR ORDERING

In ordering from this list, use ONLY the PART number in the FIRST column.

The number stamped on a Sewing Machine part is in every case the number of the single part only.

Every combination of parts sent out as such has its specific number, which, although not stamped on the parts, must be used when ordering the combination.

Each number always indicates the SAME PART in whatever list it appears, or for whatever machine.

The letters after some of the numbers indicate the style of finish only, as follows:

A. Hardened, Polished and Plated.
B. Polished and Plated.
C. Hardened only.
D. Polished only.
E. Soft, not Polished.
F. Hardened and Polished.
G.
H. Blued.
J. Plated only.
K. Hardened and Plated.
L. Brass or Gilt
M. Oxidized.
P. Japanned.
R. Parkerized.

These letters MUST BE USED *when* they appear in the list, and AFTER the number *as* in the list.

In this series

1 to 1500 and 50001 to 51500 are Screw Numbers.
1501 to 1800 are Nut Numbers.
1801 to 2000 are Roller Numbers.
2001 to 50000 and 52001 and upward are numbers of Machine Parts.

The figures in the second column refer only to the plates illustrating the parts, and are NOT TO BE USED in ordering

Parts marked with an asterisk (*) are furnished only when repairs are made at factory.

LIST OF PARTS COMPLETE

FOR

MACHINE No. 44-1

DROP FEED, FOR GENERAL CLOTH WORK

NO.	PLATE	NAME
*16501	——	Arm with 11104
8582	773	" Dowel Pin
12453	773	" Oil Tube for intermediate bearing
12454	773	" " " with 29599, for oiling 12409
11119	773	" " " " " " " 12408
24131	2014	" " " " " " " 20283
29599	2014	" " " Packing (felt)
748E	782	" Screw (back)
868E	1366	" " (front)
16511	1349	" Shaft
*11104	——	" " Bushing (front)
12357	767	" " Flanged Bushing (back)
448C	783	" " " " " Set Screw
144D	782	Arm Shaft Screw
12480	767	" Side Cap
219D	774	" " " Screw
12193	2004	" " Cover
286D	783	" " " Thumb Screw
12403	772	" Spool Pin and Thread Eyelet
11241	2003	" " " Washer (cloth)
24296	1348	Balance Wheel (power) light rim, $2\frac{3}{16}$ in. pulley, with two 448C
24297	1340	Balance Wheel Oil Cover
210D	1343	" " " " Screw
448C	783	" " Set Screw
*16503	——	Bed
20197	1350	Crank Connecting Rod with 20198 and two 896E
*20198	——	Crank Connecting Rod Cap
896E	773	" " " " Screw
908C	773	" " " Hinge Screw
1619E	773	" " " " " Nut
20057	——	Face Plate
20058	1340	Face Plate complete, Nos. 2827, 12150 and 20057

NO.	PLATE	NAME
190D	782	Face Plate Screw.....
44181	——	" " Thread Guard (lower).....
12150	773	" " " " " 44181 with 12152.....
12152	773	Face Plate Thread Guard (lower) Rivet...
2827	773	" " " " (upper) with 8505
8505	773	" " " " " Rivet...
286D	783	" " Thumb Screw.....
12368	767	Feed Bar.....
313C	783	" " Screw Centre.....
56813	——	" " " " 313C with 1519J..
1519J	783	" " " " Nut.....
3033	770	" Connecting Link.....
375C	782	" " " Hinge Screw.....
1518E	783	" " " " " Nut.
12369	776	Feed Dog, 12 teeth (12 teeth to the inch)

NOTE: No. 12369 is sent with this Machine unless another Feed Dog is specified on order.

12457	776	Feed Dog, for cloth, 16 teeth (16 teeth to the inch).....
12370	778	Feed Dog, for cloth, 15 teeth (16 teeth to the inch).....
43979	778	Feed Dog, for cloth, 21 teeth (22 teeth to the inch).....
12425	779	Feed Dog, for cloth.....
12450	777	" " " " 11 teeth (18 teeth to the inch).....
20348	777	Feed Dog, for chiffon, 22 teeth (36 teeth to the inch).....
20275	1259	Feed Dog, for umbrella work.....
19474	1258	" " " corset work.....
44136	5805	" " " tailor work.....
20018	1258	" " " finishing knit underwear...
20119	1259	" " " heavy work on duck, overalls, etc.....
20352	1267	Feed Dog, for general muslin work.....
208E	782	" " Screw.....
20283	1315	" and Feed Lifting Eccentric with 446C
446C	783	" " " " " Set Screw
24036	1340	" " " " " Sleeve...
20284	1350	" Forked Connection.....
375C	782	" " " Hinge Screw...
1518E	783	" " " " " Nut
24969	2551	" Lifting Rock Shaft.....
24970	——	Feed Lifting Rock Shaft complete, Nos. 12376 and 24969.....

NO.	PLATE	NAME
12376	770	Feed Lifting Rock Shaft Crank with 157J and 1813
157J	782	Feed Lifting Rock Shaft Crank Clamping Screw
1813	783	Feed Lifting Rock Shaft Crank Roller and Stud
43976	2551	Feed Lifting Rock Shaft Crank Connecting Rod with 43977 and two 966E
*43977	——	Feed Lifting Rock Shaft Crank Connecting Rod Cap
966E	5806	Feed Lifting Rock Shaft Crank Connecting Rod Cap Screw
375C	782	Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw
1518E	783	Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw Nut
307C	783	Feed Lifting Rock Shaft Screw Centre
56814	——	" " " " " " 307C with 1513J
1513J	783	Feed Lifting Rock Shaft Screw Centre Nut
3039	768	" Regulator
1128E	2009	" " Hinge Screw
818D	783	" " Thumb Screw
16506	766	" Rock Shaft
24376	——	Feed Rock Shaft complete, Nos. 16506 and 29633
29633	1354	Feed Rock Shaft Crank with 157J
157J	782	" " " " Clamping Screw
307C	783	" " " Screw Centre
56814	——	" " " " " 307C with 1513J
1513J	783	Feed Rock Shaft Screw Centre Nut
12381	767	Needle Bar (hollow)
19229	2004	" " " for high lift
12382	770	" " Connecting Link with 794E
794E	782	" " " " Adjusting Screw
12383	——	Needle Bar Connecting Stud
1904	770	" " " " Roller (roller only)
453C	783	Needle Bar Connecting Stud Set Screw
12384	770	Needle Bar Connecting Stud complete, Nos. 453C, 1904 and 12383

NO.	PLATE	NAME
20188	767	Needle Bar Crank with 858c and 1065c..
1065c	1366	" " " Position Screw.....
858c	783	" " " Set Screw.....
936E	773	" " Screw Bushing.....
4302	773	" " Thread Guard.....
233D	782	" " " " Screw.....
4303	773	" Clamp with 808F, for 12381.....
24101	——	" " Body.....
808F	782	" " Screw.....
24102	1353	" " Thread Guide.....
651D	1353	" " " " Screw.....
24103	1353	Needle Clamp (high lift) complete for 19229, Nos. 651D, 808F, 24101 and 24102
24104	1350	Oscillating Rock Shaft.....
24105	——	Oscillating Rock Shaft complete, Nos. 4784, 12388 and 24104.....
12388	767	Oscillating Rock Shaft Hinge Pin.....
878J	783	" " " " " Oil Hole Stop Screw.....
12459	773	Oscillating Rock Shaft Hinge Pin Oil Hole Stop Screw Washer (leather).....
448c	783	Oscillating Rock Shaft Hinge Pin Set Screw.....
4784	1353	Oscillating Rock Shaft Oil Pad.....
16509	766	" Shaft.....
19496	——	" " Crank for 19447.....
44134	——	" " " " 44135.....
19447	1353	Oscillating Shaft Crank complete, Nos. 457c, 1518E, 19449 and 19496.....
44135	5806	Oscillating Shaft Crank complete, Nos. 1518E, 19449, 44134 and two 453c.....
2049	773	Oscillating Shaft Crank Pin.....
457c	783	" " " Set Screw for 19447
453c	783	" " " " " " 44135
19448	1353	" " " Slide Block.....
229D	782	" " " " " Cap Screw.....
12424	773	Oscillating Shaft Crank Slide Block Cap Screw Washer.....
988c	1353	Oscillating Shaft Crank Slide Block Screw Stud.....
1518E	783	Oscillating Shaft Crank Slide Block Screw Stud Nut.....
19449	1353	Oscillating Shaft Crank Slide Block complete, Nos. 229D, 988c, 12424 and 19448

NO.	PLATE	NAME
12391	767	Presser Bar (hollow).....
20059	1341	" " Guide Bracket with 453c....
453c	783	" " " " Set Screw....
2062	771	" " Lifter.....
689c	782	" " " Screw.....
1520e	783	" " " " Nut..... ....
12327	770	" " Lifting and Releasing Lever Bracket.....
11167	767	Presser Bar Spring (light) .051 wire.....

NOTE: No. 11167 is sent with this Machine unless another Spring is specified on order.

12139	2004	Presser Bar Spring (medium) .055 wire...
20023	2004	" " " (heavy) .063 wire....
11170	771	" " " Washer.....
12143	780	Presser Foot for 12369 and 12457.....

NOTE: No. 12143 is sent with this Machine unless another Presser Foot is specified on order.

20458	780	Presser Foot for 44136.....
12335	1308	" " (narrow) for 12369 and 12457
12258	1308	" " (wide) for 12369 and 12457
12142	780	" " for 12370 and 43979.....
12259	780	" " " 12425 and 19474.....
12260	780	" " " 12450 and 20348.....
20020	1308	" " " 20018.....
62527	5806	" " Hinge Pin.....
24544	——	" " Plate.....
24982	——	" " Shank.....
26231	2014	" " Spring.....
24983	781	Presser Foot (spring hinged) complete for 12425, 19474 and 20119, Nos. 24544, 24982, 26231 and 62527.....
7298	2014	Presser Foot Hinge Pin.....
19334	——	" " Plate.....
19335	——	" " Shank.....
19336	1308	Presser Foot (hinged) complete for 12370 and 20009, Nos. 7298, 19334 and 19335
7298	2014	Presser Foot Hinge Pin.....
20268	——	" " Plate.....
20269	——	" " Shank.....
20270	1308	Presser Foot (hinged) complete for 12369 and 12457, Nos. 7298, 20268 and 20269
20276	1259	Presser Foot for 20275.....
20342	781	" " " 12450 and 20348.....
20343	781	" " with guide on bottom to the right of needle hole.....
190d	782	Presser Foot Screw.....

NO.	PLATE	NAME
688J	783	Pressure Regulating Thumb Screw.....
2996	771	Shuttle Bobbin.....
15140	1353	" " Case Latch.....
2973	771	" " " " Lever.....
2974	771	" " " " " Fulcrum Pin.....
2975	771	Shuttle Bobbin Case Latch Spring.....
592E	782	" " " " Stop Screw...
15141	——	Shuttle Bobbin Case Hinge, Nos. 2973, 2974 and 15140.....
7553	771	Shuttle Bobbin Case Position Finger.....
2523	771	" " " " " Rivet
24412	1361	" " " " Plate.....
391D	1366	" " " " " Screw
24074	771	Shuttle Bobbin Case complete, Nos. 591F, 592E, 2523, 2975, 7553, 15098 and 15141
12393	771	Shuttle Body.....
591F	782	" Tension Regulating Screw.....
15098	771	" " Spring.....
19292	771	Shuttle, $1\frac{11}{16}$ in. diam., Nos. 2996, 12393 and 24074.....
*12394	——	Shuttle Driver.....
12444	771	" " 12394 with two 1266C.....
2049	773	" " Pin.....
1266C	5806	" " Set Screw.....
2531	767	" Race Back.....
2532	772	" " " Position Pin.....
2533	767	" " " Spring.....
907D	782	" " " " Screw.....
24413	——	" " Body.....
25000	——	" " " 24413 with 24414 and two 1053D.....
24414	1362	Shuttle Race Cap.....
1053D	2006	" " " Screw.....
24415	1361	Shuttle Race complete, Nos. 907D, 2531, 2533, 24412, 25000 and two each 391D and 2532.....
145D	782	Shuttle Race Screw.....
12431	——	" " Slide.....
12432	2004	Shuttle Race Slide complete, Nos. 4307, 12431 and two 725E.....
4307	772	Shuttle Race Slide Spring.....
725E	1387	" " " " Screw.....
20060	1311	Slack Thread Regulator.....
225F	1323	" " " Adjusting Screw...

NO.	PLATE	NAME
2102	5806	Tension Disc
1560c	783	" Regulating Thumb Nut
32572	5806	" Releasing Disc
43944	5806	" " Lever
12398	773	" " " Hinge Pin
12329	772	" " " Spring
32574	5806	" " Pin
50327c	5806	" Screw Stud
44141	——	" " " 50327c with 1560c
43945	5806	" Spring
44118	——	Tension complete, Nos. 7336, 32572, 32574, 43945, 43946, 44141 and two 2102
52454	5842	Thread Retainer
50429c	——	" " Set Screw
12404	770	" Take-up Crank
3094	773	" " " Wedge
690E	782	" " " " Screw
12408	770	" " Lever
775E	782	" " " Cap Screw
12166	773	" " " Hinge Pin
12409	770	" " " Link
11204	770	" " " " Hinge Pin
435c	5806	" " " " " " Set Screw
12410	——	Thread Take-up Lever complete, Nos. 12166, 12408 and 12409
43946	5806	Thread Take-up Spring
7336	772	" " " Regulator
448c	783	" " " " Set Screw
12411	776	Throat Plate, large needle hole, for 12369 and 12457

NOTE: No. 12411 is sent with this Machine unless another Throat Plate is specified on order.

12449	——	Throat Plate, small needle hole, for 12369 and 12457
12412	778	Throat Plate, large needle hole, for 12370 and 43979
12426	779	Throat Plate, large needle hole, for 12425
12466	——	" " small needle hole, for 12425
12464	777	" " large needle hole, for 12450 and 20348
12451	——	Throat Plate, small needle hole, for 12450 and 20348

NO.	PLATE	NAME
19475	1258	Throat Plate, large needle hole, for 19474
44137	5805	" " " " " " 44136
44138	——	" " small needle hole, for 44136
20019	1258	" " large needle hole, for 20018
20120	1259	" " " oblong needle hole, for 20119.....
20187	——	Throat Plate, small oblong needle hole, for 20119.....
20277	1259	Throat Plate, large needle hole, for 20275
20362	——	" " small needle hole, for 20275
20353	1267	" " large needle hole, for 20352
20354	——	" " small needle hole, for 20352
691F	782	" " Screw.....
24079	2644	Drip Pan with four 1 inch wire nails.....

LIST OF PARTS COMPLETE

FOR

MACHINE No. 44-2

DROP FEED, FOR SHIRTS, LINEN AND COTTON GOODS

NO.	PLATE	NAME
*16501	——	Arm with 11104
8582	773	" Dowel Pin
12453	773	" Oil Tube for intermediate bearing
12454	773	" " " with 29599, for oiling 12409
11119	773	" " " " " " " 12408
24131	2014	" " " " " " " 20283
29599	2014	" " " Packing (felt)
748E	782	" Screw (back)
868E	1366	" " (front)
16511	1349	" Shaft
*11104	——	" " Bushing (front)
12357	767	" " Flanged Bushing (back)
448C	783	" " " " " Set Screw
144D	782	Arm Shaft Screw
12480	767	" Side Cap
219D	774	" " " Screw
12193	2004	" " Cover
286D	783	" " " Thumb Screw
12403	772	" Spool Pin and Thread Eyelet
11241	2003	" " " Washer (cloth)
24296	1348	Balance Wheel (power) light rim, $2\frac{3}{16}$ in. pulley, with two 448c
24297	1340	Balance Wheel Oil Cover
210D	1343	" " " " Screw
448C	783	" " Set Screw
*16503	——	Bed
20197	1350	Crank Connecting Rod with 20198 and two 896E
*20198	——	Crank Connecting Rod Cap
896E	773	" " " " Screw
908C	773	" " " Hinge Screw
1619E	773	" " " " " Nut.
20057	——	Face Plate
20058	1340	Face Plate complete, Nos. 2827, 12150 and 20057

NO.	PLATE	NAME
190D	782	Face Plate Screw.. .....
44181	——	" " Thread Guard (lower).....
12150	773	" " " " " 44181 with 12152..... .....
12152	773	Face Plate Thread Guard (lower) Rivet
2827	773	" " " " (upper) with 8505.....
8505	773	Face Plate Thread Guard (upper) Rivet
286D	783	" " Thumb Screw.....
12368	767	Feed Bar.....
313C	783	" " Screw Centre.....
56813	——	" " " " 313C with 1519J
1519J	783	" " " " Nut.....
3033	770	" Connecting Link..... ....
375C	782	" " " Hinge Screw.....
1518E	783	" " " " " Nut.
20336	1264	Feed Dog, for shirt work, beveled for hemmer.....

NOTE: No. 20336 is sent with this Machine unless another Feed Dog is specified on order.

12468	777	Feed Dog, 16 teeth (16 teeth to the inch) for shirt work, beveled for hemmer. ..
20471	777	Feed Dog, 22 teeth (22 teeth to the inch) for shirt work, beveled for hemmer....
12481	778	Feed Dog, 18 teeth (16 teeth to the inch)
43978	778	" " 24 teeth (22 teeth to the inch) beveled for hemmer.....
12455	779	Feed Dog, for shirt work, beveled for hemmer.....
12372	778	Feed Dog, 13 teeth (12 teeth to the inch) beveled for hemmer.....
20002	778	Feed Dog, 18 teeth (16 teeth to the inch) beveled for hemmer.....
12437	777	Feed Dog, for cloth, four teeth at right of needle hole (square corner).....
20349	1267	Feed Dog.....
208E	782	" " Screw.....
20283	1315	" and Feed Lifting Eccentric with 446C
446C	783	" " " " " Set Screw
24036	1340	" " " " " Sleeve...
20284	1350	" Forked Connection.....
375C	782	" " " Hinge Screw...
1518E	783	" " " " " Nut
24969	2551	" Lifting Rock Shaft.....
24970	——	Feed Lifting Rock Shaft complete, Nos. 12376 and 24969.....

NO.	PLATE	NAME
12376	770	Feed Lifting Rock Shaft Crank with 157J and 1813
157J	782	Feed Lifting Rock Shaft Crank Clamping Screw
1813	783	Feed Lifting Rock Shaft Crank Roller and Stud
43976	2551	Feed Lifting Rock Shaft Crank Connecting Rod with 43977 and two 966E
*43977	——	Feed Lifting Rock Shaft Crank Connecting Rod Cap
966E	5806	Feed Lifting Rock Shaft Cran : Connecting Rod Cap Screw
375C	782	Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw
1518E	783	Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw Nut
307C	783	Feed Lifting Rock Shaft Screw Centre
56814	——	" " " " " " 307C with 1513J
1513J	783	Feed Lifting Rock Shaft Screw Centre Nut
3039	768	" Regulator
1128E	2009	" " Hinge Screw
818D	783	" " Thumb Screw
16506	766	" Rock Shaft
24376	——	Feed Rock Shaft complete, Nos. 16506 and 29633
29633	1354	Feed Rock Shaft Crank with 157J
157J	782	" " " " Clamping Screw
307C	783	" " " Screw Centre
56814	——	" " " " " 307C with 1513J
1513J	783	Feed Rock Shaft Screw Centre Nut
12381	767	Needle Bar (hollow)
19229	2004	" " " for high lift
12382	770	" " Connecting Link with 794E
794E	782	" " " " Adjusting Screw
*12383	——	Needle Bar Connecting Stud
1904	770	" " " " Roller (roller only)
453C	783	Needle Bar Connecting Stud Set Screw
12384	770	Needle Bar Connecting Stud complete, Nos. 453C, 1904 and 12383

NO.	PLATE	NAME
20188	767	Needle Bar Crank with 858c and 1065c..
1065c	1366	" " " Position Screw.....
858c	783	" " " Set Screw.....
936e	773	" " Screw Bushing.....
4302	773	" " Thread Guard.....
233d	782	" " " " Screw.....
4303	773	" Clamp with 808f, for 12381.....
24101	——	" " Body.....
808f	782	" " Screw.....
24102	1353	" " Thread Guide.....
651d	1353	" " " " Screw.....
24103	1353	Needle Clamp (high lift) complete for 19229, Nos. 651d, 808f, 24101 and 24102
24104	1350	Oscillating Rock Shaft.....
24105	——	Oscillating Rock Shaft complete, Nos. 4784, 12388 and 24104.....
12388	767	Oscillating Rock Shaft Hinge Pin.... ..
878j	783	" " " " " Oil Hole Stop Screw.....
12459	773	Oscillating Rock Shaft Hinge Pin Oil Hole Stop Screw Washer (leather).....
448c	783	Oscillating Rock Shaft Hinge Pin Set Screw.....
4784	1353	Oscillating Rock Shaft Oil Pad.....
16509	766	" Shaft.....
19496	——	" " Crank for 19447.....
44134	——	" " " " 44135.....
19447	1353	Oscillating Shaft Crank complete, Nos. 457c, 1518e, 19449 and 19496.....
44135	5806	Oscillating Shaft Crank complete, Nos. 1518e, 19449, 44134 and two 453c.....
2049	773	Oscillating Shaft Crank Pin.....
457c	783	" " " Set Screw for 19447
453c	783	" " " " " " 44135
19448	1353	" " " Slide Block.....
229d	782	" " " " " Cap Screw.....
12424	773	Oscillating Shaft Crank Slide Block Cap Screw Washer.....
988c	1353	Oscillating Shaft Crank Slide Block Screw Stud.....
1518e	1353	Oscillating Shaft Crank Slide Block Screw Stud Nut.....
19449	1353	Oscillating Shaft Crank Slide Block complete, Nos. 229d, 988c, 12424 and 19448

NO.	PLATE	NAME
12391	767	Presser Bar (hollow).....
20059	1341	" " Guide Bracket with 453c....
453c	783	" " " " Set Screw....
2062	771	" " Lifter.....
689c	782	" " " Screw.....
1520e	783	" " " " Nut.....
12327	770	" " Lifting and Releasing Lever Bracket.....
11167	767	Presser Bar Spring (light) .051 wire.....

NOTE: No. 11167 is sent with this Machine unless another Spring is specified on order.

12139	2004	Presser Bar Spring (medium) .055 wire...
20023	2004	" " " (heavy) .063 wire....
11170	771	" " " Washer.....
12144	780	Presser Foot for 12372, 12437, 12455, 12468, 12481, 20002 and 20336.....

NOTE: No. 12144 is sent with this Machine unless another Presser Foot is specified on order.

12260	780	Presser Foot for 12437.....
12474	1308	" " " 12372, 12481 and 20002
12261	1308	" " " 12481.....
62527	8376	" " Hinge Pin.....
24544	——	" " Plate..... .....
24982	——	" " Shank.....
26231	8376	" " Spring.....
24983	781	Presser Foot (hinged) complete for 12481, Nos. 24544, 24982, 26231 and 62527...
2532	772	Presser Foot Hinge Pin.....
20310	——	" " Plate.....
19223	——	" " Shank.....
20311	781	Presser Foot (hinged) complete for 12372, 12437, 12455, 12468, 12481, 20002 and 20336, Nos. 2532, 19223 and 20310....
2532	772	Presser Foot Hinge Pin.....
20344	——	" " Plate.....
20345	——	" " Shank.....
26231	1353	" " Spring.....
20346	781	Presser Foot (spring hinged) complete, Nos. 2532, 20344, 20345 and 26231....
190d	782	Presser Foot Screw.....
688j	783	Pressure Regulating Thumb Screw.....
2996	771	Shuttle Bobbin.....
15140	1353	" " Case Latch.....
2973	771	" " " " Lever.....
2974	771	" " " " " Fulcrum Pin.....

NO.	PLATE	NAME
2975	771	Shuttle Bobbin Case Latch Spring.....
592E	782	" " " " Stop Screw...
15141	——	Shuttle Bobbin Case Hinge, Nos. 2973, 2974 and 15140.....
7553	771	Shuttle Bobbin Case Position Finger.....
2523	771	" " " " " Rivet
24412	1361	" " " " Plate.....
391D	1366	" " " " " Screw
24074	771	Shuttle Bobbin Case complete, Nos. 591F, 592E, 2523, 2975, 7553, 15098 and 15141
12393	771	Shuttle Body.....
591F	782	" Tension Regulating Screw.....
15098	771	" " Spring.....
19292	771	Shuttle, $1\frac{11}{16}$ in. diam., Nos. 2996, 12393 and 24074.....
*12394	——	Shuttle Driver.....
12444	771	" " 12394 with two 1266C.....
2049	773	" " Pin.....
1266C	5806	" " Set Screw.....
2531	767	" Race Back.....
2532	772	" " " Position Pin.....
2533	767	" " " Spring.....
907D	782	" " " " Screw.....
24413	——	" " Body.....
25000	——	" " " 24413 with 24414 and two 1053D.....
24414	1362	Shuttle Race Cap.....
1053D	2006	" " " Screw.....
24415	1361	Shuttle Race complete, Nos. 907D, 2531, 2533, 24412, 25000 and two each 391D and 2532.....
145D	782	Shuttle Race Screw.....
12431	——	" " Slide.....
12432	2004	Shuttle Race Slide complete, Nos. 4307, 12431 and two 725E.....
4307	772	Shuttle Race Slide Spring.....
725E	1387	" " " " Screw.....
20060	1311	Slack Thread Regulator.....
225F	1323	" " " Adjusting Screw
2102	5806	Tension Disc.....
1560C	783	" Regulating Thumb Nut.....
32572	5806	" Releasing Disc.....
43944	5806	" " Lever.....
12398	773	" " " Hinge Pin.....
12329	772	" " " Spring.....
32574	5806	" " Pin.....

NO.	PLATE	NAME
50327c	5806	Tension Screw Stud
44141	——	" " " 50327c with 1560c
43945	5806	" Spring
44118	——	Tension complete, Nos. 7336, 32572, 32574, 43945, 43946, 44141 and two 2102
52454	5842	Thread Retainer
50429c	——	" " Set Screw
12404	770	" Take-up Crank
3094	773	" " " Wedge
690E	782	" " " " Screw
12408	770	" " Lever
775E	782	" " " Cap Screw
12166	773	" " " Hinge Pin
12409	770	" " " Link
11204	770	" " " " Hinge Pin
435c	5806	" " " " " " Set Screw
12410	——	Thread Take-up Lever complete, Nos. 12166, 12408 and 12409
43946	5806	Thread Take-up Spring
7336	772	" " " Regulator
448c	783	" " " " Set Screw
20337	——	Throat Plate, large needle hole, for 20336
20338	1264	" " small needle hole, for 20336

NOTE: No. 20338 is sent with this Machine unless another Throat Plate is specified on order.

12469	——	Throat Plate, large needle hole, for 12468 and 20471
12470	777	Throat Plate, small needle hole, for 12468 and 20471
12482	——	Throat Plate, large needle hole, for 12481 and 43978
12483	778	Throat Plate, small needle hole, for 12481 and 43978
12456	779	Throat Plate, small needle hole, for 12455
12414	——	" " large needle hole, for 12372 and 20002
12442	778	Throat Plate, small needle hole, for 12372 and 20002
12465	——	Throat Plate, large needle hole, for 12437
12440	777	" " small needle hole, for 12437
20350	1267	" " large needle hole, for 20349
20351	——	" " small needle hole, for 20349
691F	782	" " Screw
24079	2644	Drip Pan with four 1 in. wire nails

LIST OF PARTS COMPLETE

FOR

MACHINE No. 44-3

FOR COLLAR AND CUFF WORK. DROP FEED

NO.	PLATE	NAME
*16501	——	Arm with 11104
8582	773	" Dowel Pin
12453	773	" Oil Tube for intermediate bearing
12454	773	" " " with 29599, for oiling 12409
11119	773	" " " " " " " 12408
24131	2014	" " " " " " " 20283
29599	2014	" " " Packing (felt)
748E	782	" Screw (back)
868E	1366	" " (front)
16511	1349	" Shaft
*11104	——	" " Bushing (front)
12357	767	" " Flanged Bushing (back)
448C	783	" " " " " Set Screw
144D	782	Arm Shaft Screw
12480	767	" Side Cap
219D	774	" " " Screw
12193	2004	" " Cover
286D	783	" " " Thumb Screw
12403	772	" Spool Pin and Thread Eyelet
11241	2003	" " " Washer (cloth)
24296	1348	Balance Wheel (power) light rim, $2\frac{3}{16}$ in. pulley, with two 448C
24297	1340	Balance Wheel Oil Cover
210D	1343	" " " " Screw
448C	783	" " Set Screw
*16503	——	Bed
20197	1350	Crank Connecting Rod with 20198 and two 896E
*20198	——	Crank Connecting Rod Cap
896E	773	" " " " Screw
908C	773	" " " Hinge Screw
1619E	773	" " " " " Nut
20057	——	Face Plate
20058	1340	Face Plate complete, Nos. 2827, 12150 and 20057

NO.	PLATE	NAME
190D	782	Face Plate Screw
44181	——	" " Thread Guard (lower)
12150	773	" " " " " 44181 with 12152
12152	773	Face Plate Thread Guard (lower) Rivet
2827	773	" " " " (upper) with 8505
8505	773	Face Plate Thread Guard (upper) Rivet
286D	783	" " Thumb Screw
12368	767	Feed Bar
313C	783	" " Screw Centre
56813	——	" " " " 313C with 1519J
1519J	783	" " " " Nut
3033	770	" Connecting Link
375C	782	" " " Hinge Screw
1518E	783	" " " " " Nut
12460	775	" Dog

NOTE: No. 12460 is sent with this Machine unless another Feed Dog is specified on order.

12433	775	Feed Dog
12471	775	" "
20369	775	" " 16 teeth (18 teeth to the inch)
208E	782	" " Screw
20283	1315	" and Feed Lifting Eccentric with 446C
446C	783	" " " " " Set Screw
24036	1340	" " " " " Sleeve
20284	1350	" Forked Connection
375C	782	" " " Hinge Screw
1518E	783	" " " " " Nut
24969	2551	" Lifting Rock Shaft
24970	——	Feed Lifting Rock Shaft complete, Nos. 12376 and 24969
12376	770	Feed Lifting Rock Shaft Crank with 157J and 1813
157J	782	Feed Lifting Rock Shaft Crank Clamping Screw
1813	783	Feed Lifting Rock Shaft Crank Roller and Stud
43976	2551	Feed Lifting Rock Shaft Crank Connecting Rod with 43977 and two 966E
*43977	——	Feed Lifting Rock Shaft Crank Connecting Rod Cap
966E	5806	Feed Lifting Rock Shaft Crank Connecting Rod Cap Screw
375C	782	Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw

NO.	PLATE	NAME
1518E	783	Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw Nut
307C	783	Feed Lifting Rock Shaft Screw Centre
56814	——	" " " " " " 307C with 1513J
1513J	783	Feed Lifting Rock Shaft Screw Centre Nut
3039	768	" Regulator
1128E	2009	" " Hinge Screw
818D	783	" " Thumb Screw
24585	8375	" " " " Stop
16506	766	" Rock Shaft
24376	——	Feed Rock Shaft complete, Nos. 16506 and 29633
29633	1354	Feed Rock Shaft Crank with 157J
157J	782	" " " " Clamping Screw
307C	783	" " " Screw Centre
56814	——	" " " " " 307C with 1513J
1513J	783	Feed Rock Shaft Screw Centre Nut
12381	767	Needle Bar (hollow)
19229	2004	" " " for high lift
12382	770	" " Connecting Link with 794E
794E	782	" " " " Adjusting Screw
*12383	——	Needle Bar Connecting Stud
1904	770	" " " " Roller (roller only)
453C	783	Needle Bar Connecting Stud Set Screw
12384	770	Needle Bar Connecting Stud complete, Nos. 453C, 1904 and 12383
20188	767	Needle Bar Crank with 858C and 1065C
1065C	1366	" " " Position Screw
858C	783	" " " Set Screw
936E	773	" " Screw Bushing
4302	773	" " Thread Guard
233D	782	" " " " Screw
4303	773	" Clamp with 808F
24101	——	" " Body
808F	782	" " Screw
24102	1353	" " Thread Guide
651D	1353	" " " " Screw
24103	1353	Needle Clamp (high lift) complete for 19229, Nos. 651D, 808F, 24101 and 24102
24104	1350	Oscillating Rock Shaft
24105	——	Oscillating Rock Shaft complete, Nos. 4784, 12388 and 24104

NO.	PLATE	NAME
12388	767	Oscillating Rock Shaft Hinge Pin.....
878J	783	" " " " " Oil Hole Stop Screw.....
12459	773	Oscillating Rock Shaft Hinge Pin Oil Hole Stop Screw Washer (leather).....
448C	783	Oscillating Rock Shaft Hinge Pin Set Screw.....
4784	1353	Oscillating Rock Shaft Oil Pad.....
16509	766	" Shaft.....
19496	——	" " Crank for 19447.....
44134	——	" " " " 44135.....
19447	1353	Oscillating Shaft Crank complete, Nos. 457C, 1518E, 19449 and 19496.....
44135	5806	Oscillating Shaft Crank complete, Nos. 1518E, 19449, 44134 and two 453C.....
2049	773	Oscillating Shaft Crank Pin.....
457C	783	" " " Set Screw for 19447
453C	783	" " " " " " 44135
19448	1353	" " " Slide Block.....
229D	782	" " " " " Cap Screw.....
12424	773	Oscillating Shaft Crank Slide Block Cap Screw Washer.....
988C	1353	Oscillating Shaft Crank Slide Block Screw Stud.....
1518E	783	Oscillating Shaft Crank Slide Block Screw Stud Nut.....
19449	1353	Oscillating Shaft Crank Slide Block complete, Nos. 229D, 988C, 12424 and 19448
12391	767	Presser Bar (hollow).....
20059	1341	" " Guide Bracket with 453C....
453C	783	" " " " Set Screw....
2062	771	" " Lifter.....
689C	782	" " " Screw.....
1520E	783	" " " " Nut.....
12327	770	" " Lifting and Releasing Lever Bracket.....
11167	767	Presser Bar Spring (light) .051 wire.....

NOTE: No. 11167 is sent with this Machine unless another Spring is specified on order.

12139	2004	Presser Bar Spring (medium) .055 wire...
20023	2004	" " " (heavy) .063 wire....
11170	771	" " " Washer.....

NO.	PLATE	NAME
12435	780	Presser Foot with 228D, for 12433, 12460, 12471 and 25967.....
		NOTE: No. 12435 is sent with this Machine unless another Presser Foot is specified on order.
12462	781	Presser Foot, for $\frac{3}{16}$ in. to $\frac{1}{4}$ in. gauge....
		NOTE: When ordering No. 12462, give width of turned edge from seam.
12463	781	Presser Foot with Strip Guide.....
26276	1394	" " Hinge Pin.....
20133	——	" " Plate.....
19223	——	" " Shank.....
20134	1308	Presser Foot (hinged) complete, for $\frac{3}{16}$ in. to $\frac{1}{4}$ in. gauge, Nos. 19223, 20133 and 26276.....
		NOTE: When ordering No. 20134, give width of turned edge from seam.
2532	772	Presser Foot Hinge Pin.....
20155	——	" " Plate.....
20156	——	" " Shank.....
20157	1309	Presser Foot (hinged) complete for 12433, 12460, 12471 and 25967, Nos. 228D, 2532, 20155 and 20156.....
26276	1394	Presser Foot Hinge Pin.....
20360	——	" " Plate.....
19335	——	" " Shank.....
20361	781	Presser Foot (hinged) plain bottom, complete, Nos. 19335, 20360 and 26276....
26279	——	Presser Foot Extension, $\frac{1}{16}$ in., for 12435 and 20157.....
26280	——	Presser Foot Extension, $\frac{1}{8}$ in., for 12435 and 20157.....
26281	1387	Presser Foot Extension, $\frac{1}{4}$ in., for 12435 and 20157.....
26282	——	Presser Foot Extension, $\frac{3}{8}$ in., for 12435 and 20157.....
26283	——	Presser Foot Extension, $\frac{1}{2}$ in., for 12435 and 20157.....
228D	2038	Presser Foot Extension Screw.....
190D	782	" " Screw.....
25967	1387	" " Strip Gauge for 12435 and 20157.....
228D	2038	Presser Foot Strip Gauge Screw.....
		NOTE: Nos. 25967 and 26279 to 26283 are sent with this Machine unless otherwise specified on order.

NO.	PLATE	NAME
688J	783	Pressure Regulating Thumb Screw
2996	771	Shuttle Bobbin
15140	1353	" " Case Latch
2973	771	" " " " Lever
2974	771	" " " " " Fulcrum Pin
2975	771	Shuttle Bobbin Case Latch Spring
592E	782	" " " " Stop Screw
15141	——	Shuttle Bobbin Case Hinge, Nos. 2973, 2974 and 15140
7553	771	Shuttle Bobbin Case Position Finger
2523	771	" " " " " Rivet
24412	1361	" " " " Plate
391D	1366	" " " " " Screw
24074	771	Shuttle Bobbin Case complete, Nos. 591F, 592E, 2523, 2975, 7553, 15098 and 15141
12393	771	Shuttle Body
591F	782	" Tension Regulating Screw
15098	771	" " Spring
19292	771	Shuttle, $1\frac{11}{16}$ in. diam., Nos. 2996, 12393 and 24074
*12394	——	Shuttle Driver
12444	771	" " 12394 with two 1266C
2049	773	" " Pin
1266C	5806	" " Set Screw
2531	767	" Race Back
2532	772	" " " Position Pin
2533	767	" " " Spring
907D	782	" " " " Screw
24416	——	" " Body
24414	1362	" " Cap
1053D	2006	" " " Screw
24417	1362	Shuttle Race complete, Nos. 907D, 2531, 2533, 24412, 24414, 24416 and two each 391D, 1053D and 2532
145D	782	Shuttle Race Screw
12431	——	" " Slide
12432	2004	Shuttle Race Slide complete, Nos. 4307, 12431 and two 725E
4307	772	Shuttle Race Slide Spring
725E	1387	" " " " Screw
20060	1311	Slack Thread Regulator
225F	1323	" " " Adjusting Screw
2102	5806	Tension Disc
1560C	783	" Regulating Thumb Nut
32572	5806	" Releasing Disc

NO.	PLATE	NAME
43944	5806	Tension Releasing Lever
12398	773	" " " Hinge Pin
12329	772	" " " Spring
32574	5806	" " Pin
50327c	5806	" Screw Stud
44141	——	" " " 50327c with 1560c
43945	5806	" Spring
44118	——	Tension complete, Nos. 7336, 32572, 32574, 43945, 43946, 44141 and two 2102
52454	5842	Thread Retainer
50429c	——	" " Set Screw
12404	770	" Take-up Crank
3094	773	" " " Wedge
690E	782	" " " " Screw
12408	770	" " Lever
775E	782	" " " Cap Screw
12166	773	" " " Hinge Pin
12409	770	" " " Link
11204	770	" " " " Hinge Pin
435c	5806	" " " " " " Set Screw
12410	——	Thread Take-up Lever complete, Nos. 12166, 12408 and 12409
43946	5806	Thread Take-up Spring
7336	772	" " " Regulator
448c	783	" " " " Set Screw
12461	775	Throat Plate, small needle hole, for 12460

NOTE: No. 12461 is sent with this Machine unless another Throat Plate is specified on order.

12434	775	Throat Plate, small needle hole, for 12433
12472	——	" " medium needle hole, for 12471 and 20369
12473	775	Throat Plate, small needle hole, for 12471 and 20369
691F	782	Throat Plate Screw
24079	2644	Drip Pan with four 1 in. wire nails

SPOOL HOLDER (Disc)

26763	1352	Bracket with 219F and 287D
219F	774	" Screw
287D	2636	" Thumb Screw
19066	1352	Spindle
19067	1352	" Thread Guiding Disc
691F	782	" " " " Screw
26764	1352	Spool Holder (disc) complete, Nos. 691F, 19066, 19067 and 26763

LIST OF PARTS COMPLETE

FOR



MACHINE No. 44-8

FOR LIGHT OR HEAVY CLOTH. HAS VERTICAL TRIMMER THAT TRIMS FROM $\frac{1}{16}$ TO $\frac{1}{4}$ INCH FROM THE SEAM. DROP FEED. MACHINES ARE FITTED WITH $\frac{1}{4}$ INCH CUTTING BAR UNLESS OTHERWISE ORDERED, AND AN EXTRA $\frac{3}{16}$ INCH CUTTING BAR AND PRESSER FOOT ARE ALSO FURNISHED. WHEN A DIFFERENT WIDTH IS ORDERED, THE EXTRA CUTTING BAR WILL BE ONE SIZE LARGER EXCEPT WHEN $\frac{1}{4}$ INCH IS REQUIRED.

NO.	PLATE	NAME
*16557	——	Arm with 11104
8582	773	" Dowel Pin
12453	773	" Oil Tube for intermediate bearing
12454	773	" " " with 29599, for oiling 12409
11119	773	" " " " " " " 12408 and 16569
24131	2014	Arm Oil Tube with 29599, for oiling 20283
29599	2014	" " " Packing (felt)
748E	782	" Screw (back)
868E	1366	" " (front)
16511	1349	" Shaft
*11104	——	" " Bushing (front)
12357	767	" " Flanged Bushing (back)
448C	783	" " " " " Set Screw
144D	782	Arm Shaft Screw
12193	2004	" Side Cover
286D	783	" " " Thumb Screw
12403	772	" Spool Pin and Thread Eyelet
11241	2003	" " " Washer (cloth)
24296	1348	Balance Wheel (power) light rim, $2\frac{3}{16}$ in. pulley, with two 448C
24297	1340	Balance Wheel Oil Cover
210D	1343	" " " " Screw
448C	783	" " Set Screw
*16596	——	Bed
20197	1350	Crank Connecting Rod with 20198 and two 896E
*20198	——	Crank Connecting Rod Cap
896E	773	" " " " Screw
908C	773	" " " Hinge Screw
1619E	773	" " " " " Nut
16558	——	Face Plate
16559	1351	Face Plate complete, Nos. 2827, 12150 and 16558
217D	1312	Face Plate Screw
44181	——	" " Thread Guard (lower)
12150	773	" " " " " 44181 with 12152
12152	773	Face Plate Thread Guard (lower) Rivet
2827	773	" " " " (upper) with 8505
8505	773	Face Plate Thread Guard (upper) Rivet.
12368	767	Feed Bar
313C	783	" " Screw Centre
56813	——	" " " " 313C with 1519J
1519J	783	" " " " Nut

NO.	PLATE	NAME
3033	770	Feed Connecting Link.....
375c	782	" " " Hinge Screw.....
1518E	783	" " " " " Nut..
24573	1271	" Dog, 24 teeth (32 teeth to the inch)
19103	1271	" " 12 teeth (16 teeth to the inch)
208E	782	" " Screw.....
20283	1315	" and Feed Lifting Eccentric with 446c
446c	783	" " " " " Set Screw
24036	1340	" " " " " Sleeve...
20284	1350	" Forked Connection.....
375c	782	" " " Hinge Screw....
1518E	783	" " " " " Nut
24969	2551	" Lifting Rock Shaft.....
24970	——	Feed Lifting Rock Shaft complete, Nos. 12376 and 24969.....
12376	770	Feed Lifting Rock Shaft Crank with 157J and 18'3.....
157J	782	Feed Lifting Rock Shaft Crank Clamping Screw.....
1813	783	Feed Lifting Rock Shaft Crank Roller and Stud.....
43976	2551	Feed Lifting Rock Shaft Crank Connecting Rod with 43977 and two 966E.....
*43977	——	Feed Lifting Rock Shaft Crank Connecting Rod Cap.....
966E	5806	Feed Lifting Rock Shaft Crank Connecting Rod Cap Screw.....
375c	782	Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw.....
1518E	783	Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw Nut.....
307c	783	Feed Lifting Rock Shaft Screw Centre...
56814	——	" " " " " " 307c with 1513J.....
1513J	783	Feed Lifting Rock Shaft Screw Centre Nut
3039	768	" Regulator.....
1128E	2009	" " Hinge Screw.....
818D	783	" " Thumb Screw.....
16506	766	" Rock Shaft.....
24376	——	Feed Rock Shaft complete, Nos. 16506 and 29633.....
29633	1354	Feed Rock Shaft Crank with 157J.....
157J	782	" " " " Clamping Screw..
307c	783	" " " Screw Centre.....
56814	——	" " " " " 307c with 1513J.....
1513J	783	Feed Rock Shaft Screw Centre Nut.....

NO.	PLATE	NAME
5726	1271	Knife
		NOTE: Two No. 5726 are sent with this Machine.
620F	782	Knife Adjusting Screw
19297	1315	" Bar with 2301
24431	1352	" " Crank with 191c
1162c	1366	" " " Coupling Pin
1564D	2442	" " " " " Head
2297	2442	" " " " " Spring
2022	773	" " " Pin
191c	1366	" " " Set Screw
24432	——	Knife Bar Crank complete, Nos. 1162c, 1564D, 2297 and 24431
16563	1315	Knife Bar Driving Crank (forked)
16564	1315	" " " " Bracket
24433	——	Knife Bar Driving Crank Bracket complete, Nos. 2022, 16563, 16564 and 24432
647c	774	Knife Bar Driving Crank Bracket Screw
24122	1317	" " Lifting Spring
24123	1317	" " " Case
24124	1317	" " " " Guide
*24906	——	" " " " " 24124 with 2523 and 24125
24125	1317	Knife Bar Lifting Spring Guide Bracket
621D	1317	" " " " " " Screw
2523	1317	" " " " " Pin
2301	1317	" " Stop Pin
24128	——	Knife Bar complete, Nos. 621D, 19297, 19391, 24109, 24906 and three 335H
19391	8376	Knife Holder with 620F, 2291 and two 223F
24109	8376	" " Handle
335H	1317	" " " Screw
335H	1317	" " Screw
223F	1317	" Screw
2291	1317	" " Washer
16568	1352	Needle Bar with 620F, 1072F and 24391
12382	770	" " Connecting Link with 794E
794E	782	" " " " Adjusting Screw
*12383	——	Needle Bar Connecting Stud
1904	770	" " " " Roller (roller only)
453c	783	Needle Bar Connecting Stud Set Screw
12384	770	Needle Bar Connecting Stud complete, Nos. 453c, 1904 and 12383
16569	1315	Needle Bar Crank (eccentric) with 448c and 743c

NO.	PLATE	NAME
743c	1317	Needle Bar Crank Position Screw.....
448c	783	" " " Set Screw.....
24391	8376	" " Thread Guard.....
620F	782	" " " " Set Screw....
1072F	1317	" Set Screw.....
24104	1350	Oscillating Rock Shaft.....
24105	——	Oscillating Rock Shaft complete, Nos. 4784, 12388 and 24104.....
12388	767	Oscillating Rock Shaft Hinge Pin.....
878J	783	" " " " " Oil Hole Stop Screw.....
12459	773	Oscillating Rock Shaft Hinge Pin Oil Hole Stop Screw Washer (leather).....
448c	783	Oscillating Rock Shaft Hinge Pin Set Screw.....
4784	1353	Oscillating Rock Shaft Oil Pad.....
16509	766	" Shaft.....
19496	——	" " Crank for 19447.....
44134	——	" " " " 44135.....
19447	1353	Oscillating Shaft Crank complete, Nos. 457c, 1518E, 19449 and 19496.....
44135	5806	Oscillating Shaft Crank complete, Nos. 1518E, 19449, 44134 and two 453c.....
2049	773	Oscillating Shaft Crank Pin.....
457c	783	" " " Set Screw for 19447
453c	783	" " " " " " 44135
19448	1353	" " " Slide Block.....
229D	782	" " " " " Cap Screw.....
12424	773	Oscillating Shaft Crank Slide Block Cap Screw Washer.....
988c	1353	Oscillating Shaft Crank Slide Block Screw Stud.....
1518E	783	Oscillating Shaft Crank Slide Block Screw Stud Nut.....
19449	1353	Oscillating Shaft Crank Slide Block complete, Nos. 229D, 988c, 12424 and 19448
12391	767	Presser Bar (hollow).....
12326	770	" " Guide Bracket with 453c....
453c	783	" " " " Set Screw....
2062	771	" " Lifter.....
689c	782	" " " Screw.....
1520E	783	" " " " Nut.....
12327	770	" " Lifting and Releasing Lever Bracket.....

NO.	PLATE	NAME
11167	767	Presser Bar Spring (light) .051 wire.....
		NOTE: No. 11167 is sent with this Machine unless another Spring is specified on order.
12139	2004	Presser Bar Spring (medium) .055 wire...
20023	2004	" " " (heavy) .063 wire....
11170	771	" " " Washer.....
24722	1271	" Foot, $\frac{1}{16}$ in. to $\frac{11}{64}$ in. gauge, for 19103 and 24573.....
19392	1271	Presser Foot, $\frac{3}{16}$ in. gauge and above, for 19103 and 24573.....
		NOTE: No. 24722, $\frac{1}{8}$ in. gauge, and No. 19392, $\frac{3}{16}$ in. gauge, are sent with this Machine unless other gauges are specified on order.
190D	782	Presser Foot Screw.....
688J	783	Pressure Regulating Thumb Screw.....
2996	771	Shuttle Bobbin.....
15140	1353	" " Case Latch.....
2973	771	" " " " Lever.....
2974	771	" " " " " Fulcrum Pin.....
2975	771	Shuttle Bobbin Case Latch Spring.....
592E	782	" " " " Stop Screw...
15141	——	Shuttle Bobbin Case Hinge, Nos. 2973, 2974 and 15140.....
7553	771	Shuttle Bobbin Case Position Finger.....
2523	771	" " " " " Rivet
24412	1361	" " " " Plate.....
391D	1366	" " " " " Screw
24074	771	Shuttle Bobbin Case complete, Nos. 591F, 592E, 2523, 2975, 7553, 15098 and 15141
12393	771	Shuttle Body.....
591F	782	" Tension Regulating Screw.....
15098	771	" " Spring.....
19292	771	Shuttle, $1\frac{11}{16}$ in. diam., Nos. 2996, 12393 and 24074.....
*12394	——	Shuttle Driver.....
12444	771	" " 12394 with two 1266C....
2049	773	" " Pin.....
1266C	5806	" " Set Screw.....
2531	767	" Race Back.....
2532	772	" " " Position Pin.....
2533	767	" " " Spring.....
907D	782	" " " " Screw.....
24413	——	" " Body.....
62502	——	" " " 24413 with 24418 and two 1053D, for 62517.....

NO.	PLATE	NAME
62517	——	Shuttle Race Body 62502 with two 2532, for 24419
24418	1362	Shuttle Race Cap
1053D	2006	" " " Screw
24419	1362	Shuttle Race complete, Nos. 907D, 2531, 2533, 24412, 62517 and two 391D
145D	782	Shuttle Race Screw
12431	——	" " Slide
12432	2004	Shuttle Race Slide complete, Nos. 4307, 12431 and two 725E
4307	772	Shuttle Race Slide Spring
725E	1387	" " " " Screw
2102	5806	Tension Disc
1560C	783	" Regulating Thumb Nut
32572	5806	" Releasing Disc
43944	5806	" " Lever
12398	773	" " " Hinge Pin
12329	772	" " " Spring
32574	5806	" " Pin
50327C	5806	" Screw Stud
44141	——	" " " 50327C with 1560C
43945	5806	" Spring
44118	——	Tension complete, Nos. 7336, 32572, 32574, 43945, 43946, 44141 and two 2102
12149	2014	Tension Thread Guard
52454	5842	Thread Retainer
50429C	——	" " Set Screw
12404	770	" Take-up Crank
3094	773	" " " Wedge
690E	782	" " " " Screw
12408	770	" " Lever
775E	782	" " " Cap Screw
12166	773	" " " Hinge Pin
12409	770	" " " Link
11204	770	" " " " Hinge Pin
435C	5806	" " " " " " Set Screw
12410	——	Thread Take-up Lever complete, Nos. 12166, 12408 and 12409
43946	5806	Thread Take-up Spring
7336	772	" " " Regulator
448C	783	" " " " Set Screw

NO.	PLATE	NAME
5729	——	Throat Plate Body.....
5730	1271	" " Cutting Bar.....

NOTE: When ordering No. 5730, state required distance of trimmed edge from seam.

NOTE: No. 5730, $\frac{3}{16}$ in. gauge, is sent with this Machine unless otherwise specified on order.

578D	8376	Throat Plate Cutting Bar Screw.....
5731	1271	" " Slide.....
578D	8376	" " " Adjusting Screw.....
5732	1271	Throat Plate complete for 19103 and 24573, Nos. 5729 to 5731 and three 578D

NOTE: When ordering No. 5732, state required distance of trimmed edge from seam.

NOTE: No. 5732, ⅛ in. gauge, is sent with this Machine unless otherwise specified on order.

691F	782	Throat Plate Screw.....
24079	2644	Drip Pan with four 1 in. wire nails.....

LIST OF PARTS COMPLETE

FOR



MACHINE No. 44-9

FOR CLOTH OR LEATHER. USEFUL FOR WORK OF UNEQUAL THICKNESS AND FOR BINDING WITH BINDERS OF DIFFERENT WIDTHS. DROP FEED. ALTERNATING PRESSERS.

NO.	PLATE	NAME
*19353	——	Arm with 11104
8582	773	" Dowel Pin
12453	773	" Oil Tube for intermediate bearing
12454	773	" " " with 29599, for oiling 12409
11119	773	" " " " " " " 12408 and 19365
24131	2014	Arm Oil Tube with 29599, for oiling 20283
29599	2014	" " " Packing (felt)
748E	782	" Screw (back)
868E	1366	" " (front)

NO.	PLATE	NAME
16511	1349	Arm Shaft
*11104	——	" " Bushing (front)
12357	767	" " Flanged Bushing (back)
448c	783	" " " " " Set Screw
144d	782	Arm Shaft Screw
12193	2004	" Side Cover
286d	783	" " " Thumb Screw
12403	772	" Spool Pin and Thread Eyelet
11241	2003	" " " Washer (cloth)
24296	1348	Balance Wheel (power) light rim, $2\frac{3}{16}$ in. pulley, with two 448c
24297	1340	Balance Wheel Oil Cover
210d	1343	" " " " Screw
448c	783	" " Set Screw
*24454	——	Bed
20197	1350	Crank Connecting Rod with 20198 and two 896e
*20198	——	Crank Connecting Rod Cap
896e	773	" " " " Screw
908c	773	" " " Hinge Screw
1619e	773	" " " " " Nut
19354	——	Face Plate
19355	1311	Face Plate complete, Nos. 2827, 12150 and 19354
219d	774	Face Plate Screw
44181	——	" " Thread Guard (lower)
12150	773	" " " " " 44181 with 12152
12152	773	Face Plate Thread Guard (lower) Rivet
2827	773	" " " " (upper) with 8505
8505	773	" " " " " Rivet
12368	767	Feed Bar
313c	783	" " Screw Centre
56813	——	" " " " 313c with 1519j
1519j	783	" " " " Nut
3033	770	" Connecting Link
375c	782	" " " Hinge Screw
1518e	783	" " " " " Nut.
12370	778	Feed Dog, 15 teeth (16 teeth to the inch)

Note: No. 12370 is sent with this Machine unless another Feed Dog is specified on order.

43979	778	Feed Dog, 21 teeth (22 teeth to the inch)
12369	776	" " 12 teeth (12 teeth to the inch)
12457	776	" " 16 teeth (16 teeth to the inch)
20106	1259	" "

NO.	PLATE	NAME
208E	782	Feed Dog Screw
20283	1315	" and Feed Lifting Eccentric with 446C
446C	783	" " " " " Set Screw
24036	1340	" " " " " Sleeve
20284	1350	" Forked Connection
375C	782	" " " Hinge Screw
1518E	783	" " " " " Nut
24969	2551	" Lifting Rock Shaft
24970	——	Feed Lifting Rock Shaft complete, Nos. 12376 and 24969
12376	770	Feed Lifting Rock Shaft Crank with 157J and 1813
157J	782	Feed Lifting Rock Shaft Crank Clamping Screw
1813	783	Feed Lifting Rock Shaft Crank Roller and Stud
43976	2551	Feed Lifting Rock Shaft Crank Connecting Rod with 43977 and two 966E
*43977	——	Feed Lifting Rock Shaft Crank Connecting Rod Cap
966E	5806	Feed Lifting Rock Shaft Crank Connecting Rod Cap Screw
375C	782	Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw
1518E	783	Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw Nut
307C	783	Feed Lifting Rock Shaft Screw Centre
56814	——	" " " " " " 307C with 1513J
1513J	783	Feed Lifting Rock Shaft Screw Centre Nut
3039	768	" Regulator
1128E	2009	" " Hinge Screw
818D	783	" " Thumb Screw
16506	766	" Rock Shaft
24376	——	Feed Rock Shaft complete, Nos. 16506 and 29633
29633	1354	Feed Rock Shaft Crank with 157J
157J	782	" " " " Clamping Screw
307C	783	" " " Screw Centre
56814	——	" " " " " 307C with 1513J
1513J	783	Feed Rock Shaft Screw Centre Nut
12391	767	Lifting Presser Bar (hollow)
19356	1312	" " " Bell Crank
199D	1312	" " " " " Cap Screw
19357	1312	" " " " " Connecting Link

NO.	PLATE	NAME
199D	1312	Lifting Presser Bar Bell Crank Connecting Link Cap Screw
19358	1312	Lifting Presser Bar Bell Crank Driving Arm
19362	1313	Lifting Presser Bar Bell Crank Driving Arm Eccentric Connection
375C	782	Lifting Presser Bar Bell Crank Driving Arm Eccentric Connection Hinge Screw
1518E	783	Lifting Presser Bar Bell Crank Driving Arm Eccentric Connection Hinge Screw Nut
2049	773	Lifting Presser Bar Bell Crank Driving Arm Pin
19359	1312	Lifting Presser Bar Bell Crank Driving Arm Shaft
19360	1311	Lifting Presser Bar Bell Crank Driving Arm Shaft Bracket
19361	——	Lifting Presser Bar Bell Crank Driving Arm Shaft Bracket complete, Nos. 2049 and 19358 to 19360
965D	1312	Lifting Presser Bar Bell Crank Driving Arm Shaft Bracket Screw
24589	5736	Lifting Presser Bar Guide Bracket with 453C
24716	——	Lifting Presser Bar Guide Bracket complete, Nos. 19356, 19357, 19366, 24589 and three 199D
453C	783	Lifting Presser Bar Guide Bracket Set Screw
24590	5736	Lifting Presser Bar Guide Bracket Support
175D	5736	" " " " " " Screw
4855	1312	Lifting Presser Bar Lifter
689C	782	" " " " Screw
1520E	783	" " " " " Nut
12327	770	" " " Lifting and Releasing Lever Bracket
11167	767	Lifting Presser Bar Spring (light) .051 wire
		NOTE: No. 11167 is sent with this Machine unless another Spring is specified on order.
12139	2004	Lifting Presser Bar Spring (medium) .055 wire
20023	2004	Lifting Presser Bar Spring (heavy) .063 wire

NO.	PLATE	NAME
11170	771	Lifting Presser Bar Spring Washer.....
19364	1312	" " Foot.....
19375	1313	" " " .....
193D	1312	" " " Screw.....
12381	767	Needle Bar (hollow).....
12382	770	" " Connecting Link with 794E...
794E	782	" " " " Adjusting Screw.....
*12383	——	Needle Bar Connecting Stud.....
1904	770	" " " " Roller (roller only).....
453C	783	Needle Bar Connecting Stud Set Screw...
12384	770	Needle Bar Connecting Stud complete, Nos. 453C, 1904 and 12383.....
19365	1311	Needle Bar Crank and Lifting Eccentric with 448C and 743C.....
743C	1313	Needle Bar Crank and Lifting Eccentric Position Screw.....
448C	783	Needle Bar Crank and Lifting Eccentric Set Screw.....
936E	773	Needle Bar Screw Bushing.....
4302	773	" " Thread Guard.....
233D	782	" " " " Screw.....
4303	773	" Clamp with 808F.....
808F	782	" " Screw.....
24104	1350	Oscillating Rock Shaft.....
24105	——	Oscillating Rock Shaft complete, Nos. 4784, 12388 and 24104.....
12388	767	Oscillating Rock Shaft Hinge Pin.....
878J	783	" " " " " Oil Hole Stop Screw.....
12459	773	Oscillating Rock Shaft Hinge Pin Oil Hole Stop Screw Washer (leather).....
448C	783	Oscillating Rock Shaft Hinge Pin Set Screw.....
4784	1353	Oscillating Rock Shaft Oil Pad.....
16509	766	" Shaft.....
19496	——	" " Crank for 19447.....
44134	——	" " " " 44135.....
19447	1353	Oscillating Shaft Crank complete, Nos. 457C, 1518E, 19449 and 19496.....
44135	5806	Oscillating Shaft Crank complete, Nos. 1518E, 19449, 44134 and two 453C.....
2049	773	Oscillating Shaft Crank Pin.....
457C	783	" " " Set Screw for 19447
453C	783	" " " " " for 44135

NO.	PLATE	NAME
19448	1353	Oscillating Shaft Crank Slide Block.....
229D	782	" " " " " Cap Screw.....
12424	773	Oscillating Shaft Crank Slide Block Cap Screw Washer.....
988C	1353	Oscillating Shaft Crank Slide Block Screw Stud.....
1518E	783	Oscillating Shaft Crank Slide Block Screw Stud Nut.....
19449	1353	Oscillating Shaft Crank Slide Block complete, Nos. 229D, 988C, 12424 and 19448
688J	783	Pressure Regulating Thumb Screw.....
2996	771	Shuttle Bobbin.....
15140	1353	" " Case Latch.....
2973	771	" " " " Lever.....
2974	771	" " " " " Fulcrum Pin.....
2975	771	Shuttle Bobbin Case Latch Spring.....
592E	782	" " " " Stop Screw...
15141	——	Shuttle Bobbin Case Hinge, Nos. 2973, 2974 and 15140.....
7553	771	Shuttle Bobbin Case Position Finger.....
2523	771	" " " " " Rivet
24412	1361	" " " " Plate.....
391D	1366	" " " " " Screw
24074	771	Shuttle Bobbin Case complete, Nos. 591F, 592E, 2523, 2975, 7553, 15098 and 15141
24889	8375	Shuttle Body.....
591F	782	" Tension Regulating Screw.....
15098	771	" " Spring.....
24890	8375	Shuttle, 1 $\frac{11}{16}$ in. diam., Nos. 2996, 24074 and 24889.....
*12394	——	Shuttle Driver.....
12444	771	" " 12394 with two 1266C....
2049	773	" " Pin.....
1266C	5806	" " Set Screw.....
2531	767	" Race Back.....
2532	772	" " " Position Pin.....
2533	767	" " " Spring.....
907D	782	" " " " Screw.....
24413	——	" " Body.....
62502	——	" " " 24413 with 24418 and two 1053D.....
62517	——	Shuttle Race Body 62502 with two 2532..
24418	1362	" " Cap.....
1053D	2006	" " " Screw.....

NO.	PLATE	NAME
24419	1362	Shuttle Race complete, Nos. 907D, 2531, 2533, 24412, 62517 and two 391D.....
145D	782	Shuttle Race Screw.....
12431	——	" " Slide.....
12432	2004	Shuttle Race Slide complete, Nos. 4307, 12431 and two 725E.....
4307	772	Shuttle Race Slide Spring.....
725E	1387	" " " " Screw.....
2921	771	Tension Disc.....
1560C	783	" Regulating Thumb Nut.....
20037	2009	" Releaser.....
12397	772	" Releasing Lever.....
12398	773	" " " Hinge Pin.....
12329	772	" " " Spring.....
413C	783	" Screw Stud.....
33892	——	" " " 413C with 1560C ....
2923	771	" Spring.. .....
12149	2014	" Thread Guard.....
44147	——	Tension complete, Nos. 2923, 7336, 8511, 20037, 33892 and two 2921.....
52454	5842	Thread Retainer.....
50429C	——	" " Set Screw.....
12404	770	" Take-up Crank.....
3094	773	" " " Wedge.....
690E	782	" " " " Screw....
12408	770	" " Lever.....
775E	782	" " " Cap Screw.....
12166	773	" " " Hinge Pin.....
12409	770	" " " Link.....
11204	770	" " " " Hinge Pin
435C	5806	" " " " " " Set Screw.....
12410	——	Thread Take-up Lever complete, Nos. 12166, 12408 and 12409.....
8511	773	Thread Take-up Spring.....
7336	772	" " " Regulator.....
448C	783	" " " " Set Screw
12412	778	Throat Plate, large needle hole, for 12370 and 43979.....

NOTE: No. 12412 is sent with this Machine unless another Throat Plate is specified on order.

12411	776	Throat Plate, large needle hole, for 12369 and 12457.....
12449	——	Throat Plate, small needle hole, for 12369 and 12457.....

NO.	PLATE	NAME
20107	1259	Throat Plate, small needle hole, for 20106
691F	782	" " Screw.....
19366	1313	Vibrating Presser Bar.....
19367	1313	" " " Cap.....
199D	1312	" " " " Screw for 19366
219F	774	" " " " " " 19367
19368	1313	" " " Cushion (rawhide)
19369	1313	" " " Spring.....
335D	1313	" " " " Screw.....
19370	1312	" " Foot for 12370 and 43979
19374	1313	" " " " 12369 and 12457
19376	1313	" " " " 20106.....
217D	1312	" " " Screw.....
24079	2644	Drip Pan with four 1 in. wire nails.....

LIST OF PARTS COMPLETE

FOR

MACHINE No. 44-13

FOR CLOTH. THROAT PLATE FLUSH WITH BED. DROP FEED

NO.	PLATE	NAME
*16501	——	Arm with 11104
8582	773	" Dowel Pin
12453	773	" Oil Tube for intermediate bearing
12454	773	" " " with 29599, for oiling 12409
11119	773	" " " " " " " 12408
24131	2014	" " " " " " " 20283
29599	2014	" " " Packing (felt)
748E	782	" Screw (back)
868E	1366	" " (front)
16511	1349	" Shaft
*11104	——	" " Bushing (front)
12357	767	" " Flanged Bushing (back)
448c	783	" " " " " Set Screw

NO.	PLATE	NAME
144D	782	Arm Shaft Screw
12480	767	" Side Cap
219D	774	" " " Screw
12193	2004	" " Cover
286D	783	" " " Thumb Screw
12403	772	" Spool Pin and Thread Eyelet
11241	2003	" " " Washer (cloth)
24296	1348	Balance Wheel (power) light rim, $2\frac{3}{16}$ in. pulley, with two 448C
24297	1340	Balance Wheel Oil Cover
210D	1343	" " " " Screw
448C	783	" " Set Screw
*16503	——	Bed
20197	1350	Crank Connecting Rod with 20198 and two 896E
*20198	——	Crank Connecting Rod Cap
896E	773	" " " " Screw
908C	773	" " " Hinge Screw
1619E	773	" " " " " Nut
20057	——	Face Plate
20058	1340	Face Plate complete, Nos. 2827, 12150 and 20057
190D	782	Face Plate Screw
44181	——	" " Thread Guard (lower)
12150	773	" " " " " 44181 with 12152
12152	773	Face Plate Thread Guard (lower) Rivet
2827	773	" " " " (upper) with 8505
8505	773	" " " " " Rivet
286D	783	" " Thumb Screw
12368	767	Feed Bar
313C	783	" " Screw Centre
56813	——	" " " " 313C with 1519J
1519J	783	" " " " Nut
3033	770	" Connecting Link
375C	782	" " " Hinge Screw
1518E	783	" " " " " Nut
12369	776	Feed Dog, 12 teeth (12 teeth to the inch)

NOTE: No. 12369 is sent with this Machine unless another Feed Dog is specified on order.

12457	776	Feed Dog, for cloth, 16 teeth (16 teeth to the inch)
12425	779	Feed Dog, for cloth
12450	777	" " " " 11 teeth (18 teeth to the inch)

NO.	PLATE	NAME
20348	777	Feed Dog, for chiffon, 22 teeth (36 teeth to the inch).....
12370	778	Feed Dog, for cloth, 15 teeth (16 teeth to the inch).....
43979	778	Feed Dog, for cloth, 21 teeth (22 teeth to the inch).....
20106	1259	Feed Dog, for cloth.....
20117	1261	" " " shirt work, 16 teeth (16 tceeth to the inch) beveled for hemmer
20119	1259	Feed Dog, for heavy work on duck, overalls, etc.....
44144	1262	Feed Dog, 22 teeth (24 teeth to the inch) beveled for hemmer.....
20138	1263	Feed Dog, for shirt work, 13 teeth (12 teeth to the inch) beveled for hemmer
20147	1260	Feed Dog, 12 teeth (14 teeth to the inch)
44177	1260	" " 19 teeth (22 teeth to the inch)
44156	1262	" " 24 teeth (24 teeth to the inch)
20151	1262	" " 13 teeth (14 teeth to the inch) for shirt work, beveled for hemmer....
20158	1262	Feed Dog, 17 teeth (16 teeth to the inch) for shirt work.....
20162	1263	Feed Dog, 17 teeth (16 teeth to the inch) for shirt work, beveled for hemmer....
208E	782	Feed Dog Screw.....
20283	1315	" and Feed Lifting Eccentric with 446C
446C	783	" " " " " Set Screw
24036	1340	" " " " " Sleeve...
20284	1350	" Forked Connection.....
375C	782	" " " Hinge Screw...
1518E	783	" " " " " Nut
24969	2551	" Lifting Rock Shaft.....
24970	——	Feed Lifting Rock Shaft complete, Nos. 12376 and 24969.....
12376	770	Feed Lifting Rock Shaft Crank with 157J and 1813.....
157J	782	Feed Lifting Rock Shaft Crank Clamping Screw.....
1813	783	Feed Lifting Rock Shaft Crank Roller and Stud.....
43976	2551	Feed Lifting Rock Shaft Crank Connecting Rod with 43977 and two 966E.....
43977	——	Feed Lifting Rock Shaft Crank Connecting Rod Cap.....
966E	5806	Feed Lifting Rock Shaft Crank Connecting Rod Cap Screw.....
375C	782	Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw.....

NO.	PLATE	NAME
1518E	783	Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw Nut
307C	783	Feed Lifting Rock Shaft Screw Centre
56814	——	" " " " " " 307C with 1513J
1513J	783	Feed Lifting Rock Shaft Screw Centre Nut
3039	768	" Regulator
1128E	2009	" " Hinge Screw
818D	783	" " Thumb Screw
16506	766	" Rock Shaft
24376	——	Feed Rock Shaft complete, Nos. 16506 and 29633
29633	1354	Feed Rock Shaft Crank with 157J
157J	782	" " " " Clamping Screw
307C	783	" " " Screw Centre
56814	——	" " " " " 307C with 1513J
1513J	783	Feed Rock Shaft Screw Centre Nut
12381	767	Needle Bar (hollow)
12382	770	" " Connecting Link with 794E
794E	782	" " " " Adjusting Screw
*12383	——	Needle Bar Connecting Stud
1904	770	" " " " Roller (roller only)
453C	783	Needle Bar Connecting Stud Set Screw
12384	770	Needle Bar Connecting Stud complete, Nos. 453C, 1904 and 12383
20188	767	Needle Bar Crank with 858C and 1065C
1065C	1366	" " " Position Screw
858C	783	" " " Set Screw
936E	773	" " Screw Bushing
4302	773	" " Thread Guard
233D	782	" " " " Screw
4303	773	" Clamp with 808F
808F	782	" " Screw
24104	1350	Oscillating Rock Shaft
24105	——	Oscillating Rock Shaft complete, Nos. 4784, 12388 and 24104
12388	767	Oscillating Rock Shaft Hinge Pin
878J	783	" " " " " Oil Hole Stop Screw
12459	773	Oscillating Rock Shaft Hinge Pin Oil Hole Stop Screw Washer (leather)
448C	783	Oscillating Rock Shaft Hinge Pin Set Screw

NO.	PLATE	NAME
4784	1353	Oscillating Rock Shaft Oil Pad.....
16509	766	" Shaft.....
19496	——	" " Crank for 19447.....
44134	——	" " " " 44135.....
19447	1353	Oscillating Shaft Crank complete, Nos. 457c, 1518e, 19449 and 19496.....
44135	5806	Oscillating Shaft Crank complete, Nos. 1518e, 19449, 44134 and two 453c.....
2049	773	Oscillating Shaft Crank Pin.....
457c	783	" " " Set Screw for 19447
453c	783	" " " " " " 44135
19448	1353	" " " Slide Block.....
229d	782	" " " " " Cap Screw.....
12424	773	Oscillating Shaft Crank Slide Block Cap Screw Washer.....
988c	1353	Oscillating Shaft Crank Slide Block Screw Stud.....
1518e	783	Oscillating Shaft Crank Slide Block Screw Stud Nut.....
19449	1353	Oscillating Shaft Crank Slide Block complete, Nos. 229d, 988c, 12424 and 19448
12391	767	Presser Bar (hollow).....
20059	1341	" " Guide Bracket with 453c....
453c	783	" " " " Set Screw....
2062	771	" " Lifter.....
689c	782	" " " Screw.....
1520e	783	" " " " Nut.....
12327	770	" " Lifting and Releasing Lever Bracket.....
11167	767	Presser Bar Spring (light) .051 wire.....

NOTE: No. 11167 is sent with this Machine unless another Spring is specified on order.

12139	2004	Presser Bar Spring (medium) .055 wire...
20023	2004	" " " (heavy) .063 wire....
11170	771	" " " Washer.....
12142	780	" Foot for 12370 and 43979.....
12143	780	" " " 12369, 12457 and 20106

NOTE: No. 12143 is sent with this Machine unless another Presser Foot is specified on order.

12258	1308	Presser Foot (wide) for 12369, 12457 and 20106.....
12335	1308	Presser Foot (narrow) for 12369, 12457 and 20106.....

NO.	PLATE	NAME
12144	780	Presser Foot for 20117, 20138, 20147, 20151, 20158, 20162, 44144, 44156 and 44177
12259	780	Presser Foot for 12425
12260	780	" " " 12450, 20147 and 44177
12474	1308	" " " 20138 and 20162
7298	2014	" " Hinge Pin
19334	——	" " Plate
19335	——	" " Shank
19336	1308	Presser Foot (hinged) complete for 12370 and 43979, Nos. 7298, 19334 and 19335
62527	5806	Presser Foot Hinge Pin
24544	——	" " Plate
24982	——	" " Shank
26231	2014	" " Spring
24983	781	Presser Foot (spring hinged) complete for 20119, Nos. 24544, 24982, 26231 and 62527
7298	2014	Presser Foot Hinge Pin
20268	——	" " Plate
20269	——	" " Shank
20270	1308	Presser Foot (hinged) complete for 12369, 12457 and 20106, Nos. 7298, 20268 and 20269
20342	781	Presser Foot for 12450 and 20348
20343	781	" " with guide on bottom to the right of needle hole
190D	782	Presser Foot Screw
688J	783	Pressure Regulating Thumb Screw
19131	5737	Shuttle Bobbin
20649	5737	" " Case Latch
2973	5737	" " " " Lever
2974	5737	" " " " " Fulcrum Pin
2975	5737	Shuttle Bobbin Case Latch Spring
592E	5737	" " " " Stop Screw
20650	——	Shuttle Bobbin Case Hinge, Nos. 2973, 2974 and 20649
20755	5737	Shuttle Bobbin Case Position Finger
2523	5737	" " " " " Rivet
24323	2046	" " " " Plate
391D	1366	" " " " " Screw
20756	5737	Shuttle Bobbin Case complete, Nos. 591F, 592E, 2523, 2975, 20650, 20654 and 20755

NO.	PLATE	NAME
20757	5737	Shuttle Body
591F	5737	" Tension Regulating Screw
20654	5737	" " Spring
20758	5737	Shuttle, $1\frac{11}{16}$ in. diam., Nos. 19131, 20756 and 20757
19406	2012	Shuttle Driver with two 1266C
2049	773	" " Pin
1266C	5806	" " Set Screw
2419	2006	" Race Back
2532	772	" " " Position Pin
2533	767	" " " Spring
907D	782	" " " " Screw
24324	——	" " Body
24998	——	" " " 24324 with 24009 and two 1053D
24009	2006	Shuttle Race Cap
1053D	2006	" " " Screw
24325	2046	Shuttle Race complete, Nos. 907D, 2419, 2533, 24323, 24998 and two each 391D and 2532
145D	782	Shuttle Race Screw
12431	——	" " Slide
12432	2004	Shuttle Race Slide complete, Nos. 4307, 12431 and two 725E
4307	772	Shuttle Race Slide Spring
725E	1387	" " " " Screw
20060	1311	Slack Thread Regulator
225F	1323	" " " Adjusting Screw
2102	5806	Tension Disc
1560C	783	" Regulating Thumb Nut
32572	5806	" Releasing Disc
43944	5806	" " Lever
12398	773	" " " Hinge Pin
12329	772	" " " Spring
32574	5806	" " Pin
50327C	5806	" Screw Stud
44141	——	" " " 50327C with 1560C
43945	5806	" Spring
44118	——	Tension complete, Nos. 7336, 32572, 32574, 43945, 43946, 44141 and two 2102
52454	5842	Thread Retainer
50429C	——	" " Set Screw
12404	770	" Take-up Crank
3094	773	" " " Wedge
690E	782	" " " " Screw
12408	770	" " Lever
775E	782	" " " Cap Screw

NO.	PLATE	NAME
12166	773	Thread Take-up Lever Hinge Pin.....
12409	770	" " " Link.....
11204	770	" " " " Hinge Pin...
435c	5806	" " " " " " Set Screw.....
12410	——	Thread Take-up Lever complete, Nos. 12166, 12408 and 12409.....
43946	5806	Thread Take-up Spring.....
7336	772	" " " Regulator.....
448c	783	" " " " Set Screw
12411	776	Throat Plate, large needle hole, for 12369 and 12457.....

NOTE: No. 12411 is sent with this Machine unless another Throat Plate is specified on order.

12449	——	Throat Plate, small needle hole, for 12369 and 12457.....
12412	778	Throat Plate, large needle hole, for 12370 and 43979.....
12466	——	Throat Plate, small needle hole, for 12425
12464	777	" " large needle hole, for 12450 and 20348.....
12451	——	Throat Plate, small needle hole, for 12450 and 20348.....
19497	1261	Throat Plate, large needle hole, for 20117
19405	——	" " small needle hole, for 20117
19409	——	" " large needle hole, for 20138 and 20162.....
19410	1263	Throat Plate, small needle hole, for 20138 and 20162.....
19412	1260	Throat Plate, large needle hole, for 20147 and 44177.....
19413	——	Throat Plate, small needle hole, for 20147 and 44177.....
19415	1262	Throat Plate, large needle hole, for 20151 and 44144.....
19416	——	Throat Plate, small needle hole, for 20151 and 44144.....
19418	1262	Throat Plate, large needle hole, for 20158 and 44156.....
19419	——	Throat Plate, small needle hole, for 20158 and 44156.....
20107	1259	Throat Plate, small needle hole, for 20106

NO.	PLATE	NAME
20120	1259	Throat Plate, large oblong needle hole, for 20119.....
20187	——	Throat Plate, small oblong needle hole, for 20119.....
691F	782	Throat Plate Screw.....
24079	2644	Drip Pan with four 1 in. wire nails.....

LIST OF PARTS COMPLETE

FOR

MACHINE No. 44-17

FOR COLLARS AND CUFFS. THROAT PLATE FLUSH WITH BED. DROP FEED.

NO.	PLATE	NAME
*16501	——	Arm with 11104
8582	773	" Dowel Pin
12453	773	" Oil Tube, for intermediate bearing
12454	773	" " " with 29599, for oiling 12409
11119	773	" " " " " " " 12408
24131	2014	" " " " " " " 20283
29599	2014	" " " Packing (felt)
748E	782	" Screw (back)
868E	1366	" " (front)
16511	1349	" Shaft
*11104	——	" " Bushing (front)
12357	767	" " Flanged Bushing (back)
448c	783	" " " " " Set Screw

NO.	PLATE	NAME
144D	782	Arm Shaft Screw
12480	767	" Side Cap
219D	774	" " " Screw
12193	2004	" " Cover
286D	783	" " " Thumb Screw
12403	772	" Spool Pin and Thread Eyelet
11241	2003	" " " Washer (cloth)
24296	1348	Balance Wheel (power) light rim, $2\frac{3}{16}$ in. pulley, with two 448C
24297	1340	Balance Wheel Oil Cover
210D	1343	" " " " Screw
448C	783	" " Set Screw
*16503	——	Bed
20197	1350	Crank Connecting Rod with 20198 and two 896E
*20198	——	Crank Connecting Rod Cap
896E	773	" " " " Screw
908C	773	" " " Hinge Screw
1619E	773	" " " " " Nut.
20057	——	Face Plate
20058	1340	Face Plate complete, Nos. 2827, 12150 and 20057
190D	782	Face Plate Screw
44181	——	Face Plate Thread Guard (lower)
12150	773	" " " " " 44181 with 12152
12152	773	Face Plate Thread Guard (lower) Rivet
2827	773	" " " " (upper) with 8505
8505	773	" " " " " Rivet
286D	783	" " Thumb Screw
12368	767	Feed Bar
313C	783	" " Screw Centre
56813	——	" " " " 313C with 1519J
1519J	783	" " " " Nut
3033	770	" Connecting Link
375C	782	" " " Hinge Screw
1518E	783	" " " " " Nut
12460	775	" Dog

NOTE: No. 12460 is sent with this Machine unless another Feed Dog is specified on order.

19488	775	Feed Dog
20041	1266	" "
208E	782	" " Screw
20283	1315	" and Feed Lifting Eccentric with 446C
446C	783	" " " " " Set Screw
24036	1340	" " " " " Sleeve

NO.	PLATE	NAME
20284	1350	Feed Forked Connection
375c	782	" " " Hinge Screw
1518e	783	" " " " " Nut
24969	2551	" Lifting Rock Shaft
24970	——	Feed Lifting Rock Shaft complete, Nos. 12376 and 24969
12376	770	Feed Lifting Rock Shaft Crank with 157j and 1813
157j	782	Feed Lifting Rock Shaft Crank Clamping Screw
1813	783	Feed Lifting Rock Shaft Crank Roller and Stud
43976	2551	Feed Lifting Rock Shaft Crank Connecting Rod with 43977 and two 966e
*43977	——	Feed Lifting Rock Shaft Crank Connecting Rod Cap
966e	5806	Feed Lifting Rock Shaft Crank Connecting Rod Cap Screw
375c	782	Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw
1518e	783	Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw Nut
307c	783	Feed Lifting Rock Shaft Screw Centre
56814	——	" " " " " " 307c with 1513j
1513j	783	Feed Lifting Rock Shaft Screw Centre Nut
3039	768	" Regulator
1128e	2009	" " Hinge Screw
818d	783	" " Thumb Screw
24585	8375	" " " " Stop
16506	766	" Rock Shaft
24376	——	Feed Rock Shaft complete, Nos. 16506 and 29633
29633	1354	Feed Rock Shaft Crank with 157j
157j	782	" " " " Clamping Screw
307c	783	" " " Screw Centre
56814	——	" " " " " 307c with 1513j
1513j	783	Feed Rock Shaft Screw Centre Nut
12381	767	Needle Bar (hollow)
12382	770	" " Connecting Link with 794e
794e	782	" " " " Adjusting Screw
*12383	——	Needle Bar Connecting Stud
1904	770	" " " " Roller (roller only)

NO.	PLATE	NAME
453c	783	Needle Bar Connecting Stud Set Screw..
12384	770	Needle Bar Connecting Stud complete, Nos. 453c, 1904 and 12383.....
20188	767	Needle Bar Crank with 858c and 1065c..
1065c	1366	" " " Position Screw.....
858c	783	" " " Set Screw.....
936e	773	" " Screw Bushing.....
4302	773	" " Thread Guard.....
233d	782	" " " " Screw.....
4303	773	" Clamp with 808f.....
808f	782	" " Screw.....
24104	1350	Oscillating Rock Shaft.....
24105	——	Oscillating Rock Shaft complete, Nos. 4784, 12388 and 24104.....
12388	767	Oscillating Rock Shaft Hinge Pin.....
878j	783	" " " " " Oil Hole Stop Screw.....
12459	773	Oscillating Rock Shaft Hinge Pin Oil Hole Stop Screw Washer (leather).....
448c	783	Oscillating Rock Shaft Hinge Pin Set Screw.....
4784	1353	Oscillating Rock Shaft Oil Pad.....
16509	766	" Shaft.....
19496	——	" " Crank for 19447.....
44134	——	" " " " 44135.....
19447	1353	Oscillating Shaft Crank complete, Nos. 457c, 1518e, 19449 and 19496.....
44135	5806	Oscillating Shaft Crank complete, Nos. 1518e, 19449, 44134 and two 453c.....
2049	773	Oscillating Shaft Crank Pin.....
457c	783	" " " Set Screw for 19447
453c	783	" " " " " " 44135
19448	1353	" " " Slide Block.....
229d	782	" " " " " Cap Screw.....
12424	773	Oscillating Shaft Crank Slide Block Cap Screw Washer.....
988c	1353	Oscillating Shaft Crank Slide Block Screw Stud.....
1518e	783	Oscillating Shaft Crank Slide Block Screw Stud Nut.....
19449	1353	Oscillating Shaft Crank Slide Block complete, Nos. 229d, 988c, 12424 and 19448

NO.	PLATE	NAME
12391	767	Presser Bar (hollow)
20059	1341	" " Guide Bracket with 453c
453c	783	" " " " Set Screw
2062	771	" " Lifter
689c	782	" " " Screw
1520e	783	" " " " Nut
12327	770	" " Lifting and Releasing Lever Bracket
11167	767	Presser Bar Spring (light) .051 wire

NOTE: No. 11167 is sent with this Machine unless another Spring is specified on order.

12139	2004	Presser Bar Spring (medium) .055 wire
20023	2004	" " " (heavy) .063 wire
11170	771	" " " Washer
12435	780	" Foot with 228d, for 12460, 19488, 20041 and 25967

NOTE: No. 12435 is sent with this Machine unless another Presser Foot is specified on order.

12462	781	Presser Foot, $\frac{3}{16}$ in. to $\frac{1}{4}$ in. gauge

NOTE: When ordering No. 12462, give width of turned edge from seam.

12463	781	Presser Foot with Strip Guide
26276	1394	" " Hinge Pin
20133	——	" " Plate
19223	——	" " Shank
20134	1308	Presser Foot (hinged) complete, $\frac{3}{16}$ in. to $\frac{1}{4}$ in. gauge, Nos. 19223, 20133 and 26276

NOTE: When ordering No. 20134, give width of turned edge from seam.

2532	772	Presser Foot Hinge Pin
20155	——	" " Plate
20156	——	" " Shank
20157	1309	Presser Foot (hinged) complete for 12460, 19488, 20041 and 25967, Nos. 228d, 2532, 20155 and 20156
26276	1394	Presser Foot Hinge Pin
20360	——	" " Plate
19335	——	" " Shank
20361	781	Presser Foot (hinged) plain bottom, complete, Nos. 19335, 20360 and 26276
26279	——	Presser Foot Extension, $\frac{1}{16}$ in., for 12435 and 20157

NO.	PLATE	NAME
26280	——	Presser Foot Extension, 1/8 in., for 12435 and 20157
26281	1387	Presser Foot Extension, 1/4 in., for 12435 and 20157
26282	——	Presser Foot Extension, 3/8 in., for 12435 and 20157
26283	——	Presser Foot Extension, 1/2 in., for 12435 and 20157
228D	2038	Presser Foot Extension Screw
190D	782	" " Screw
25967	1387	" " Strip Gauge
228D	2038	" " " " Screw

NOTE: Nos. 25967 and 26279 to 26283 are sent with this Machine unless otherwise specified on order

688J	783	Pressure Regulating Thumb Screw
19131	5737	Shuttle Bobbin
20649	5737	" " Case Latch
2973	5737	" " " " Lever
2974	5737	" " " " " Fulcrum Pin
2975	5737	Shuttle Bobbin Case Latch Spring
592E	5737	" " " " Stop Screw
20650	——	Shuttle Bobbin Case Hinge, Nos. 2973, 2974 and 20649
20755	5737	Shuttle Bobbin Case Position Finger
2523	5737	" " " " " Rivet
24323	2046	" " " " Plate
391D	1366	" " " " " Screw
20756	5737	Shuttle Bobbin Case complete, Nos. 591F, 592E, 2523, 2975, 20650, 20654 and 20755
20757	5737	Shuttle Body
591F	5737	" Tension Regulating Screw
20654	5737	" " Spring
20758	5737	Shuttle, 1 11/16 in. diam., Nos. 19131, 20756 and 20757
19406	2012	Shuttle Driver with two 1266C
2049	773	" " Pin
1266C	5806	" " Set Screw
2419	2006	" Race Back
2532	772	" " " Position Pin
2533	767	" " " Spring
907D	782	" " " " Screw
24326	——	" " Body
62513	——	" " " 24326 with 24009 and two 1053D

NO.	PLATE	NAME
62522	——	Shuttle Race Body 62513 with two 2532
24009	2006	" " Cap
1053D	2006	" " " Screw
24327	1359	Shuttle Race complete, Nos. 907D, 2419, 2533, 24323, 62522 and two 391D
145D	782	Shuttle Race Screw
12431	——	" " Slide
12432	2004	Shuttle Race Slide complete, Nos. 4307, 12431 and two 725E
4307	772	Shuttle Race Slide Spring
725E	1387	" " " " Screw
20060	1311	Slack Thread Regulator
225F	1323	" " " Adjusting Screw
2102	5806	Tension Disc
1560C	783	" Regulating Thumb Nut
32572	5806	" Releasing Disc
43944	5806	" " Lever
12398	773	" " " Hinge Pin
12329	772	" " " Spring
32574	5806	" " Pin
50327C	5806	" Screw Stud
44141	——	" " " 50327C with 1560C
43945	5806	" Spring
44118	——	Tension complete, Nos. 7336, 32572, 32574, 43945, 43946, 44141 and two 2102
52454	5842	Thread Retainer
50429C	——	" " Set Screw
12404	770	" Take-up Crank
3094	773	" " " Wedge
690E	782	" " " " Screw
12408	770	" " Lever
775E	782	" " " Cap Screw
12166	773	" " " Hinge Pin
12409	770	" " " Link
11204	770	" " " " Hinge Pin
435C	5806	" " " " " " Set Screw
12410	——	Thread Take-up Lever complete, Nos. 12166, 12408 and 12409
43946	5806	Thread Take-up Spring
7336	772	" " " Regulator
448C	783	" " " " Set Screw
12434	775	Throat Plate, small needle hole, for 19488

NOTE: Two No. 12434 are sent with this Machine unless other Throat Plates are specified on order.

NO.	PLATE	NAME
20042	1266	Throat Plate, large needle hole, for 20041
20043	——	" " small needle hole, for 20041
12461	775	" " " " " 12460
691F	782	" " Screw.....
24079	2644	Drip Pan with four 1 in. wire nails.....

SPOOL HOLDER (Disc)

26763	1352	Bracket with 219F and 287D.....
219F	774	" Screw.....
287D	2636	" Thumb Screw.....
19066	1352	Spindle.....
19067	1352	" Thread Guiding Disc.....
691F	782	" " " " Screw.....
26764	1352	Spool Holder (disc) complete, Nos. 691F, 19066, 19067 and 26763.....

LIST OF PARTS COMPLETE

FOR

MACHINE No. 44-20

FOR LIGHT WORK ONLY, WITH SHORT STITCH, IN CLOTH. DROP FEED.

NO.	PLATE	NAME
*24025	——	Arm with 11104
8582	773	" Dowel Pin
12453	773	" Oil Tube, for intermediate bearing
12454	773	" " " with 29599, for oiling 24099
11119	773	" " " " " " " 24068
24131	2014	" " " " " " " 24035
29599	2014	" " " Packing (felt)
748E	782	" Screw (back)
868E	1366	" " (front)
24026	1339	" Shaft
*11104	——	" " Bushing (front)
12357	767	" " Flanged Bushing (back)
448C	783	" " " " " Set Screw
144D	782	Arm Shaft Screw
12480	767	" Side Cap
219D	774	" " " Screw
12193	2004	" " Cover
286D	783	" " " Thumb Screw
12403	772	" Spool Pin and Thread Eyelet
11241	2003	" " " Washer (cloth)
24328	1339	Balance Wheel, light rim, 2¼ in. pulley, with two 448C
24297	1340	Balance Wheel Oil Cover
210D	1343	" " " " Screw
448C	783	" " Set Screw
*24027	——	Bed
24028	1339	Crank Connecting Rod with 24085 and two 896E
*24085	——	Crank Connecting Rod Cap
896E	773	" " " " Screw
908C	773	" " " Hinge Screw
1619E	773	" " " " " Nut
20057	——	Face Plate

NO.	PLATE	NAME
20058	1340	Face Plate complete, Nos. 2827, 12150 and 20057
190D	782	Face Plate Screw
44181	——	" " Thread Guard (lower)
12150	773	" " " " " 44181 with 12152
12152	773	Face Plate Thread Guard (lower) Rivet
2827	773	" " " " (upper) with 8505
8505	773	" " " " " Rivet
286D	783	" " Thumb Screw
24034	1340	Feed Bar
313C	783	" " Screw Centre
56813	——	" " " " 313C with 1519J
1519J	783	" " " " Nut
3033	770	" Connecting Link
375C	782	" " " Hinge Screw
1518E	783	" " " " " Nut
12450	777	" Dog, for cloth, 11 teeth (18 teeth to the inch)

NOTE: No. 12450 is sent with this Machine unless another Feed Dog is specified on order.

20348	777	Feed Dog, 22 teeth (36 teeth to the inch) for chiffon
20142	1260	Feed Dog, 13 teeth (16 teeth to the inch) for general work
20147	1260	Feed Dog, 12 teeth (14 teeth to the inch)
62529	1260	" " 18 teeth (22 teeth to the inch) for general work
20151	1262	Feed Dog, 13 teeth (14 teeth to the inch) for shirt work, beveled for hemmer
44144	1262	Feed Dog, 22 teeth (24 teeth to the inch) beveled for hemmer
20159	1261	Feed Dog, for shirt work
20117	1261	" " 16 teeth (16 teeth to the inch) for shirt work, beveled for hemmer
20132	1261	Feed Dog, 22 teeth (22 teeth to the inch) for shirt work, beleved for hemmer
20138	1263	Feed Dog, 13 teeth (12 teeth to the inch) for shirt work, beveled for hemmer
20162	1263	Feed Dog, 17 teeth (16 teeth to the inch) for shirt work, beveled for hemmer
12369	776	Feed Dog, 12 teeth (12 teeth to the inch)
12457	776	" " 16 teeth (16 teeth to the inch)
20325	1264	" " 18 teeth (16 teeth to the inch) for shirt work

NO.	PLATE	NAME
20468	8375	Feed Dog, for tucking
44177	1260	" " 19 teeth (22 teeth to the inch)
208E	782	" " Screw
24035	1340	" and Feed Lifting Eccentric with 448c
448c	783	" " " " " Set Screw
24036	1340	" " " " " Sleeve
24037	1339	" Forked Connection
375c	782	" " " Hinge Screw
1518E	783	" " " " " Nut
16504	766	" Lifting Rock Shaft
16588	——	Feed Lifting Rock Shaft complete, Nos. 2049, 12376, 16504 and 16556
16556	2009	Feed Lifting Rock Shaft Crank (back) with 462c
2049	773	Feed Lifting Rock Shaft Crank (back) Pin
462c	773	Feed Lifting Rock Shaft Crank (back) Set Screw
12376	770	Feed Lifting Rock Shaft Crank (front) with 157J and 1813
157J	782	Feed Lifting Rock Shaft Crank (front) Clamping Screw
1813	783	Feed Lifting Rock Shaft Crank (front) Roller and Stud
12430	5764	Feed Lifting Rock Shaft Crank Connecting Rod with 12204 and two 966E
*12204	——	Feed Lifting Rock Shaft Crank Connecting Rod Cap
966E	5806	Feed Lifting Rock Shaft Crank Connecting Rod Cap Screw
375c	782	Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw
1518E	783	Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw Nut
307c	783	Feed Lifting Rock Shaft Screw Centre
56814	——	" " " " " " 307c with 1513J
1513J	783	Feed Lifting Rock Shaft Screw Centre Nut
3039	768	" Regulator
1128E	2009	" " Hinge Screw
818D	783	" " Thumb Screw
16506	766	" Rock Shaft
24376	——	Feed Rock Shaft complete, Nos. 16506 and 29633

NO.	PLATE	NAME
29633	1354	Feed Rock Shaft Crank with 157J.....
157J	782	" " " " Clamping Screw
307C	783	" " " Screw Centre.....
56814	——	" " " " " 307C with 1513J.....
1513J	783	Feed Rock Shaft Screw Centre Nut.....
24451	2647	Needle Bar.....
24442	2647	" " Bushing with 29532.....
1133E	8376	" " " Set Screw.....
24040	1341	" " Connecting Link with 794E..
794E	782	" " " " Adjusting Screw.....
775E	782	Needle Bar Connecting Link Cap Screw...
24041	1341	" " " Stud with 207E...
207E	1341	" " " " Clamping Screw.....
24052	1340	Needle Bar Crank with 858C, 1036C, 1037C and 1065C.....
1065C	1366	Needle Bar Crank Position Screw.....
858C	783	" " " Set Screw.....
862D	1341	" " Hole Plug Screw.....
29532	1341	" " Oil Cup.....
24452	2647	" " Gib.....
24453	2647	" Clamp with 196F and 24452.....
196F	772	" " Screw.....
24043	1340	Oscillating Rock Shaft.....
24044	——	Oscillating Rock Shaft complete, Nos. 4784, 12388 and 24043.....
12388	767	Oscillating Rock Shaft Hinge Pin.....
878J	783	" " " " " Oil Hole Stop Screw.....
12459	773	Oscillating Rock Shaft Hinge Pin Oil Hole Stop Screw Washer (leather).....
448C	783	Oscillating Rock Shaft Hinge Pin Set Screw.....
4784	1353	Oscillating Rock Shaft Oil Pad.....
24045	1339	" Shaft.....
24046	1341	" " Bushing (back).....
24047	1341	" " " (front).....
24048	——	" " Crank.....
24049	1343	Oscillating Shaft Crank complete, Nos. 462C, 1636E, 24048 and 24050.....
2269	773	Oscillating Shaft Crank Pin.....
462C	773	" " " Set Screw.....
19448	1353	" " " Slide Block.....
229D	782	" " " " " Cap Screw.....

NO.	PLATE	NAME
12424	773	Oscillating Shaft Crank Slide Block Cap Screw Washer
1035c	1343	Oscillating Shaft Crank Slide Block Screw Stud
1636E	1343	Oscillating Shaft Crank Slide Block Screw Stud Nut
24050	1343	Oscillating Shaft Crank Slide Block complete, Nos. 229D, 1035c, 12424 and 1944S
12391	767	Presser Bar (hollow)
20059	1341	" " Guide Bracket with 453c
453c	783	" " " " Set Screw
2062	771	" " Lifter
689c	782	" " " Screw
1520E	783	" " " " Nut
12327	770	" " Lifting and Releasing Lever Bracket
11167	767	Presser Bar Spring (light) .051 wire

NOTE: No. 11167 is sent with this Machine unless another Spring is specified on order.

12139	2004	Presser Bar Spring (medium) .055 wire
20023	2004	" " " (heavy) .063 wire
11170	771	" " " Washer
12143	780	" Foot for 12369 and 12457
12144	780	" " " 20117, 20132, 20138, 20151, 20159, 20162 and 44144
12260	780	Presser Foot for 12450, 20147, 20348 and 44177
2532	772	Presser Foot Hinge Pin
20344	——	" " Plate
20345	——	" " Shank
26231	1353	" " Spring
20346	781	Presser Foot (spring hinged) complete, Nos. 2532, 20344, 20345 and 26231
7298	2014	Presser Foot Hinge Pin
20268	——	" " Plate
20269	——	" " Shank
20270	1308	Presser Foot (hinged) complete for 12369 and 12457, Nos. 7298, 20268 and 20269
20118	1308	Presser Foot, for general work, for 12450

NOTE: No. 20118 is sent with this Machine unless another Presser Foot is specified on order.

2532	772	Presser Foot Hinge Pin
20472	——	" " Plate
20473	——	" " Shank
26231	1353	" " Spring

NO.	PLATE	NAME
20474	8375	Presser Foot (spring hinged) complete, for fine silk, etc., Nos. 2532, 20472, 20473 and 26231
20150	1308	Presser Foot for 20142 and 62529
20342	781	" " " 12450 and 20348
190D	782	" " Screw
688J	783	Pressure Regulating Thumb Screw
24051	1343	Shuttle Bobbin
15140	1353	" " Case Latch
2973	771	" " " " Lever
2974	771	" " " " " Fulcrum Pin
2975	771	Shuttle Bobbin Case Latch Spring
592E	782	" " " " Stop Screw
15141	——	Shuttle Bobbin Case Hinge, Nos. 2973, 2974 and 15140
24055	1343	Shuttle Bobbin Case Position Finger
2523	771	" " " " " Rivet
24412	1391	" " " " Plate
391D	1366	" " " " " Screw
24056	1343	Shuttle Bobbin Case complete, Nos. 591F, 592E, 2523, 2975, 15141, 24055 and 24058
24057	1343	Shuttle Body
591F	782	" Tension Regulating Screw
24058	1343	" " Spring
24059	1343	Shuttle, 1 $\frac{11}{16}$ in. diam., Nos. 24051, 24056 and 24057
*24060	——	Shuttle Driver
24061	1343	" " 24060 with two 462c
2269	773	" " Pin
462c	773	" " Set Screw
24062	1342	" Race Back
2532	772	" " " Position Pin
2533	767	" " " Spring
907D	782	" " " " Screw
24437	——	" " Body
62510	——	" " " 24437 with 24064 and two 1053D
62519	——	Shuttle Race Body 62510 with two 2532
24064	1342	" " Cap
1053D	2006	" " " Screw
24438	1364	Shuttle Race complete, Nos. 907D, 2533, 24062, 24412, 62519 and two 391D
145D	782	Shuttle Race Screw
12431	——	" " Slide

NO.	PLATE	NAME
12432	2004	Shuttle Race Slide complete, Nos. 4307, 12431 and two 725E
4307	772	Shuttle Race Slide Spring
725E	1387	" " " " Screw
20060	1311	Slack Thread Regulator
225F	1323	" " " Adjusting Screw
2102	5806	Tension Disc
1560c	783	" Regulating Thumb Nut
32572	5806	" Releasing Disc
43944	5806	" " Lever
12398	773	" " " Hinge Pin
12329	772	" " " Spring
32574	5806	" " Pin
50327c	5806	" Screw Stud
44141	——	" " " 50327c with 1560c
8238	1353	" Spring
24984	——	Tension complete, Nos. 7336, 8238, 24071, 32572, 32574, 44141 and two 2102
24078	1343	Thread Guard (side of arm)
52454	5842	" Retainer
50429c	——	" " Set Screw
24097	1341	" Take-up Crank
1037c	1341	" " " Position Screw
1036c	1341	" " " Set Screw
24068	1341	" " Lever
12166	773	" " " Hinge Pin
24099	1341	" " " Link
11204	770	" " " " Hinge Pin
435c	5806	" " " " " " Set Screw
24070	——	Thread Take-up Lever complete, Nos. 12166, 24068 and 24099
24071	1343	Thread Take-up Spring
7336	772	" " " Regulator
448c	783	" " " " Set Screw
20135	1264	Throat Plate, large needle hole, for 12450 and 20348
20136	——	Throat Plate, small needle hole, for 12450 and 20348

NOTE: No. 20136 is sent with this Machine unless another Throat Plate is specified on order.

20124	1261	Throat Plate, large needle hole, for 20117 and 20132
20125	——	Throat Plate, small needle hole, for 20117 and 20132

NO.	PLATE	NAME
20139	1263	Throat Plate, large needle hole, for 20138 and 20162.....
20140	——	Throat Plate, small needle hole, for 20138 and 20162.....
20143	1260	Throat Plate, large needle hole, for 20142 and 62529.....
20144	——	Throat Plate, small needle hole, for 20142 and 62529.....
20148	1260	Throat Plate, large needle hole, for 20147 and 44177.....
20149	——	Throat Plate, small needle hole, for 20147 and 44177.....
20152	1262	Throat Plate, large needle hole, for 20151 and 44144.....
20153	——	Throat Plate, small needle hole, for 20151 and 44144.....
20160	1261	Throat Plate, large needle hole, for 20159
20161	——	" " small needle hole, for 20159
20190	1263	" " large needle hole, for 12369 and 12457.....
20191	——	Throat Plate, small needle hole, for 12369 and 12457.....
20326	1264	Throat Plate, large needle hole, for 20325
20327	——	" " small needle hole, for 20325
20469	8375	" " large needle hole, for 20468
20470	——	" " small needle hole, for 20468
691F	782	" " Screw..... .....
24079	2644	Drip Pan with four 1 in. wire nails.....

LIST OF PARTS COMPLETE

FOR

MACHINE No. 44-22

FOR RUFFLING AND STITCHING THICK OR THIN FABRICS, APRONS, DRESSES, INFANTS' GARMENTS, SKIRTS, ETC. ONE NEEDLE, POSITIVE RUFFLING MECHANISM, DROP FEED.

NO.	PLATE	NAME
*24302	——	Arm with 11104
8582	773	" Dowel Pin
12453	773	" Oil Tube, for intermediate bearing
12454	773	" " " with 29599, for oiling 12409
11119	773	" " " " " " " 12408 and 24207
24131	2014	Arm Oil Tube with 29599, for oiling 20283
29599	2014	" " " Packing (felt)
748E	782	" Screw (back)
868E	1366	" " (front)
24195	1349	" Shaft
*11104	——	" " Bushing (front)
12357	767	" " Flanged Bushing (back)
448C	783	" " " " " Set Screw
144D	782	Arm Shaft Screw
12480	767	" Side Cap
219D	774	" " " Screw
12193	2004	" " Cover
286D	783	" " " Thumb Screw
12403	772	" Spool Pin and Thread Eyelet
11241	2003	" " " Washer (cloth)
24296	1348	Balance Wheel (power) light rim, $2\frac{3}{16}$ in. pulley, with two 448C
24297	1340	Balance Wheel Oil Cover
210D	1343	" " " " Screw
448C	783	" " Set Screw
*16503	——	Bed
20197	1350	Crank Connecting Rod with 20198 and two 896E
*20198	——	Crank Connecting Rod Cap
896E	773	" " " " Screw
908C	773	" " " Hinge Screw
1619E	773	" " " " " Nut

NO.	PLATE	NAME
20057	——	Face Plate
20058	1340	Face Plate complete, Nos. 2827, 12150 and 20057
190D	782	Face Plate Screw
44181	——	" " Thread Guard (lower)
12150	773	" " " " " 44181 with 12152
12152	773	Face Plate Thread Guard (lower) Rivet
2827	773	" " " " (upper) with 8505
8505	773	" " " " " Rivet
286D	783	" " Thumb Screw
12368	767	Feed Bar
313C	783	" " Screw Centre
56813	——	" " " " 313C with 1519J
1519J	783	" " " " Nut
3033	770	" Connecting Link
375C	782	" " " Hinge Screw
1518E	783	" " " " " Nut
24303	1344	" Dog
208E	782	" " Screw
20283	1315	" and Feed Lifting Eccentric with 446C
446C	783	" " " " " Set Screw
24036	1340	" " " " " Sleeve
20284	1350	" Forked Connection
375C	782	" " " Hinge Screw
1518E	783	" " " " " Nut
24969	2551	" Lifting Rock Shaft
24970	——	Feed Lifting Rock Shaft complete, Nos. 12376 and 24969
12376	770	Feed Lifting Rock Shaft Crank with 157J and 1813
157J	782	Feed Lifting Rock Shaft Crank Clamping Screw
1813	783	Feed Lifting Rock Shaft Crank Roller and Stud
43976	2551	Feed Lifting Rock Shaft Crank Connecting Rod with 43977 and two 966E
*43977	——	Feed Lifting Rock Shaft Crank Connecting Rod Cap
966E	5806	Feed Lifting Rock Shaft Crank Connecting Rod Cap Screw
375C	782	Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw
1518E	783	Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw Nut

NO.	PLATE	NAME
307c	783	Feed Lifting Rock Shaft Screw Centre...
56814	——	" " " " " " 307c with 1513J.....
1513J	783	Feed Lifting Rock Shaft Screw Centre Nut
3039	768	" Regulator.....
1128E	2009	" " Hinge Screw.....
818D	783	" " Thumb Screw.....
16506	766	" Rock Shaft.....
24376	——	Feed Rock Shaft complete, Nos. 16506 and 29633.....
29633	1354	Feed Rock Shaft Crank with 157J.....
157J	782	" " " " Clamping Screw.
307c	783	" " " Screw Centre.....
56814	——	" " " " " 307c with 1513J.....
1513J	783	Feed Rock Shaft Screw Centre Nut.....
12381	767	Needle Bar (hollow).....
12382	770	" " Connecting Link with 794E..
794E	782	" " " " Adjusting Screw.....
*12383	——	Needle Bar Connecting Stud.....
1904	770	" " " " Roller (roller only).....
453c	783	Needle Bar Connecting Stud Set Screw...
12384	770	Needle Bar Connecting Stud complete, Nos. 453c, 1904 and 12383.....
20188	767	Needle Bar Crank with 858c and 1065c..
1065c	1366	" " " Position Screw.....
858c	783	" " " Set Screw.....
936E	773	" " Screw Bushing... .....
4302	773	" " Thread Guard.....
233D	782	" " " " Screw.....
4303	773	" Clamp with 808F.....
808F	782	" " Screw.....
24104	1350	Oscillating Rock Shaft.....
24105	——	Oscillating Rock Shaft complete, Nos. 4784, 12388 and 24104.....
12388	767	Oscillating Rock Shaft Hinge Pin.....
878J	783	" " " " " Oil Hole Stop Screw.....
12459	773	Oscillating Rock Shaft Hinge Pin Oil Hole Stop Screw Washer (leather).....
448c	783	Oscillating Rock Shaft Hinge Pin Set Screw.....

NO.	PLATE	NAME
4784	1353	Oscillating Rock Shaft Oil Pad.....
16509	766	" Shaft.....
19496	——	" " Crank for 19447.....
44134	——	" " " " 44135.....
19447	1353	Oscillating Shaft Crank complete, Nos. 457c, 1518e, 19449 and 19496.....
44135	5806	Oscillating Shaft Crank complete, Nos. 1518e, 19449, 44134 and two 453c.....
2049	773	Oscillating Shaft Crank Pin.....
457c	783	" " " Set Screw for 19447
453c	783	" " " " " " 44135
19448	1253	" " " Slide Block.....
229d	782	" " " " " Cap Screw.....
12424	773	Oscillating Shaft Crank Slide Block Cap Screw Washer.....
988c	1353	Oscillating Shaft Crank Slide Block Screw Stud.....
1518e	783	Oscillating Shaft Crank Slide Block Screw Stud Nut.....
19449	1353	Oscillating Shaft Crank Slide Block complete, Nos. 229d, 988c, 12424 and 19448
12391	767	Presser Bar (hollow).....
20059	1341	" " Guide Bracket with 453c....
453c	783	" " " " Set Screw....
2062	771	" " Lifter.....
689c	782	" " " Screw.....
1520e	783	" " " " Nut.....
12327	770	" " Lifting and Releasing Lever Bracket.....
11167	767	Presser Bar Spring (light) .051 wire.....

NOTE: No. 11167 is sent with this Machine unless another Spring is specified on order.

12139	2004	Presser Bar Spring (medium) .055 wire...
20023	2004	" " " (heavy) .063 wire....
11170	771	" " " Washer.....
24304	1344	" Foot.....
190d	782	" " Screw.....
688j	783	Pressure Regulating Thumb Screw.....
26888	1344	Ruffling Arm (lower).....
26889	1344	" " (upper) with 190d and 219f
207f	1344	" " Adjusting Screw.....
2291	1344	" " " " Washer...
190d	782	" " Clamping Screw.....
26890	1344	Ruffling Arm (adjustable) Nos. 2291, 26888, 26889 and two 207f.....

NO.	PLATE	NAME
28845	——	Ruffling Arm (adjustable) complete, Nos. 226D, 1550J, 24203 to 24206, 26890 and two 665D
24199	1323	Ruffling Arm Shaft
24200	1324	" " " Bracket (right)
145D	1324	" " " " " Screw
24201	1324	" " " " (left)
159D	1324	" " " " " Screw
6533	1323	" " " Collar with 460C
460C	1323	" " " " Set Screw
219F	774	" " Set Screw
24305	1344	" Blade
24203	1344	" " Holder
226D	1344	" " " Cap Screw
24204	1344	" " " Spring
24205	1344	" " " " Stop
24206	1344	" " " Stud
1550J	1344	" " " " Nut
665D	1344	" " Screw
24207	1323	" Eccentric with two 453C
24208	1323	" " Collar with 453C
453C	1323	" " " Set Screw
24219	1323	" " Connection with 24220 and two 742E
24220	——	Ruffling Eccentric Connection Cap
742E	1323	" " " " Screw
24210	1324	" " " Washer
453C	1323	" " Set Screw
24211	1323	" Regulator with 225F
225F	1323	" " Set Screw
181D	1323	" " Stop Screw
1641E	1323	" " " " Nut
1108F	1323	" " Thumb Screw
1641E	1323	" " " " Nut
24718	1352	" Separating Blade
4604	1385	" " " Rivet
43919	1352	" " " Shank
24410	1352	Ruffling Separating Blade on Shank complete, Nos. 24718, 43919 and two 4604
1423D	5742	Ruffling Separating Blade Screw
19131	5737	Shuttle Bobbin
20649	5737	" " Case Latch
2973	5737	" " " " Lever
2974	5737	" " " " " Fulcrum Pin
2975	5737	Shuttle Bobbin Case Latch Spring
592E	5737	" " " " Stop Screw

NO.	PLATE	NAME
20650	——	Shuttle Bobbin Case Hinge, Nos. 2973, 2974 and 20649
20755	5737	Shuttle Bobbin Case Position Finger
2523	5737	" " " " " Rivet
24323	2046	" " " " Plate
391D	1366	" " " " " Screw
20756	5737	Shuttle Bobbin Case complete, Nos. 591F, 592E, 2523, 2975, 20650, 20654 and 20755
20757	5737	Shuttle Body
591F	5737	" Tension Regulating Screw
20654	5737	" " Spring
20758	5737	Shuttle, $1\frac{11}{16}$ in. diam., Nos. 19131, 20756 and 20757
19406	2012	Shuttle Driver with two 1266C
2049	773	" " Pin
1266C	5806	" " Set Screw
2419	2006	" Race Back
2532	772	" " " Position Pin
2533	767	" " " Spring
907D	782	" " " " Screw
24324	——	" " Body
24998	——	" " " 24324 with 24009 and two 1053D
24009	2006	Shuttle Race Cap
1053D	2006	" " " Screw
24325	2046	Shuttle Race complete, Nos. 907D, 2419, 2533, 24323, 24998 and two each 391D and 2532
145D	782	Shuttle Race Screw
12431	——	" " Slide
12432	2004	Shuttle Race Slide complete, Nos. 4307, 12431 and two 725E
4307	772	Shuttle Race Slide Spring
725E	1387	" " " " Screw
44009	8375	Slack Thread Regulator
225F	1323	" " " Adjusting Screw
2102	5806	Tension Disc
1560C	783	" Regulating Thumb Nut
32572	5806	" Releasing Disc
43944	5806	" " Lever
12398	773	" " " Hinge Pin
12329	772	" " " Spring
32574	5806	" " Pin
50327C	5806	" Screw Stud
44141	——	" " " 50327C with 1560C
43945	5806	" Spring

NO.	PLATE	NAME
44118	——	Tension complete, Nos. 7336, 32572, 32574, 43945, 43946, 44141 and two 2102
52454	5842	Thread Retainer.....
50429c	——	" " Set Screw.....
12404	770	" Take-up Crank.....
3094	773	" " " Wedge.....
690E	782	" " " " Screw....
12408	770	" " Lever.....
775E	782	" " " Cap Screw.....
12166	773	" " " Hinge Pin.....
12409	770	" " " Link.....
11204	770	" " " " Hinge Pin....
435c	5806	" " " " " " Set Screw.....
12410	——	Thread Take-up Lever complete, Nos. 12166, 12408 and 12409.....
43946	5806	Thread Take-up Spring.....
7336	772	" " " Regulator.....
448c	783	" " " " Set Screw
24306	1344	Throat Plate for 24303.....
691F	782	" " Screw.....
24079	2644	Drip Pan with four 1 in. wire nails.....

LIST OF PARTS COMPLETE

FOR

MACHINE No. 44-23

UPPER AND LOWER POSITIVE FEEDING MECHANISM, ALTERNATING PRESSERS. FOR GENERAL WORK.

NO.	PLATE	NAME
*24340	——	Arm with 11104
8582	773	" Dowel Pin
12453	773	" Oil Tube for intermediate bearing
11119	773	" " " with 29599, for oiling 12408 and 19365
12454	773	Arm Oil Tube with 29599, for oiling 12409
24131	2014	" " " " " " " 20283
29599	2014	" " " Packing (felt)
748E	782	" Screw (back)
868E	1366	" " (front)
16511	1349	" Shaft
*11104	——	" " Bushing (front)
12357	767	" " Flanged Bushing (back)
448C	783	" " " " " Set Screw
144D	782	Arm Shaft Screw
12193	2004	" Side Cover
286D	783	" " " Thumb Screw
12403	772	" Spool Pin and Thread Eyelet
11241	2003	" " " Washer (cloth)
24296	1348	Balance Wheel (power) light rim, $2\frac{3}{16}$ in. pulley, with two 448C
24297	1340	Balance Wheel Oil Cover
210D	1343	" " " " Screw
448C	783	" " Set Screw
*24341	——	Bed
20197	1350	Crank Connecting Rod with 20198 and two 896E
*20198	——	Crank Connecting Rod Cap
896E	773	" " " " Screw
908C	773	" " " Hinge Screw
1619E	773	" " " " " Nut
19354	——	Face Plate
19355	1311	Face Plate complete, Nos. 2827, 12150 and 19354

NO.	PLATE	NAME
219D	774	Face Plate Screw
44181	——	" " Thread Guard (lower)
12150	773	" " " " " 44181 with 12152
12152	773	Face Plate Thread Guard (lower) Rivet
2827	773	" " " " (upper) with 8505
8505	773	" " " " " Rivet
24342	1311	Feed Bar (lower)
4653	1354	" " " Hinge Pin
1517E	1366	" " " " " Nut
711C	1366	" " " " " Screw Bearing
1517E	1366	Feed Bar (lower) Hinge Pin Screw Bearing Nut
24343	1354	Feed Bar (upper) with 620C
3033	770	" Connecting Link
375C	782	" " " Hinge Screw
1518E	783	" " " " " Nut
24344	1267	Feed Dog (lower)
208E	782	" " " Screw
24345	1354	" " (upper)
330D	1366	" " " Screw
20283	1315	" and Feed Lifting Eccentric with 446C
446C	783	" " " " " Set Screw
24036	1340	" " " " " Sleeve
20284	1350	" Forked Connection
375C	782	" " " Hinge Screw
1518E	783	" " " " " Nut
24349	1354	" (upper) Lifting Bar
24350	1354	" " " " Hinge Pin
620C	782	" " " " " " Set Screw
24969	2551	Feed Lifting Rock Shaft
24970	——	Feed Lifting Rock Shaft complete, Nos. 12376 and 24969
12376	770	Feed Lifting Rock Shaft Crank with 157J and 1813
157J	782	Feed Lifting Rock Shaft Crank Clamping Screw
1813	783	Feed Lifting Rock Shaft Crank Roller and Stud
43976	2551	Feed Lifting Rock Shaft Crank Connecting Rod with 43977 and two 966E
*43977	——	Feed Lifting Rock Shaft Crank Connecting Rod Cap
966E	5806	Feed Lifting Rock Shaft Crank Connecting Rod Cap Screw

NO.	PLATE	NAME
375c	782	Feed Lifting Rock Shaft Crank Connect-Rod Hinge Screw
1518e	783	Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw Nut
307c	783	Feed Lifting Rock Shaft Screw Centre
56814	——	" " " " " " 307c with 1513j
1513j	783	Feed Lifting Rock Shaft Screw Centre Nut
24348	1354	" Pressure Spring
207f	1341	" " " Screw
3039	768	" Regulator
1128e	2009	" " Hinge Screw
818d	783	" " Thumb Screw
24346	1349	" Rock Shaft
24377	——	Feed Rock Shaft complete, Nos. 24346 and 29633
29633	1354	Feed Rock Shaft Crank with 157j
157j	782	" " " " Clamping Screw
307c	783	" " " Screw Centre
56814	——	" " " " " 307c with 1513j
1513j	783	Feed Rock Shaft Screw Centre Nut
12391	767	Lifting Presser Bar (hollow)
19356	1312	" " " Bell Crank
199d	1312	" " " " " Cap Screw
19357	1312	" " " " " Connecting Link
199d	1312	Lifting Presser Bar Bell Crank Connecting Link Cap Screw
24351	1354	Lifting Presser Bar Bell Crank Driving Arm
2049	773	Lifting Presser Bar Bell Crank Driving Arm Pin
19359	1312	Lifting Presser Bar Bell Crank Driving Arm Shaft
19360	1311	Lifting Presser Bar Bell Crank Driving Arm Shaft Bracket
24352	——	Lifting Presser Bar Bell Crank Driving Arm Shaft Bracket complete, Nos. 2049, 19359, 19360 and 24351
965d	1312	Lifting Presser Bar Bell Crank Driving Arm Shaft Bracket Screw
19362	1313	Lifting Presser Bar Bell Crank Driving Arm Eccentric Connection
375c	782	Lifting Presser Bar Bell Crank Driving Arm Eccentric Connection Hinge Screw

NO.	PLATE	NAME
1518E	783	Lifting Presser Bar Bell Crank Driving Arm Eccentric Connection Hinge Screw Nut
19363	1312	Lifting Presser Bar Guide Bracket with 453C
453C	783	Lifting Presser Bar Guide Bracket Set Screw
4855	1312	Lifting Presser Bar Lifter
689C	782	" " " " Screw
1520E	783	" " " " " Nut
12327	770	" " " Lifting and Releasing Lever Bracket
11167	767	Lifting Presser Bar Spring (light) .051 wire

NOTE: No. 11167 is sent with this Machine unless another Spring is specified on order.

12139	2004	Lifting Presser Bar Spring (medium) .055 wire
20023	2004	Lifting Presser Bar Spring (heavy) .063 wire
11170	771	Lifting Presser Bar Spring Washer
19364	1312	" " Foot
193D	1312	" " " Screw
19229	2004	Needle Bar (hollow) for high lift
12382	770	" " Connecting Link with 794E
794E	782	" " " " Adjusting Screw
12383	——	Needle Bar Connecting Stud
1904	770	" " " " Roller (roller only)
453C	783	Needle Bar Connecting Stud Set Screw
12384	770	Needle Bar Connecting Stud complete, Nos. 453C, 1904 and 12383
19365	1311	Needle Bar Crank and Lifting Eccentric with 448C and 743C
448C	783	Needle Bar Crank and Lifting Eccentric Set Screw
743C	1313	Needle Bar Crank and Lifting Eccentric Position Screw
936E	773	Needle Bar Screw Bushing
24101	——	" Clamp Body
808F	782	" " Screw
24102	1353	" " Thread Guide
651D	1353	" " " " Screw
24103	1353	Needle Clamp (high lift) complete, Nos. 651D, 808F, 24101 and 24102
24104	1350	Oscillating Rock Shaft

NO.	PLATE	NAME
24105	——	Oscillating Rock Shaft complete, Nos. 4784, 12388 and 24104
12388	767	Oscillating Rock Shaft Hinge Pin
878J	783	" " " " " Oil Hole Stop Screw
12459	773	Oscillating Rock Shaft Hinge Pin Oil Hole Stop Screw Washer (leather)
448C	783	Oscillating Rock Shaft Hinge Pin Set Screw
4784	1353	Oscillating Rock Shaft Oil Pad
16509	766	" Shaft
19496	——	" " Crank for 19447
44134	——	" " " " 44135
19447	1353	Oscillating Shaft Crank complete, Nos. 457C, 1518E, 19449 and 19496
44135	5806	Oscillating Shaft Crank complete, Nos. 1518E, 19449, 44134 and two 453C
2049	773	Oscillating Shaft Crank Pin
457C	783	" " " Set Screw for 19447
453C	783	" " " " " " 44135
19448	1353	" " " Slide Block
229D	782	" " " " " Cap Screw
12424	773	Oscillating Shaft Crank Slide Block Cap Screw Washer
988C	1353	Oscillating Shaft Crank Slide Block Screw Stud
1518E	783	Oscillating Shaft Crank Slide Block Screw Stud Nut
19449	1353	Oscillating Shaft Crank Slide Block complete, Nos. 229D, 988C, 12424 and 19448
688J	783	Pressure Regulating Thumb Screw
2996	771	Shuttle Bobbin
15140	1353	" " Case Latch
2973	771	" " " " Lever
2974	771	" " " " " Fulcrum Pin
2975	771	Shuttle Bobbin Case Latch Spring
592E	782	" " " " Stop Screw
15141	——	Shuttle Bobbin Case Hinge, Nos. 2973, 2974 and 15140
7553	771	Shuttle Bobbin Case Position Finger
2523	771	" " " " " Rivet
24412	1361	" " " " Plate
391D	1366	" " " " " Screw
24074	771	Shuttle Bobbin Case complete, Nos. 591F, 592E, 2523, 2975, 7553, 15098 and 15141

NO.	PLATE	NAME
12393	771	Shuttle Body
591F	782	" Tension Regulating Screw
15098	771	" " Spring
19292	771	Shuttle, $1\frac{11}{16}$ in. diam., Nos. 2996, 12393 and 24074
*12394	——	Shuttle Driver
12444	771	" " 12394 with two 1266C
2049	773	" " Pin
1266C	5806	" " Set Screw
2531	767	" Race Back
2532	772	" " " Position Pin
2533	767	" " " Spring
907D	782	" " " " Screw
24413	——	" " Body
25000	——	" " " 24413 with 24414 and two 1053D
24414	1362	Shuttle Race Cap
1053D	2006	" " " Screw
24415	1361	Shuttle Race complete, Nos. 907D, 2531, 2533, 24412, 25000 and two each 391D and 2532
145D	782	Shuttle Race Screw
12431	——	" " Slide
12432	2004	Shuttle Race Slide complete, Nos. 4307, 12431 and two 725E
4307	772	Shuttle Race Slide Spring
725E	1387	" " " " Screw
2921	771	Tension Disc
1560C	783	" Regulating Thumb Nut
20037	2009	" Releaser
12397	772	" Releasing Lever
12398	773	" " " Hinge Pin
12329	772	" " " Spring
413C	783	" Screw Stud
33892	——	" " " 413C with 1560C
2923	771	" Spring
12149	2014	" Thread Guard
44147	——	Tension complete, Nos. 2923, 7336, 8511, 20037, 33892 and two 2921
52454	5842	Thread Retainer
50429C	——	" " Set Screw
12404	770	" Take-up Crank
3094	773	" " " Wedge
690E	782	" " " " Screw
12408	770	" " Lever
775E	782	" " " Cap Screw
12166	773	" " " Hinge Pin

NO.	PLATE	NAME
12409	770	Thread Take-up Lever Link.....
11204	770	" " " " Hinge Pin...
435c	5S06	" " " " " " Set Screw.....
12410	——	Thread Take-up Lever comlpete, Nos. 12166, 12408 and 12409.....
8511	773	Thread Take-up Spring.....
7336	772	" " " Regulator.....
448c	7S3	" " " " Set Screw
24353	1267	Throat Plate, large needle hole, for 24344

NOTE: No. 24353 is sent with this Machine unless another Throat Plate is specified on order.

24354	——	Throat Plate, small needle hole, for 24344
691F	7S2	" " Screw.....
24079	2644	Drip Pan with four 1 in. wire nails.....

LIST OF PARTS COMPLETE

FOR

MACHINE No. 44-24

DROP FEED, FOR TUCKING, WITH TUCK FOLDING ATTACHMENT, WHICH CAN BE READILY ADJUSTED TO MAKE TUCKS OF ANY WIDTH FROM ¼ INCH TO 1¼ INCHES FROM THE RIGHT OR LEFT HAND SIDE OF THE GOODS.

NO.	PLATE	NAME
*24335	——	Arm with 11104
8582	773	" Dowel Pin
12453	773	" Oil Tube for intermediate bearing
12454	773	" " " with 29599, for oiling 12409
11119	773	" " " " " " " 12408
24131	2014	" " " " " " " 20283
29599	2014	" " " Packing (felt)
748E	782	" Screw (back)
868E	1366	" " (front)
16511	1349	" Shaft
*11104	——	" " Bushing (front)
12357	767	" " Flanged Bushing (back)
448C	783	" " " " " Set Screw
144D	782	Arm Shaft Screw
12480	767	" Side Cap
219D	774	" " " Screw
12193	2004	" " Cover
286D	783	" " " Thumb Screw
12403	772	" Spool Pin and Thread Eyelet
11241	2003	" " " Washer (cloth)
24296	1348	Balance Wheel (power) light rim, $2\frac{3}{16}$ in. pulley, with two 448C
24297	1340	Balance Wheel Oil Cover
210D	1343	" " " " Screw
448C	783	" " Set Screw
*16503	——	Bed
20197	1350	Crank Connecting Rod with 20198 and two 896E
*20198	——	Crank Connecting Rod Cap
896E	773	" " " " Screw
908C	773	" " " Hinge Screw
1619E	773	" " " " " Nut

NO.	PLATE	NAME
20057	——	Face Plate
20058	1340	Face Plate complete, Nos. 2827, 12150 and 20057
190D	782	Face Plate Screw
44181	——	" " Thread Guard (lower)
12150	773	" " " " " 44181 with 12152
12152	773	Face Plate Thread Guard (lower) Rivet
2827	773	" " " " (upper) with 8505
8505	773	" " " " " Rivet
286D	783	" " Thumb Screw
12368	767	Feed Bar
313C	783	" " Screw Centre
56813	——	" " " " 313C with 1519J
1519J	783	" " " " Nut
3033	770	" Connecting Link
375C	782	" " " Hinge Screw
1518E	783	" " " " " Nut
20138	1263	" Dog, 13 teeth (12 teeth to the inch) for shirt work, beveled for hemmer
208E	782	Feed Dog Screw
20283	1315	" and Feed Lifting Eccentric with 446C
446C	783	" " " " " Set Screw
24036	1340	" " " " " Sleeve
20284	1350	" Forked Connection
375C	782	" " " Hinge Screw
1518E	783	" " " " " Nut
24969	2551	" Lifting Rock Shaft
24970	——	Feed Lifting Rock Shaft complete, Nos. 12376 and 24969
12376	770	Feed Lifting Rock Shaft Crank with 157J and 1813
157J	782	Feed Lifting Rock Shaft Crank Clamping Screw
1813	783	Feed Lifting Rock Shaft Crank Roller and Stud
43976	2551	Feed Lifting Rock Shaft Crank Connecting Rod with 43977 and two 966E
*43977	——	Feed Lifting Rock Shaft Crank Connecting Rod Cap
966E	5806	Feed Lifting Rock Shaft Crank Connecting Rod Cap Screw
375C	782	Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw
1518E	783	Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw Nut

NO.	PLATE	NAME
307c	783	Feed Lifting Rock Shaft Screw Centre...
56814	——	" " " " " " 307c with 1513J.....
1513J	783	Feed Lifting Rock Shaft Screw Centre Nut
3039	768	" Regulator.....
1128E	2009	" " Hinge Screw.....
818D	783	" " Thumb Screw.....
16506	766	" Rock Shaft.....
24376	——	Feed Rock Shaft complete, Nos. 16506 and 29633.....
29633	1354	Feed Rock Shaft Crank with 157J.....
157J	782	" " " " Clamping Screw.
307c	783	" " " Screw Centre .....
56814	——	" " " " " 307c with 1513J.....
1513J	783	Feed Rock Shaft Screw Centre Nut.....
12381	767	Needle Bar (hollow).....
12382	770	" " Connecting Link with 794E..
794E	782	" " " " Adjusting Screw.....
*12383	——	Needle Bar Connecting Stud.....
1904	770	" " " " Roller (roller only).....
453c	783	Needle Bar Connecting Stud Set Screw.
12384	770	Needle Bar Connecting Stud complete, Nos. 453c, 1904 and 12383.....
20188	767	Needle Bar Crank with 858c and 1065c..
1065c	1366	" " " Position Screw.....
858c	783	" " " Set Screw.....
936E	773	" " Screw Bushing.....
4302	773	" " Thread Guard.....
233D	782	" " " " Screw.....
4303	773	" Clamp with 808F.....
808F	782	" " Screw.....
24104	1350	Oscillating Rock Shaft.....
24105	——	Oscillating Rock Shaft complete, Nos. 4784, 12388 and 24104.....
12388	767	Oscillating Rock Shaft Hinge Pin.....
878J	783	" " " " " Oil Hole Stop Screw.....
12459	773	Oscillating Rock Shaft Hinge Pin Oil Hole Stop Screw Washer (leather).....
448c	783	Oscillating Rock Shaft Hinge Pin Set Screw.....

NO.	PLATE	NAME
4784	1353	Oscillating Rock Shaft Oil Pad.....
16509	766	" Shaft.....
19496	——	" " Crank for 19447.....
44134	——	" " " " 44135.....
19447	1353	Oscillating Shaft Crank complete, Nos. 457C, 1518E, 19449 and 19496.....
44135	5806	Oscillating Shaft Crank complete, Nos. 1518E, 19449, 44134 and two 453C.....
2049	773	Oscillating Shaft Crank Pin.....
457C	783	" " " Set Screw for 19447
453C	783	" " " " " " 44135
19448	1353	" " " Slide Block.....
229D	782	" " " " " Cap Screw.....
12424	773	Oscillating Shaft Crank Slide Block Cap Screw Washer.....
988C	1353	Oscillating Shaft Crank Slide Block Screw Stud.....
1518E	783	Oscillating Shaft Crank Slide Block Screw Stud Nut.....
19449	1353	Oscillating Shaft Crank Slide Block complete, Nos. 229D, 988C, 12424 and 19448
12391	767	Presser Bar (hollow).....
20059	1341	" " Guide Bracket with 453C....
453C	783	" " " " Set Screw....
2062	771	" " Lifter.....
689C	782	" " " Screw.....
1520E	783	" " " " Nut.....
12327	770	" " Lifting and Releasing Lever Bracket.....
11167	767	Presser Bar Spring (light) .051 wire.....

NOTE: No. 11167 is sent with this Machine unless another Spring is specified on order.

12139	2004	Presser Bar Spring (medium) .055 wire....
20023	2004	" " " (heavy) .063 wire.....
11170	771	" " " Washer.....
12144	780	" Foot for 20138.....
190D	782	" " Screw.....
688J	783	Pressure Regulating Thumb Screw.....
19131	5737	Shuttle Bobbin.....
20649	5737	" " Case Latch.....
2973	5737	" " " " Lever.....
2974	5737	" " " " " Fulcrum Pin.....
2975	5737	Shuttle Bobbin Case Latch Spring.....
592E	5737	" " " " Stop Screw...

NO.	PLATE	NAME
20650	——	Shuttle Bobbin Case Hinge, Nos. 2973, 2974 and 20649
20755	5737	Shuttle Bobbin Case Position Finger
2523	5737	" " " " " Rivet
24323	2046	" " " " Plate
391D	1366	" " " " " Screw
20756	5737	Shuttle Bobbin Case complete, Nos. 591F, 592E, 2523, 2975, 20650, 20654 and 20755
20757	5737	Shuttle Body
591F	5737	" Tension Regulating Screw
20654	5737	" " Spring
20758	5737	Shuttle, $1\frac{11}{16}$ in. diam., Nos. 19131, 20756 and 20757
19406	2012	Shuttle Driver with two 1266C
2049	773	" " Pin
1266C	5806	" " Set Screw
2419	2006	" Race Back
2532	772	" " " Position Pin
2533	767	" " " Spring
907D	782	" " " " Screw
24324	——	" " Body
24998	——	" " " 24324 with 24009 and two 1053D
24009	2006	Shuttle Race Cap
1053D	2006	" " Screw
24325	2046	Shuttle Race complete, Nos. 907D, 2419, 2533, 24323, 24998 and two each 391D and 2532
145D	782	Shuttle Race Screw
12431	——	" " Slide
12432	2004	Shuttle Race Slide complete, Nos. 4307, 12431 and two 725E
4307	772	Shuttle Race Slide Spring
725E	1387	" " " " Screw
20060	1311	Slack Thread Regulator
225F	1323	" " " Adjusting Screw
2102	5806	Tension Disc
1560C	783	" Regulating Thumb Nut
32572	5806	" Releasing Disc
43944	5806	" " Lever
12398	773	" " " Hinge Pin
12329	772	" " " Spring
32574	5806	" " Pin
50327C	5806	" Screw Stud
44141	——	" " " 50327C with 1560C
43945	5806	" Spring

NO.	PLATE	NAME
44118	——	Tension complete, Nos. 7336, 32572, 32574, 43945, 43946, 44141 and two 2102
52454	5842	Thread Retainer
50429c	——	" " Set Screw
12404	770	" Take-up Crank
3094	773	" " " Wedge
690e	782	" " " " Screw
12408	770	" " Lever
775e	782	" " " Cap Screw
12166	773	" " " Hinge Pin
12409	770	" " " Link
11204	770	" " " " Hinge Pin
435c	5806	" " " " " " Set Screw
12410	——	Thread Take-up Lever complete, Nos. 12166, 12408 and 12409
43946	5806	Thread Take-up Spring
7336	772	" " " Regulator
448c	783	" " " " Set Screw
26891	2631	Throat Plate, small needle hole, for 20138
691f	782	" " Screw
26892	2629	Tuck Folder (under, right) for 26895
26896	2630	" " " " " 26899
401e	2442	" " " " Screw for 26895
756e	2442	" " " " " " 26899
26502	2629	" " (upper, left) for 26895
26897	2630	" " " " " 26899
4621	2442	" " " " Guide Pin
337d	2442	" " " " Screw
26893	2629	" " Arm with 2301
691f	2442	" " " Screw
26894	2629	" " Guide (under, left) with 4621, for 26895
26898	2630	Tuck Folder Guide (under, left) with 4621, for 26899
4621	2442	Tuck Folder Guide (under, left) Rivet
401e	2442	" " " " " Screw
26437	2629	" " Sliding Bracket with 2301, for 26895
26449	2630	Tuck Folder Sliding Bracket with 2301, for 26899
26438	2629	Tuck Folder Sliding Bracket Cap
233d	2442	" " " " " Screw
514c	2442	" " " " Locking Pin
26439	2442	" " " " " " Bushing with 468c

NO.	PLATE	NAME
1564D	2442	Tuck Folder Sliding Bracket Locking Pin Head
2297	2442	Tuck Folder Sliding Bracket Locking Pin Spring
2296	2442	Tuck Folder Sliding Bracket Locking Pin Spring Bushing
468C	2442	Tuck Folder Sliding Bracket Locking Pin Spring Bushing Set Screw
2301	2442	Tuck Folder Sliding Bracket Stop Pin
233D	2442	" " " " " Screw.
26592	2629	" Guide
2301	2442	" " Guide Pin
26450	2630	" " (under)
26451	2630	" " (upper)
26636	2630	" " Division Block
7476	2442	" " Rivet
26637	——	Tuck Guide complete, Nos. 26450, 26451, 26636 and three 7476
658D	2442	Tuck Guide Thumb Screw
26895	——	Tuck Folding Attachment complete, for folding the tuck to the right, beginning at the left hand side of the goods, Nos. 514C, 1564D, 2296, 2297, 4621, 26437 to 26439, 26502, 26 92, 26891 to 26894, two each 337D, 658D, three 233D and four 401E
26899	——	Tuck Folding Attachment complete, for folding the tuck to the right, beginning at the right hand side of the goods, Nos. 514C, 1564D, 2296, 2297, 4621, 26438, 26439, 26449, 26637, 26891, 26893, 26896 to 26898, two each 337D, 401E, 658D, 756E and three 233D
24079	2641	Drip Pan with four 1 in. wire nails

LIST OF PARTS COMPLETE

FOR

MACHINE No. 44-28

DROP FEED, SINGLE NEEDLE, POSITIVE ADJUSTABLE RUFFLING MECHANISM, WITH TRIMMING ATTACHMENT. FOR CLOTH.

NO.	PLATE	NAME
*24407	——	Arm with 11104
8582	773	" Dowel Pin
12453	773	" Oil Tube, for intermediate bearing
12454	773	" " " with 29599, for oiling 12409
11119	773	" " " " " " " 1240S, 16569 and 24207
24131	2014	Arm Oil Tube with 29599, for oiling 20283
29599	2014	" " " Packing (felt)
748E	782	" Screw (back)
868E	1366	" " (front)
24195	1349	" Shaft
*11104	——	" " Bushing (front)
12357	767	" " Flanged Bushing (back)
448C	783	" " " " " Set Screw
144D	782	Arm Shaft Screw
12193	2004	" Side Cover
286D	783	" " " Thumb Screw
12403	772	" Spool Pin and Thread Eyelet
11241	2003	" " " Washer (cloth)
24296	1348	Balance Wheel (power) light rim, $2\frac{3}{16}$ in. pulley, with two 448c
24297	1340	Balance Wheel Oil Cover
210D	1343	" " " " Screw
448C	783	" " Set Screw
*16596	——	Bed
20197	1350	Crank Connecting Rod with 20198 and two 896E
*20198	——	Crank Connecting Rod Cap
896E	773	" " " " Screw
908C	773	" " " Hinge Screw
1619E	773	" " " " " Nut.
16558	——	Face Plate

NO.	PLATE	NAME
16559	1351	Face Plate complete, Nos. 2827, 12150 and 16558
217D	1312	Face Plate Screw
44181	——	" " Thread Guard (lower)
12150	773	" " " " " 44181 with 12152
12152	773	Face Plate Thread Guard (lower) Rivet
2827	773	" " " " (upper) with 8505
8505	773	" " " " " Rivet
12368	767	Feed Bar
313c	783	" " Screw Centre
56813	——	" " " " 313c with 1519J
1519J	783	" " " " Nut
3033	770	" Connecting Link
375c	782	" " " Hinge Screw
1518E	783	" " " " " Nut
24408	1271	" Dog
208E	782	" " Screw
20283	1315	" and Feed Lifting Eccentric with 446c
446c	783	" " " " " Set Screw
24036	1340	" " " " " Sleeve
20284	1350	" Forked Connection
375c	782	" " " Hinge Screw
1518E	783	" " " " " Nut
24969	2551	" Lifting Rock Shaft
24970	——	Feed Lifting Rock Shaft complete, Nos. 12376 and 24969
12376	770	Feed Lifting Rock Shaft Crank with 157J and 1813
157J	782	Feed Lifting Rock Shaft Crank Clamping Screw
1813	783	Feed Lifting Rock Shaft Crank Roller and Stud
43976	2551	Feed Lifting Rock Shaft Crank Connecting Rod with 43977 and two 966E
*43977	——	Feed Lifting Rock Shaft Crank Connecting Rod Cap
966E	5806	Feed Lifting Rock Shaft Crank Connecting Rod Cap Screw
375c	782	Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw
1518E	783	Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw Nut
307c	783	Feed Lifting Rock Shaft Screw Centre
56814	——	" " " " " " 307c with 1513J

NO.	PLATE	NAME
1513J	783	Feed Lifting Rock Shaft Screw Centre Nut
3039	768	" Regulator
1128E	2009	" " Hinge Screw
818D	783	" " Thumb Screw
16506	766	" Rock Shaft
24376	——	Feed Rock Shaft complete, Nos. 16506 and 29633
29633	1354	Feed Rock Shaft Crank with 157J
157J	782	" " " " Clamping Screw.
307C	783	" " " Screw Centre
56814	——	" " " " " 307C with 1513J
1513J	783	Feed Rock Shaft Screw Centre Nut
5726	1271	Knife
		NOTE: Two No. 5726 are sent with this Machine
620F	782	Knife Adjusting Screw
19297	1315	" Bar with 2301
24431	1352	" " Crank with 191C
1162C	1366	" " " Coupling Pin
1564D	2442	" " " " " Head
2297	2442	" " " " " Spring
2022	773	" " " Pin
191C	1366	" " " Set Screw
24432	——	Knife Bar Crank complete, Nos. 1162C, 1564D, 2297 and 24431
16563	1315	Knife Bar Driving Crank (forked)
16564	1315	" " " " Bracket
24433	——	Knife Bar Driving Crank Bracket complete, Nos. 2022, 16563, 16564 and 24432
647C	774	Knife Bar Driving Crank Bracket Screw.
24122	1317	" " Lifting Spring
24123	1317	" " " " Case
24124	1317	" " " " Guide
*24906	——	" " " " " 24124 with 2523 and 24125
24125	1317	Knife Bar Lifting Spring Guide Bracket
621D	1317	" " " " " " Screw
2523	1317	" " " " " Pin
2301	1317	" " Stop Pin
24128	——	Knife Bar complete, Nos. 621D, 19297, 19391, 24109, 24906 and three 335H
19391	8376	Knife Holder with 620F, 2291 and two 223F
24109	8376	" " Handle
335H	1317	" " " Screw
335H	1317	" " Screw
223F	1317	" Screw

NO.	PLATE	NAME
2291	1317	Knife Screw Washer
16568	1352	Needle Bar with 620F, 1072F and 24391
12382	770	" " Connecting Link with 794E
794E	782	" " " " Adjusting Screw
*12383	——	Needle Bar Connecting Stud
1904	770	" " " " Roller (roller only)
453C	783	Needle Bar Connecting Stud Set Screw
12384	770	Needle Bar Connecting Stud complete, Nos. 453C, 1904 and 12383
16569	1315	Needle Bar Crank (eccentric) with 448C and 743C
743C	1317	Needle Bar Crank Position Screw
448C	783	" " " Set Screw
24391	8376	" " Thread Guard
620F	782	" " " " Set Screw
1072F	1317	" Set Screw
24104	1350	Oscillating Rock Shaft
24105	——	Oscillating Rock Shaft complete, Nos. 4784, 12388 and 24104
12388	767	Oscillating Rock Shaft Hinge Pin
878J	783	" " " " " Oil Hole Stop Screw
12459	773	Oscillating Rock Shaft Hinge Pin Oil Hole Stop Screw Washer (leather)
448C	783	Oscillating Rock Shaft Hinge Pin Set Screw
4784	1353	Oscillating Rock Shaft Oil Pad
16509	766	" Shaft
19496	——	" " Crank for 19447
44134	——	" " " " 44135
19447	1353	Oscillating Shaft Crank complete, Nos. 457C, 1518E, 19449 and 19496
44135	5806	Oscillating Shaft Crank complete, Nos. 1518E, 19449, 44134 and two 453C
2049	773	Oscillating Shaft Crank Pin
457C	783	" " " Set Screw for 19447
453C	783	" " " " " " 44135
19448	1353	" " " Slide Block
229D	782	" " " " " Cap Screw
12424	773	Oscillating Shaft Crank Slide Block Cap Screw Washer
988C	1353	Oscillating Shaft Crank Slide Block Screw Stud

NO.	PLATE	NAME
1518E	783	Oscillating Shaft Crank Slide Block Screw Stud Nut.....
19449	1353	Oscillating Shaft Crank Slide Block complete, Nos. 229D, 988C, 12424 and 19448
12391	767	Presser Bar (hollow).....
12326	770	" " Guide Bracket with 453C....
453C	783	" " " " Set Screw....
2062	771	" " Lifter.....
689C	782	" " " Screw.....
1520E	783	" " " " Nut.....
12327	770	" " Lifting and Releasing Lever Bracket.....
11167	767	Presser Bar Spring (light) .051 wire.....

NOTE: No. 11167 is sent with this Machine unless another Spring is specified on order.

12139	2004	Presser Bar Spring (medium) .055 wire...
20023	2004	" " " (heavy) .063 wire....
11170	771	" " " Washer.....
24411	1344	" Foot for 24408.....

NOTE: When ordering No. 24411 state required distance of trimmed edge from seam.

NOTE: No. 24411, $\frac{3}{16}$ in gauge, is sent with this Machine unless otherwise specified on order.

190D	782	Presser Foot Screw.....
688J	783	Pressure Regulating Thumb Screw.....
26888	1344	Ruffling Arm (lower).....
26889	1344	" " (upper) with 190D and 219F
207F	1344	" " Adjusting Screw.....
2291	1344	" " " " Washer...
190D	782	" " Clamping Screw.....
26890	1344	Ruffling Arm (adjustable) Nos. 2291, 26888, 26889 and two 207F.....
28845	——	Ruffling Arm (adjustable) complete, Nos. 226D, 1550J, 24203 to 24206, 26890 and two 665D.....
24199	1323	Ruffling Arm Shaft.....
24200	1324	" " " Bracket (right).....
145D	1324	" " " " " Screw
24201	1324	" " " " (left).....
159D	1324	" " " " " Screw..
6533	1323	" " " Collar with 460C.....
460C	1323	" " " " Set Screw....
219F	774	" " Set Screw.....
24409	1344	" Blade.....
24203	1344	" " Holder.....

NO.	PLATE	NAME
226D	1344	Ruffling Blade Holder Cap Screw
24204	1344	" " " Spring
24205	1344	" " " " Stop
24206	1344	" " " Stud
1550J	1344	" " " " Nut
665D	1344	" " Screw
24207	1323	" Eccentric with two 453C
24208	1323	" " Collar with 453C
453C	1323	" " " Set Screw
24219	1323	" " Connection with 24220 and two 742E
*24220	——	Ruffling Eccentric Connection Cap
742E	1323	" " " " Screw
24210	1324	" " " Washer
453C	1323	" " Set Screw
24211	1323	" Regulator with 225F
225F	1323	" " Set Screw
181D	1323	" " Stop Screw
1641E	1323	" " " " Nut
1108F	1323	" " Thumb Screw
1641E	1323	" " " " Nut
24718	1352	" Separating Blade
4604	1385	" " " Rivet
43919	1352	" " " Shank
24410	1352	Ruffling Separating Blade on Shank complete, Nos. 24718, 43919 and two 4604
1423D	5742	Ruffling Separating Blade Screw
2996	771	Shuttle Bobbin
15140	1353	" " Case Latch
2973	771	" " " " Lever
2974	771	" " " " " Fulcrum Pin
2975	771	Shuttle Bobbin Case Latch Spring
592E	782	" " " " Stop Screw
15141	——	Shuttle Bobbin Case Hinge, Nos. 2973, 2974 and 15140
7553	771	Shuttle Bobbin Case Position Finger
2523	771	" " " " " Rivet
24412	1361	" " " " Plate
391D	1366	" " " " " Screw
24074	771	Shuttle Bobbin Case complete, Nos. 591F, 592E, 2523, 2975, 7553, 15098 and 15141
12393	771	Shuttle Body
591F	782	" Tension Regulating Screw
15098	771	" " Spring
19292	771	Shuttle, 1 $\frac{11}{16}$ in. diam., Nos. 2996, 12393 and 24074

NO.	PLATE	NAME
*12394	——	Shuttle Driver
12444	771	" " 12394 with two 1266c
2049	773	" " Pin
1266c	5806	" " Set Screw
2531	767	" Race Back
2532	772	" " " Position Pin
2533	767	" " " Spring
907D	782	" " " " Screw
24413	——	" " Body
25000	——	" " " 24413 with 24414 and two 1053D
24414	1362	Shuttle Race Cap
1053D	2006	" " " Screw
24415	1361	Shuttle Race complete, Nos. 907D, 2531, 2533, 24412, 25000 and two each 391D and 2532
145D	782	Shuttle Race Screw
12431	——	" " Slide
12432	2004	Shuttle Race Slide complete, Nos. 4307, 12431 and two 725E
4307	772	Shuttle Race Slide Spring
725E	1387	" " " " Screw
2921	771	Tension Disc
1560c	783	" Regulating Thumb Nut
20037	2009	" Releaser
12397	772	" Releasing Lever
12398	773	" " " Hinge Pin
12329	772	" " " Spring
413c	783	" Screw Stud
33892	——	" " " 413c with 1560c
2923	771	" Spring
12149	2014	" Thread Guard
44147	——	Tension complete, Nos. 2923, 7336, 8511, 20037, 33892 and two 2921
52454	5842	Thread Retainer
50429c	——	" " Set Screw
12404	770	" Take-up Crank
3094	773	" " " Wedge
690E	782	" " " " Screw
12408	770	" " Lever
775E	782	" " " Cap Screw
12166	773	" " " Hinge Pin
12409	770	" " " Link
11204	770	" " " " Hinge Pin
435c	5806	" " " " " " Set Screw

NO.	PLATE	NAME
12410	——	Thread Take-up Lever complete, Nos. 12166, 12408 and 12409.....
8511	773	Thread Take-up Spring.....
7336	772	" " " Regulator .....
448c	783	" " " " Set Screw
5730	1271	Throat Plate Cutting Bar.....

NOTE: When ordering No. 5730, state required distance of trimmed edge from seam.

NOTE: No. 5730, $\frac{3}{16}$ in. gauge, is sent with this Machine unless otherwise specified on order.

578D	8376	Throat Plate Cutting Bar Screw.....
5731	1271	" " Slide.....
236F	773	" " " Adjusting Screw.....
24429	1271	Throat Plate complete for 24408, Nos. 236F, 5730, 5731 and two 578D.....

NOTE: When ordering No. 24429, state required distance of trimmed edge from seam.

NOTE: No. 24429, $\frac{1}{8}$ in. gauge, is sent with this Machine unless otherwise specified on order.

691F	782	Throat Plate Screw.....
24079	2644	Drip Pan with four 1 in. wire nails.....

LIST OF PARTS COMPLETE

FOR

MACHINE No. 44-29

FOR COLLARS AND CUFFS. DROP FEED.

NO.	PLATE	NAME
*24025	——	Arm with 11104
8582	773	" Dowel Pin
12453	773	" Oil Tube for intermediate bearing
12454	773	" " " with 29599, for oiling 24099
11119	773	" " " " " " " 24068
24131	2014	" " " " " " " 24035
29599	2014	" " " Packing (felt)
748E	782	" Screw (back)
868E	1366	" " (front)
24026	1339	" Shaft
*11104	——	" " Bushing (front)
12357	767	" " Flanged Bushing (back)
448C	783	" " " " " Set Screw

NO.	PLATE	NAME
144D	782	Arm Shaft Screw
12480	767	" Side Cap
219D	774	" " " Screw
12193	2004	" " Cover
286D	783	" " " Thumb Screw
12403	772	" Spool Pin and Thread Eyelet
11241	2003	" " " Washer (cloth)
24328	1339	Balance Wheel, light rim, 2¼ in. pulley, with two 448C
24297	1340	Balance Wheel Oil Cover
210D	1343	" " " " Screw
448C	783	" " Set Screw
*24027	——	Bed
24028	1339	Crank Connecting Rod with 24085 and two 896E
*24085	——	Crank Connecting Rod Cap
896E	773	" " " " Screw
908C	773	" " " Hinge Screw
1619E	773	" " " " " Nut.
20057	——	Face Plate
20058	1340	Face Plate complete, Nos. 2827, 12150 and 20057
190D	782	Face Plate Screw
44181	——	" " Thread Guard (lower)
12150	773	" " " " " 44181 with 12152
12152	773	Face Plate Thread Guard (lower) Rivet
2827	773	" " " " (upper) with 8505
8505	773	" " " " " Rivet
286D	783	" " Thumb Screw
24034	1340	Feed Bar
313C	783	" " Screw Centre
56813	——	" " " " 313C with 1519J
1519J	783	" " " " Nut
3033	770	" Connecting Link
375C	782	" " " Hinge Screw
1518E	783	" " " " " Nut.
20115	1266	" Dog, $\frac{1}{16}$ in. stitch (7 teeth front and 5 teeth back of needle)
20163	1266	Feed Dog, $\frac{1}{16}$ in. stitch, $\frac{1}{64}$ in. higher (otherwise same as 20115)
20116	1266	Feed Dog, ⅛ in. stitch, 16 teeth to the inch (6 teeth front and 5 teeth back of needle)
20164	1266	Feed Dog, ⅛ in. stitch, $\frac{1}{64}$ in. higher (otherwise same as 20116)

NO.	PLATE	NAME
20137	1266	Feed Dog, ⅛ in. stitch, 22 teeth to the inch (8 teeth front and 5 teeth back of needle).....

NOTE: Nos. 20163 and 20164 are sent with this Machine unless other Feed Dogs are specified on order.

208E	782	Feed Dog Screw.....
24035	1340	" and Feed Lifting Eccentric with 448C
448C	783	" " " " " Set Screw
24036	1340	" " " " " Sleeve...
24037	1339	" Forked Connection.....
375C	782	" " " Hinge Screw...
1518E	783	" " " " " Nut
16504	766	" Lifting Rock Shaft.....
16588	——	Feed Lifting Rock Shaft complete, Nos. 2049, 12376, 16504 and 16556.....
16556	2009	Feed Lifting Rock Shaft Crank (back) with 462C.....
2049	773	Feed Lifting Rock Shaft Crank (back) Pin.....
462C	773	Feed Lifting Rock Shaft Crank (back) Set Screw.....
12376	770	Feed Lifting Rock Shaft Crank (front) with 157J and 1813.....
157J	782	Feed Lifting Rock Shaft Crank (front) Clamping Screw.....
1813	783	Feed Lifting Rock Shaft Crank (front) Roller and Stud.....
12430	5764	Feed Lifting Rock Shaft Crank Connecting Rod with 12204 and two 966E.....
*12204	——	Feed Lifting Rock Shaft Crank Connecting Rod Cap.....
966E	5806	Feed Lifting Rock Shaft Crank Connecting Rod Cap Screw.....
375C	782	Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw.....
1518E	783	Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw Nut.....
307C	783	Feed Lifting Rock Shaft Screw Centre...
56814	——	" " " " " " 307C with 1513J.....
1513J	783	Feed Lifting Rock Shaft Screw Centre Nut
3039	768	" Regulator.....
1128E	2009	" " Hinge Screw.....
818D	783	" " Thumb Screw.....
24585	8375	" " " " Stop.....
16506	766	" Rock Shaft.....

NO.	PLATE	NAME
24376	——	Feed Rock Shaft complete, Nos. 16506 and 29633
29633	1354	Feed Rock Shaft Crank with 157J
157J	782	" " " " Clamping Screw
307C	783	" " " Screw Centre
56814	——	" " " " " 307C with 1513J
1513J	783	Feed Rock Shaft Screw Centre Nut
24451	2647	Needle Bar
24442	2647	" " Bushing with 29532
1133E	8376	" " " Set Screw
24040	1341	" " Connecting Link with 794E
794E	782	" " " " Adjusting Screw
775E	782	Needle Bar Connecting Link Cap Screw
24041	1341	" " " Stud with 207E
207E	1341	" " " " Clamping Screw
24052	1340	Needle Bar Crank with 858C, 1036C, 1037C and 1065C
1065C	1366	Needle Bar Crank Position Screw
858C	783	" " " Set Screw
862D	1341	" " Hole Plug Screw
29532	1341	" " Oil Cup
24452	2647	" " Gib
24453	2647	" Clamp with 196F and 24452
196F	772	" " Screw
24043	1340	Oscillating Rock Shaft
24044	——	Oscillating Rock Shaft complete, Nos. 4784, 12388 and 24043
12388	767	Oscillating Rock Shaft Hinge Pin
878J	783	" " " " " Oil Hole Stop Screw
12459	773	Oscillating Rock Shaft Hinge Pin Oil Hole Stop Screw Washer (leather)
448C	783	Oscillating Rock Shaft Hinge Pin Set Screw
4784	1353	Oscillating Rock Shaft Oil Pad
24045	1339	" Shaft
24046	1341	" " Bushing (back)
24047	1341	" " " (front)
24048	——	" " Crank
24049	1343	Oscillating Shaft Crank complete, Nos. 462C, 1636E, 24048 and 24050
2269	773	Oscillating Shaft Crank Pin
462C	773	" " " Set Screw
19448	1353	" " " Slide Block

NO.	PLATE	NAME
229D	782	Oscillating Shaft Crank Slide Block Cap Screw
12424	773	Oscillating Shaft Crank Slide Block Cap Screw Washer
1035C	1343	Oscillating Shaft Crank Slide Block Screw Stud
1636E	1343	Oscillating Shaft Crank Slide Block Screw Stud Nut
24050	1343	Oscillating Shaft Crank Slide Block complete, Nos. 229D, 1035C, 12424 and 19448
12391	767	Presser Bar (hollow)
20059	1341	" " Guide Bracket with 453C
453C	783	" " " " Set Screw
2062	771	" " Lifter
689C	782	" " " Screw
1520E	783	" " " " Nut
12327	770	" " Lifting and Releasing Lever Bracket
11167	767	Presser Bar Spring (light) .051 wire

NOTE: No. 11167 is sent with this Machine unless another Spring is specified on order.

12139	2004	Presser Bar Spring (medium) .055 wire
20023	2004	" " " (heavy) .063 wire
11170	771	" " " Washer
12435	780	" Foot with 228D, for 20115, 20116, 20137, 20163 and 20164

NOTE: No. 12435 is sent with this Machine unless another Presser Foot is specified on order.

12462	781	Presser Foot, $\frac{3}{16}$ in. to $\frac{1}{4}$ in. gauge

NOTE: When ordering No. 12462, give width of turned edge from seam.

12463	781	Presser Foot with Strip Guide
12335	1308	" " (narrow) for 20115, 20116, 20137, 20163 and 20164
26276	1394	Presser Foot Hinge Pin
20133	——	" " Plate
19223	——	" " Shank
20134	1308	Presser Foot (hinged) complete, $\frac{3}{16}$ in. to $\frac{1}{4}$ in. gauge, Nos. 19223, 20133 and 26276

NOTE: When ordering No. 20134, give width of turned edge from seam.

2532	772	Presser Foot Hinge Pin
20155	——	" " Plate
20156	——	" " Shank

NO.	PLATE	NAME
20157	1309	Presser Foot (hinged) complete for 20115, 20116, 20137, 20163 and 20164, Nos. 228D, 2532, 20155 and 20156.....
20343	781	Presser Foot with guide on bottom to the right of needle hole.....
26276	1394	Presser Foot Hinge Pin.....
20360	——	" " Plate.....
19335	——	" " Shank.....
20361	781	Presser Foot (hinged) plain bottom, complete, Nos. 19335, 20360 and 26276....
26279	——	Presser Foot Extension, $\frac{1}{16}$ in., for 12435 and 20157.....
26280	——	Presser Foot Extension, ⅛ in., for 12435 and 20157.....
26281	1387	Presser Foot Extension, ¼ in., for 12435 and 20157.....
26282	——	Presser Foot Extension, ⅜ in., for 12435 and 20157.....
26283	——	Presser Foot Extension, ½ in., for 12435 and 20157.....
228D	2038	Presser Foot Extension Screw.....
25967	1387	" " Strip Gauge for 12435 and 20157.....
228D	2038	Presser Foot Strip Gauge Screw.....

NOTE: Nos. 25967 and 26279 to 26283 are sent with this Machine unless otherwise specified on order.

190D	782	Presser Foot Screw.....
688J	783	Pressure Regulating Thumb Screw.....
24051	1343	Shuttle Bobbin.....
15140	1353	" " Case Latch.....
2973	771	" " " " Lever.....
2974	771	" " " " " Fulcrum Pin.....
2975	771	Shuttle Bobbin Case Latch Spring.....
592E	782	" " " " Stop Screw...
15141	——	Shuttle Bobbin Case Hinge, Nos. 2973, 2974 and 15140.....
24055	1343	Shuttle Bobbin Case Position Finger.....
2523	771	" " " " " Rivet
24412	1361	" " " " Plate.....
391D	1366	" " " " " Screw
24056	1343	Shuttle Bobbin Case complete, Nos. 591F, 592E, 2523, 2975, 15141, 24055 and 24058

NO.	PLATE	NAME
24057	1343	Shuttle Body
591F	782	" Tension Regulating Screw
24058	1343	" " Spring
24059	1343	Shuttle, 1 $\frac{11}{16}$ in. diam., Nos. 24051, 24056 and 24057
*24060	——	Shuttle Driver
24061	1343	" " 24060 with two 462C
2269	773	" " Pin
462C	773	" " Set Screw
24062	1342	" Race Back
2532	772	" " " Position Pin
2533	767	" " " Spring
907D	782	" " " " Screw
24437	——	" " Body
62510	——	" " " 24437 with 24064 and two 1053D
62519	——	Shuttle Race Body 62510 with two 2532
24064	1342	" " Cap
1053D	2006	" " " Screw
24438	1364	Shuttle Race complete, Nos. 907D, 2533, 24062, 24412, 62519 and two 391D
145D	782	Shuttle Race Screw
12431	——	" " Slide
12432	2004	Shuttle Race Slide complete, Nos. 4307, 12431 and two 725E
4307	772	Shuttle Race Slide Spring
725E	1387	" " " " Screw
20060	1311	Slack Thread Regulator
225F	1323	" " " Adjusting Screw
2102	5806	Tension Disc
1560C	783	" Regulating Thumb Nut
32572	5806	" Releasing Disc
43944	5806	" " Lever
12398	773	" " " Hinge Pin
12329	772	" " " Spring
32574	5806	" " Pin
50327C	5806	" Screw Stud
44141	——	" " " 50327C with 1560C
8238	1353	" Spring
24984	——	Tension complete, Nos. 7336, 8238, 24071, 32572, 32574, 44141 and two 2102
24078	1343	Thread Guard (side of arm)
52454	5842	" Retainer
50429C	——	" " Set Screw
24097	1341	" Take-up Crank
1037C	1341	" " " Position Screw
1036C	1341	" " " Set Screw

NO.	PLATE	NAME
24068	1341	Thread Take-up Lever.....
12166	773	" " " Hinge Pin.....
24099	1341	" " " Link.....
11204	770	" " " " Hinge Pin...
435c	5806	" " " " " " Set Screw.....
24070	——	Thread Take-up Lever complete, Nos. 12166, 24068 and 24099.....
24071	1343	Thread Take-up Spring.....
7336	772	" " " Regulator.....
448c	783	" " " " Set Screw
20123	1266	Throat Plate for 20115, 20116, 20137, 20163 and 20164.....

NOTE: No. 20123 is sent with this Machine unless another Throat Plate is specified on order.

691F	782	Throat Plate Screw.....
24079	2644	Drip Pan with four 1 in. wire nails.....

SPOOL HOLDER (Disc)

26763	1352	Bracket with 219F and 287D.....
219F	774	" Screw.....
287D	2636	" Thumb Screw.....
19066	1352	Spindle.....
19067	1352	" Thread Guiding Disc.....
691F	782	" " " " Screw.....
26764	1352	Spool Holder (disc) complete, Nos. 691F, 19066, 19067 and 26763.....

LIST OF PARTS COMPLETE

FOR



MACHINE No. 44-72

FOR BINDING CORSETS AND OTHER ARTICLES; ALSO FOR STITCHING WORK OF UNEVEN THICKNESS OR HAVING ADHESIVE SURFACES. HAS POSITIVE UPPER AND UNDER FEEDING MECHANISM AND ALTERNATING PRESSERS.

NO.	PLATE	NAME
*24469	——	Arm with 11104
8582	773	" Dowel Pin
12453	773	" Oil Tube, for intermediate bearing
12454	773	" " " with 29599, for oiling 12409
11119	773	" " " " " " " 12408 and 19365
24131	2014	Arm Oil Tube with 29599, for oiling 20283
29599	2014	" " " Packing (felt)
748E	782	" Screw (back)
868E	1366	" " (front)
16511	1349	" Shaft
*11104	——	" " Bushing (front)
12357	767	" " Flanged Bushing (back)

NO.	PLATE	NAME
448c	783	Arm Shaft Flanged Bushing (back) Set Screw
144D	782	Arm Shaft Screw
12193	2004	" Side Cover
286D	783	" " " Thumb Screw
12403	772	" Spool Pin and Thread Eyelet
11241	2003	" " " Washer (cloth)
24296	1348	Balance Wheel (power) light rim, $2\frac{3}{16}$ in. pulley, with two 448c
24297	1340	Balance Wheel Oil Cover
210D	1343	" " " " Screw
448c	783	" " Set Screw
*24470	——	Bed
20197	1350	Crank Connecting Rod with 20198 and two 896E
*20198	——	Crank Connecting Rod Cap
896E	773	" " " " Screw
908c	773	" " " Hinge Screw
1619E	773	" " " " " Nut.
19354	——	Face Plate
19355	1311	Face Plate complete, Nos. 2827, 12150 and 19354
219D	774	Face Plate Screw
44181	——	" " Thread Guard (lower)
12150	773	" " " " " 44181 with 12152
12152	773	Face Plate Thread Guard (lower) Rivet
2827	773	" " " " (upper) with 8505
8505	773	" " " " " Rivet
12368	767	Feed Bar (lower)
313c	783	" " " Screw Centre
56813	——	" " " " " 313c with 1519J
1519J	783	Feed Bar (lower) Screw Centre Nut
24471	2688	" " (upper)
19367	1313	" " " Cap
199D	1312	" " " " Screw for 24901
219D	774	" " " " " " 19367
3033	770	" Connecting Link
375c	782	" " " Hinge Screw
1518E	783	" " " " " Nut.
24344	1267	" Dog
208E	782	" " Screw
20283	1315	" and Feed Lifting Eccentric with 446c
446c	783	" " " " " Set Screw
24036	1340	" " " " " Sleeve
20284	1350	" Forked Connection

NO.	PLATE	NAME
375C	782	Feed Forked Connection Hinge Screw...
1518E	783	" " " " " Nut
24969	2551	" Lifting Rock Shaft.....
24970	——	Feed Lifting Rock Shaft complete, Nos. 12376 and 24969.....
12376	770	Feed Lifting Rock Shaft Crank with 157J and 1813.....
157J	782	Feed Lifting Rock Shaft Crank Clamping Screw.....
1813	783	Feed Lifting Rock Shaft Crank Roller and Stud.....
43976	2551	Feed Lifting Rock Shaft Crank Connecting Rod with 43977 and two 966E.....
*43977	——	Feed Lifting Rock Shaft Crank Connecting Rod Cap.....
966E	5806	Feed Lifting Rock Shaft Crank Connecting Rod Cap Screw.....
375C	782	Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw.....
1518E	783	Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw Nut.....
307C	783	Feed Lifting Rock Shaft Screw Centre...
56814	——	" " " " " " 307C with 1513J.....
1513J	783	Feed Lifting Rock Shaft Screw Centre Nut
3039	768	" Regulator.....
1128E	2009	" " Hinge Screw.....
818D	783	" " Thumb Screw.....
24472	2687	" Rock Shaft.....
24473	——	Feed Rock Shaft complete, Nos. 20247, 24472 and 29633.....
29633	1354	Feed Rock Shaft Crank with 157J.....
157J	782	" " " " Clamping Screw.
307C	783	" " " Screw Centre.....
56814	——	" " " " " 307C with 1513J.....
1513J	783	Feed Rock Shaft Screw Centre Nut.....
24549	8379	" (upper) Shaft.....
20249	2687	" " " Bracket (back).....
134D	2688	" " " " " Screw
24475	2687	" " " " (front).....
171D	2688	" " " " " Screw
20251	2688	" " " Collar with 456C.....
456C	2688	" " " " Set Screw.....
20254	2687	Feed (upper) Shaft Crank (back) with 191C.....

NO.	PLATE	NAME
2049	773	Feed (upper) Shaft Crank (back) Pin....
191c	1366	" " " " " Set Screw
24476	2687	" " " " (front) with two 460c and four 454c.....
62674	——	Feed (upper) Shaft Crank (front) 24476 with 24477 and 24479.....
24477	2687	Feed (upper) Shaft Crank (front) Connection.....
24550	8375	Feed (upper) Shaft Crank (front) Connection Hinge Pin.....
1019F	2688	Feed (upper) Shaft Crank (front) Connection Hinge Pin Set Screw.....
24479	2688	Feed (upper) Shaft Crank (front) Hinge Pin.....
460c	2688	Feed (upper) Shaft Crank (front) Hinge Pin Set Screw.....
454c	2688	Feed (upper) Shaft Crank (front) Set Screw.....
20247	2687	Feed (upper) Shaft Regulator Crank with 1518E, 1942 and two 190D.....
190D	2688	Feed (upper) Shaft Regulator Crank Clamping Screw.....
1904	770	Feed (upper) Shaft Regulator Crank Roller (roller only).....
1942	2688	Feed (upper) Shaft Regulator Crank Roller and Screw Stud with 229D, 1904 and 12424.....
1518E	2688	Feed (upper) Shaft Regulator Crank Roller and Screw Stud Nut.....
229D	2688	Feed (upper) Shaft Regulator Crank Roller Cap Screw.....
12424	2688	Feed (upper) Shaft Regulator Crank Roller Cap Screw Washer.....
24480	2688	Feeding Foot, 16 teeth to the inch, with two 1019F.....
24725	8375	Feeding Foot, 36 teeth to the inch, with two 1019F.....
217D	2688	Feeding Foot Screw.....
12391	767	Lifting Presser Bar (hollow).....
19356	1312	" " " Bell Crank.....
199D	1312	" " " " " Cap Screw
19357	1312	" " " " " Connecting Link.....
199D	1312	Lifting Presser Bar Bell Crank Connecting Link Cap Screw.....
24351	1354	Lifting Presser Bar Bell Crank Driving Arm.....

NO.	PLATE	NAME
19362	1313	Lifting Presser Bar Bell Crank Driving Arm Eccentric Connection.....
375c	782	Lifting Presser Bar Bell Crank Driving Arm Eccentric Connection Hinge Screw
1518e	783	Lifting Presser Bar Bell Crank Driving Arm Eccentric Connection Hinge Screw Nut.....
2049	773	Lifting Presser Bar Bell Crank Driving Arm Pin.....
19359	1312	Lifting Presser Bar Bell Crank Driving Arm Shaft.....
19360	1311	Lifting Presser Bar Bell Crank Driving Arm Shaft Bracket.....
24352	——	Lifting Presser Bar Bell Crank Driving Arm Shaft Bracket complete, Nos. 2049, 19359, 19360 and 24351.....
965d	1312	Lifting Presser Bar Bell Crank Driving Arm Shaft Bracket Screw.....
24589	5736	Lifting Presser Bar Guide Bracket with 453c.....
24901	——	Lifting Presser Bar Guide Bracket 24589 with 19356, 19357, 24471 and three 199d
453c	783	Lifting Presser Bar Guide Bracket Set Screw.....
24590	5736	Lifting Presser Bar Guide Bracket Support
175d	5736	" " " " " " Screw.....
20240	8375	Lifting Presser Bar Lifter.....
689c	782	" " " " Screw.....
1520e	783	" " " " " Nut....
12327	770	" " " Lifting and Releasing Lever Bracket.....
11167	767	Lifting Presser Bar Spring (light) .051 wire.....
		NOTE: No. 11167 is sent with this Machine unless another Spring is specified on order.
12139	2004	Lifting Presser Bar Spring (medium) .055 wire.....
20023	2004	Lifting Presser Bar Spring (heavy) .063 wire.....
11170	771	Lifting Presser Bar Spring Washer.....
24481	2688	" " Foot.....
193d	2688	" " " Screw.....
19229	2004	Needle Bar (hollow) for high lift.....
12382	770	" " Connecting Link with 794e..

NO.	PLATE	NAME
794E	782	Needle Bar Connecting Link Adjusting Screw
*12383	——	Needle Bar Connecting Stud
1904	770	" " " " Roller (roller only)
453C	783	Needle Bar Connecting Stud Set Screw
12384	770	Needle Bar Connecting Stud complete, Nos. 453C, 1904 and 12383
19365	1311	Needle Bar Crank and Lifting Eccentric with 448C and 743C
743C	1313	Needle Bar Crank and Lifting Eccentric Position Screw
448C	783	Needle Bar Crank and Lifting Eccentric Set Screw
936E	773	Needle Bar Screw Bushing
24101	——	" Clamp Body
808F	782	" " Screw
24102	1353	" " Thread Guide
651D	1353	" " " " Screw
24103	1353	Needle Clamp (high lift) complete, Nos. 651D, 808F, 24101 and 24102
24104	1350	Oscillating Rock Shaft
24105	——	Oscillating Rock Shaft complete, Nos. 4784, 12388 and 24104
12388	767	Oscillating Rock Shaft Hinge Pin
878J	783	" " " " " Oil Hole Stop Screw
12459	773	Oscillating Rock Shaft Hinge Pin Oil Hole Stop Screw Washer (leather)
448C	783	Oscillating Rock Shaft Hinge Pin Set Screw
4784	1353	Oscillating Rock Shaft Oil Pad
16509	766	" Shaft
19496	——	" " Crank for 19447
44134	——	" " " " 44135
19447	1353	Oscillating Shaft Crank complete, Nos. 457C, 1518E, 19449 and 19496
44135	5806	Oscillating Shaft Crank complete, Nos. 1518E, 19449, 44134 and two 453C
2049	773	Oscillating Shaft Crank Pin
457C	783	" " " Set Screw for 19447
453C	783	" " " " " " 44135
19448	1353	" " " Slide Block
229D	782	" " " " " Cap Screw
12424	773	Oscillating Shaft Crank Slide Block Cap Screw Washer

NO.	PLATE	NAME
988c	1353	Oscillating Shaft Crank Slide Block Screw Stud
1518e	783	Oscillating Shaft Crank Slide Block Screw Stud Nut
19449	1353	Oscillating Shaft Crank Slide Block complete, Nos. 229d, 988c, 12424 and 19448
688j	783	Pressure Regulating Thumb Screw
2996	771	Shuttle Bobbin
15140	1353	" " Case Latch
2973	771	" " " " Lever
2974	771	" " " " " Fulcrum Pin
2975	771	Shuttle Bobbin Case Latch Spring
592e	782	" " " " Stop Screw
15141	——	Shuttle Bobbin Case Hinge, Nos. 2973, 2974 and 15140
7553	771	Shuttle Bobbin Case Position Finger
2523	771	" " " " " Rivet
24412	1361	" " " " Plate
391d	1366	" " " " " Screw
24074	771	Shuttle Bobbin Case complete, Nos. 591f, 592e, 2523, 2975, 7553, 15098 and 15141
12393	771	Shuttle Body
591f	782	" Tension Regulating Screw
15098	771	" " Spring
19292	771	Shuttle, $1\frac{11}{16}$ in. diam., Nos. 2996, 12393 and 24074
*12394	——	Shuttle Driver
12444	771	" " 12394 with two 1266c
2049	773	" " Pin
1266c	5806	" " Set Screw
2531	767	" Race Back
2532	772	" " " Position Pin
2533	767	" " " Spring
907d	782	" " " " Screw
24413	——	" " Body
25000	——	" " " 24413 with 24414 and two 1053d
24414	1362	Shuttle Race Cap
1053d	2006	" " " Screw
24415	1361	Shuttle Race complete, Nos. 907d, 2531, 2533, 24412, 25000 and two each 391d and 2532
145d	782	Shuttle Race Screw
12431	——	" " Slide
12432	2004	Shuttle Race Slide complete, Nos. 4307, 12431 and two 725e

NO.	PLATE	NAME
4307	772	Shuttle Race Slide Spring
725E	1387	" " " " Screw
2102	5806	Tension Disc
1560C	783	" Regulating Thumb Nut
32572	5806	" Releasing Disc
43944	5806	" " Lever
12398	773	" " " Hinge Pin
12329	772	" " " Spring
32574	5806	" " Pin
50327C	5806	" Screw Stud
44141	——	" " " 50327c with 1560c
43945	5806	" Spring
12149	2014	" Thread Guard
44118	——	Tension complete, Nos. 7336, 32572, 32574, 43945, 43946, 44141 and two 2102
52454	5842	Thread Retainer
50429C	——	" " Set Screw
12404	770	" Take-up Crank
3094	773	" " " Wedge
690E	782	" " " " Screw
12408	770	" " Lever
775E	782	" " " Cap Screw
12166	773	" " " Hinge Pin
12409	770	" " " Link
11204	770	" " " " Hinge Pin
435C	5806	" " " " " " Set Screw
12410	——	Thread Take-up Lever complete, Nos. 12166, 12408 and 12409
43946	5806	Thread Take-up Spring
7336	772	" " " Regulator
448C	783	" " " " Set Screw
24353	1267	Throat Plate, large needle hole, for 24344
24354	——	" " small needle hole, for 24344
691F	782	" " Screw
24079	2644	Drip Pan with four 1 in. wire nails

LIST OF PARTS COMPLETE

FOR

MACHINE No. 44-74

FOR REPAIRING BELTS IN COTTON MILLS, ETC. HAS HAND DRIVING ATTACHMENT, DROP FEED.

NO.	PLATE	NAME
*16501	——	Arm with 11104
8582	773	" Dowel Pin
12453	773	" Oil Tube for intermediate bearing
12454	773	" " " with 29599, for oiling 12409
11119	773	" " " " " " " 12408
24131	2014	" " " " " " " 20283
29599	2014	" " " Packing (felt)
748E	782	" Screw (back)
868E	1366	" " (front)
16511	1349	" Shaft
*11104	——	" " Bushing (front)
12357	767	" " Flanged Bushing (back)
448C	783	" " " " " Set Screw
144D	782	Arm Shaft Screw
12480	767	" Side Cap
219D	774	" " " Screw
12193	2004	" " Cover
286D	783	" " " Thumb Screw
12403	772	" Spool Pin and Thread Eyelet
11241	2003	" " " Washer (cloth)
4370	1348	Balance Wheel (power) heavy rim, 2¾ in. pulley, with two 448C
24297	1340	Balance Wheel Oil Cover
210D	1343	" " " " Screw
448C	783	" " Set Screw
*16503	——	Bed
20197	1350	Crank Connecting Rod with 20198 and two 896E
*20198	——	Crank Connecting Rod Cap
896E	773	" " " " Screw
908C	773	" " " Hinge Screw
1619E	773	" " " " " Nut
20057	——	Face Plate
20058	1340	Face Plate complete, Nos. 2827, 12150 and 20057

NO.	PLATE	NAME
190D	782	Face Plate Screw
44181	——	" " Thread Guard (lower)
12150	773	" " " " " 44181 with 12152
12152	773	Face Plate Thread Guard (lower) Rivet
2827	773	" " " " (upper) with 8505
8505	773	" " " " " Rivet
286D	783	" " Thumb Screw
12368	767	Feed Bar
313C	783	" " Screw Centre
56813	——	" " " " 313C with 1519J
1519J	783	" " " " Nut
3033	770	" Connecting Link
375C	782	" " " Hinge Screw
1518E	783	" " " " " Nut
12369	776	" Dog, 12 teeth (12 teeth to the inch)
208E	782	" " Screw
20283	1315	" and Feed Lifting Eccentric with 446C
446C	783	" " " " " Set Screw
24036	1340	" " " " " Sleeve
20284	1350	" Forked Connection
375C	782	" " " Hinge Screw
1518E	783	" " " " " Nut
24969	2551	" Lifting Rock Shaft
24970	——	Feed Lifting Rock Shaft complete, Nos. 12376 and 24969
12376	770	Feed Lifting Rock Shaft Crank with 157J and 1813
157J	782	Feed Lifting Rock Shaft Crank Clamping Screw
1813	783	Feed Lifting Rock Shaft Crank Roller and Stud
43976	2551	Feed Lifting Rock Shaft Crank Connecting Rod with 43977 and two 966E
*43977	——	Feed Lifting Rock Shaft Crank Connecting Rod Cap
966E	5806	Feed Lifting Rock Shaft Crank Connecting Rod Cap Screw
375C	782	Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw
1518E	783	Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw Nut
307C	783	Feed Lifting Rock Shaft Screw Centre
56814	——	" " " " " " 307C with 1513J
1513J	783	Feed Lifting Rock Shaft Screw Centre Nut
3039	768	" Regulator

NO.	PLATE	NAME
1128E	2009	Feed Regulator Hinge Screw
818D	783	" " Thumb Screw
16506	766	" Rock Shaft
24376	——	Feed Rock Shaft complete, Nos. 16506 and 29633
29633	1354	Feed Rock Shaft Crank with 157J
157J	782	" " " " Clamping Screw
307C	783	" " " Screw Centre
56814	——	" " " " " 307C with 1513J
1513J	783	Feed Rock Shaft Screw Centre Nut
94002	8377	Hand Attachment Body
24797	8377	" " " Bracket with 453C
183D	8378	" " " " Screw
80023	8377	" " Crank Handle (wood)
94012	8377	" " " " Spindle
8280	8378	" " " Hinge Pin
8435	8377	" " " Lever
94005	——	Hand Attachment Crank complete, Nos. 8435, 80023 and 94012
8281	8378	Hand Attachment Crank Lock Pin
8282	8378	" " " " " Spring
8313	8377	" " Driver
62632	——	Hand Attachment Driver 8313 with 240B, 8285, 8286 and 24798
62676	——	Hand Attachment Driver 62632 with 2532 and 8394
24798	8378	Hand Attachment Driver Finger
8285	8378	" " " " Hinge Pin
8286	8378	" " " " Lock Spring
240B	8378	Hand Attachment Driver Finger Lock Spring Screw
8392	8377	Hand Attachment Gear with 8281 and 8282
94011	8377	Hand Attachment Gear Cover
211A	8378	" " " " Screw
659D	8378	" " " Screw Stud
8394	8378	" " Pinion
2532	8378	" " " Dowel Pin
660D	8378	" " " Screw Stud
15072	2014	Bobbin Winder Bobbin Position Pin
24799	8377	" " Frame
24800	——	Bobbin Winder Frame complete, Nos. 333D, 5960, 5961, 5963, 24799 and 24802

NO.	PLATE	NAME
24801	8378	Bobbin Winder Frame Hinge Stud....
453c	8378	" " " " " Set Screw.....
5960	768	Bobbin Winder Friction Wheel (leather)..
5961	768	" " " " Washer....
333D	8378	" " " " " Screw
24802	8378	" " Spindle with 15072.....
5963	768	" " " Flange.....
24803	8377	" " Stop Latch.....
24804	8377	" " " " Arm with 453c
453c	8378	" " " " " Set Screw
1317D	8378	" " " " " Thumb Screw.....
32D	8378	Bobbin Winder Stop Latch Hinge Screw...
24805	8378	" " Tension Bracket.....
2455	8378	" " " Disc.....
15367	8378	" " " " Spring.....
2457	8378	" " " " Stud.....
24806	8378	Bobbin Winder Tension Bracket complete, Nos. 2455, 2457, 15367 and 24805.....
205D	8378	Bobbin Winder Tension Bracket Screw...
*62587	——	Hand Attachment complete with Bobbin Winder, Nos. 32D, 659D, 660D, 1317D, 8280, 8392, 24797, 24800, 24801, 24803, 24804, 62676, 94002, 94005, 94011 and two each 183D and 211A.....
24807	——	Hand Attachment complete with Bobbin Winder, Nos. 205D, 692D, 24806 and 62587.....
692D	783	Hand Attachment Screw.....
12381	767	Needle Bar (hollow).....
12382	770	" " Connecting Link with 794E..
794E	782	" " " " Adjusting Screw.....
*12383	——	Needle Bar Connecting Stud.....
1904	770	" " " " Roller (roller only).....
453c	783	Needle Bar Connecting Stud Set Screw...
12384	770	Needle Bar Connecting Stud complete, Nos. 453c, 1904 and 12383.....
20188	767	Needle Bar Crank with 858c and 1065c..
1065c	1366	" " " Position Screw.....
858c	783	" " " Set Screw.....
936E	773	" " Screw Bushing.....
4302	773	" " Thread Guard.....
233D	782	" " " " Screw.....
4303	773	" Clamp with 808F.....

NO.	PLATE	NAME
808F	782	Needle Clamp Screw
24104	1350	Oscillating Rock Shaft
24105	——	Oscillating Rock Shaft complete, Nos. 4784, 12388 and 24104
12388	767	Oscillating Rock Shaft Hinge Pin
878J	783	" " " " " Oil Hole Stop Screw
12459	773	Oscillating Rock Shaft Hinge Pin Oil Hole Stop Screw Washer (leather)
448C	783	Oscillating Rock Shaft Hinge Pin Set Screw
4784	1353	Oscillating Rock Shaft Oil Pad
16509	766	" Shaft
19496	——	" " Crank for 19447
44134	——	" " " " 44135
19447	1353	Oscillating Shaft Crank complete, Nos. 457C, 1518E, 19449 and 19496
44135	5806	Oscillating Shaft Crank complete, Nos. 1518E, 19449, 44134 and two 453C
2049	773	Oscillating Shaft Crank Pin
457C	783	" " " Set Screw for 19447
453C	783	" " " " " " 44135
19448	1353	" " " Slide Block
229D	782	" " " " " Cap Screw
12424	773	Oscillating Shaft Crank Slide Block Cap Screw Washer
988C	1353	Oscillating Shaft Crank Slide Block Screw Stud
1518E	783	Oscillating Shaft Crank Slide Block Screw Stud Nut
19449	1353	Oscillating Shaft Crank Slide Block complete, Nos. 229D, 988C, 12424 and 19448
12391	767	Presser Bar (hollow)
20059	1341	" " Guide Bracket with 453C
453C	783	" " " " Set Screw
2062	771	" " Lifter
689C	782	" " " Screw
1520E	783	" " " " Nut
12327	770	" " Lifting and Releasing Lever Bracket
11167	767	Presser Bar Spring (light) .051 wire
		NOTE: No. 11167 is sent with this Machine unless another Spring is specified on order.
12139	2004	Presser Bar Spring (medium) .055 wire
20023	2004	" " " (heavy) .063 wire
11170	771	" " " Washer

NO.	PLATE	NAME
12143	780	Presser Foot for 12369
190D	782	" " Screw
688J	783	Pressure Regulating Thumb Screw
19131	5737	Shuttle Bobbin
20649	5737	" " Case Latch
2973	5737	" " " " Lever
2974	5737	" " " " " Fulcrum Pin
2975	5737	Shuttle Bobbin Case Latch Spring
592E	5737	" " " " Stop Screw
20650	——	Shuttle Bobbin Case Hinge, Nos. 2973, 2974 and 20649
20755	5737	Shuttle Bobbin Case Position Finger
2523	5737	" " " " " Rivet
24323	2046	" " " " Plate
391D	1366	" " " " " Screw
20756	5737	Shuttle Bobbin Case complete, Nos. 591F, 592E, 2523, 2975, 20650, 20654 and 20755
20757	5737	Shuttle Body
591F	5737	" Tension Regulating Screw
20654	5737	" " Spring
20758	5737	Shuttle, $1\frac{11}{16}$ in. diam., Nos. 19131, 20756 and 20757
19406	2012	Shuttle Driver with two 1266C
2049	773	" " Pin
1266C	5806	" " Set Screw
2419	2006	" Race Back
2532	772	" " " Position Pin
2533	767	" " " Spring
907D	782	" " " " Screw
24324	——	" " Body
24998	——	" " " 24324 with 24009 and two 1053D
24009	2006	Shuttle Race Cap
1053D	2006	" " " Screw
24325	2046	Shuttle Race complete, Nos. 907D, 2419, 2533, 24323, 24998 and two each 391D and 2532
145D	782	Shuttle Race Screw
12431	——	" " Slide
12432	2004	Shuttle Race Slide complete, Nos. 4307, 12431 and two 725E
4307	772	Shuttle Race Slide Spring
725E	1387	" " " " Screw
20060	1311	Slack Thread Regulator
225F	1323	" " " Adjusting Screw

NO.	PLATE	NAME
2102	5806	Tension Disc
1560c	783	" Regulating Thumb Nut
32572	5806	" Releasing Disc
43944	5806	" " Lever
12398	773	" " " Hinge Pin
12329	772	" " " Spring
32574	5806	" " Pin
50327c	5806	" Screw Stud
44141	——	" " " 50327c with 1560c
43945	5806	" Spring
44118	——	Tension complete, Nos. 7336, 32572, 32574, 43945, 43946, 44141 and two 2102
52454	5842	Thread Retainer
50429c	——	" " Set Screw
12404	770	" Take-up Crank
3094	773	" " " Wedge
690e	782	" " " " Screw
12408	770	" " Lever
775e	782	" " " Cap Screw
12166	773	" " " Hinge Pin
12409	770	" " " Link
11204	770	" " " " Hinge Pin
435c	5806	" " " " " " Set Screw
12410	——	Thread Take-up Lever complete, Nos. 12166, 12408 and 12409
43946	5806	Thread Take-up Spring
7336	772	" " " Regulator
448c	783	" " " " Set Screw
12411	776	Throat Plate, large needle hole, for 12369

NOTE: No. 12411 is sent with this Machine unless another Throat Plate is specified on order.

12449	——	Throat Plate, small needle hole, for 12369
691f	782	" " Screw
24079	2644	Drip Pan with four 1 in. wire nails

LIST OF PARTS COMPLETE
FOR
MACHINE No. 44-75

FOR BANDING APRONS, ETC. HAS POSITIVE RUFFLING MECHANISM AND FOLDER. FOR FOLDING THE BAND, INSERTING AND FULLING IN THE BODY OF THE GARMENT IN ONE OPERATION. DROP FEED.

NO.	PLATE	NAME
*62548	——	Arm with 11104
8582	773	" Dowel Pin
12453	773	" Oil Tube for intermediate bearing
12454	773	" " " with 29599, for oiling 12409
11119	773	" " " " " " " 12408
24131	2014	" " " " " " " 20283
29599	2014	" " " Packing (felt)
748E	782	" Screw (back)
868E	1366	" " (front)
16511	1349	" Shaft
*11104	——	" " Bushing (front)
12357	767	" " Flanged Bushing (back)
448C	783	" " " " " Set Screw
144D	782	Arm Shaft Screw
12193	2004	" Side Cover
286D	783	" " " Thumb Screw
12403	772	" Spool Pin and Thread Eyelet
11241	2003	" " " Washer (cloth)
24296	1348	Balance Wheel (power) light rim, $2\frac{3}{16}$ in. pulley, with two 448C
24297	1340	Balance Wheel Oil Cover
210D	1343	" " " " Screw
448C	783	" " Set Screw
*24470	——	Bed
20197	1350	Crank Connecting Rod with 20198 and two 896E
*20198	——	Crank Connecting Rod Cap
896E	773	" " " " Screw
908C	773	" " " Hinge Screw
1619E	773	" " " " " Nut
19354	——	Face Plate
19355	1311	Face Plate complete, Nos. 2827, 12150 and 19354

NO.	PLATE	NAME
219D	774	Face Plate Screw
44181	——	" " Thread Guard (lower)
12150	773	" " " " " 44181 with 12152
12152	773	Face Plate Thread Guard (lower) Rivet
2827	773	" " " " (upper) with 8505
8505	773	" " " " " Rivet
12368	767	Feed Bar (lower)
313C	783	" " " Screw Centre
56813	——	" " " " " 313c with 1519J
1519J	783	Feed Bar (lower) Screw Centre Nut
24471	2688	" " (upper)
19367	1313	" " " Cap
199D	1312	" " " " Screw for 24901
219D	774	" " " " " " 19367
3033	770	" Connecting Link
375C	782	" " " Hinge Screw
1518E	783	" " " " " Nut
62549	8376	" Dog
208E	782	" " Screw
20283	1315	" and Feed Lifting Eccentric with 446c
446C	783	" " " " " Set Screw
24036	1340	" " " " " Sleeve
20284	1350	" Forked Connection
375C	782	" " " Hinge Screw
1518E	783	" " " " " Nut
24969	2551	" Lifting Rock Shaft
24970	——	Feed Lifting Rock Shaft complete, Nos. 12376 and 24969
12376	770	Feed Lifting Rock Shaft Crank with 157J and 1813
157J	782	Feed Lifting Rock Shaft Crank Clamping Screw
1813	783	Feed Lifting Rock Shaft Crank Roller and Stud
43976	2551	Feed Lifting Rock Shaft Crank Connecting Rod with 43977 and two 966E
*43977	——	Feed Lifting Rock Shaft Crank Connect-Rod Cap
966E	5806	Feed Lifting Rock Shaft Crank Connect-Rod Cap Screw
375C	782	Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw
1518E	783	Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw Nut

NO.	PLATE	NAME
307c	783	Feed Lifting Rock Shaft Screw Centre...
56814	——	" " " " " " 307c with 1513J.....
1513J	783	Feed Lifting Rock Shaft Screw Centre Nut
3039	768	" Regulator.....
1128E	2009	" " Hinge Screw.....
818D	783	" " Thumb Screw.....
24472	2687	" Rock Shaft.....
24473	——	Feed Rock Shaft complete, Nos. 20247, 24472 and 29633.....
29633	1354	Feed Rock Shaft Crank with 157J.....
157J	782	" " " " Clamping Screw.
307c	783	" " " Screw Centre.....
56814	——	" " " " " 307c with 1513J.....
1513J	783	Feed Rock Shaft Screw Centre Nut.....
62599	8379	" (upper) Shaft.....
20249	2687	" " " Bracket.....
134D	2688	" " " " Screw.....
20251	2688	" " " Collar with 456c.....
456c	2688	" " " " Set Screw.....
20254	2687	" " " Crank (back) with 191c
2049	773	" " " " " Pin.....
191c	1366	" " " " " Set Screw
62615	8379	" " " " (front) with four 454c.....
62550	8379	Feed (upper) Shaft Crank (front) Connection with two 452c.....
62551	8380	Feed (upper) Shaft Crank (front) Connection Hinge Pin.....
460c	2688	Feed (upper) Shaft Crank (front) Connection Hinge Pin Set Screw.....
452c	8380	Feed (upper) Shaft Crank (front) Connection Set Screw.....
24479	2688	Feed (upper) Shaft Crank (front) Hinge Pin.....
454c	2688	Feed (upper) Shaft Crank (front) Set Screw.....
20247	2687	Feed (upper) Shaft Regulator Crank with 1518E, 1942 and two 190D.....
190D	2688	Feed (upper) Shaft Regulator Crank Clamping Screw.....
1904	770	Feed (upper) Shaft Regulator Crank Roller (roller only).....
1942	2688	Feed (upper) Shaft Regulator Crank Roller and Screw Stud with 229D, 1904 and 12424.....

NO.	PLATE	NAME
1518E	2688	Feed (upper) Shaft Regulator Crank Roller and Screw Stud Nut.....
229D	2688	Feed (upper) Shaft Regulator Crank Roller Cap Screw.....
12424	2688	Feed (upper) Shaft Regulator Crank Roller Cap Screw Washer.....
62552	8380	Feeding Foot (upper) with two 460C.....
217D	2688	" " Screw.....
12391	767	Lifting Presser Bar (hollow).....
19356	1312	" " " Bell Crank.....
199D	1312	" " " " " Cap Screw.
19357	1312	" " " " " Connecting Link.....
199D	1312	Lifting Presser Bar Bell Crank Connecting Link Cap Screw.....
24351	1354	Lifting Presser Bar Bell Crank Driving Arm.....
62553	8379	Lifting Presser Bar Bell Crank Driving Arm Eccentric Connection .....
375C	782	Lifting Presser Bar Bell Crank Driving Arm Eccentric Connection Hinge Screw
1518E	783	Lifting Presser Bar Bell Crank Driving Arm Eccentric Connection Hinge Screw Nut.....
2049	773	Lifting Presser Bar Bell Crank Driving Arm Pin.....
19359	1312	Lifting Presser Bar Bell Crank Driving Arm Shaft.....
62554	8379	Lifting Presser Bar Bell Crank Driving Arm Shaft Bracket.....
62555	——	Lifting Presser Bar Bell Crank Driving Arm Shaft Bracket complete, Nos. 2049, 19359, 24351 and 62554.....
965D	1312	Lifting Presser Bar Bell Crank Driving Arm Shaft Bracket Screw.....
24589	5736	Lifting Presser Bar Guide Bracket with 453C.....
24901	——	Lifting Presser Bar Guide Bracket 24589 with 19356, 19357, 24471 and three 199D
453C	783	Lifting Presser Bar Guide Bracket Set Screw.....
62600	8379	Lifting Presser Bar Guide Bracket Support
175D	5736	" " " " " " Screw.....
62556	8376	Lifting Presser Bar Lifter.....
689C	782	" " " " Screw.....
1520E	783	" " " " " Nut....

NO.	PLATE	NAME
12327	770	Lifting Presser Bar Lifting and Releasing Lever Bracket.....
11167	767	Lifting Presser Bar Spring (light) .051 wire
		NOTE: No. 11167 is sent with this Machine unless another Spring is specified on order.
12139	2004	Lifting Presser Bar Spring (medium) .055 wire.....
20023	2004	Lifting Presser Bar Spring (heavy) .063 wire.....
11170	771	Lifting Presser Bar Spring Washer.....
62557	8380	" " Foot.....
190D	782	" " " Screw.....
19229	2004	Needle Bar (hollow) for high lift.....
12382	770	" " Connecting Link with 794E..
794E	782	" " " " Adjusting Screw.....
*12383	——	Needle Bar Connecting Stud.....
1904	770	" " " " Roller (roller only).....
453C	783	Needle Bar Connecting Stud Set Screw...
12384	770	Needle Bar Connecting Stud complete, Nos. 453C, 1904 and 12383.....
62558	8379	Needle Bar Crank and Lifting Eccentric with 448C and 743C.....
743C	1313	Needle Bar Crank and Lifting Eccentric Position Screw.....
448C	783	Needle Bar Crank and Lifting Eccentric Set Screw.....
936E	773	Needle Bar Screw Bushing.....
24101	——	" Clamp Body.....
808F	782	" " Screw.....
24102	1353	" " Thread Guide.....
651D	1353	" " " " Screw.....
24103	1353	Needle Clamp (high lift) complete, Nos. 651D, 808F, 24101 and 24102.....
24104	1350	Oscillating Rock Shaft.....
24105	——	Oscillating Rock Shaft complete, Nos. 4784, 12388 and 24104.....
12388	767	Oscillating Rock Shaft Hinge Pin.....
878J	783	" " " " " Oil Hole Stop Screw.....
12459	773	Oscillating Rock Shaft Hinge Pin Oil Hole Stop Screw Washer (leather).....
448C	783	Oscillating Rock Shaft Hinge Pin Set Screw.....

NO.	PLATE	NAME
4784	1353	Oscillating Rock Shaft Oil Pad.....
16509	766	" Shaft.....
19496	——	" " Crank for 19447.....
44134	——	" " " " 44135.....
19447	1353	Oscillating Shaft Crank complete, Nos. 457c, 1518e, 19449 and 19496.....
44135	5806	Oscillating Shaft Crank complete, Nos. 1518e, 19449, 44134 and two 453c.....
2049	773	Oscillating Shaft Crank Pin.....
457c	783	" " " Set Screw for 19447
453c	783	" " " " " " 44135
19448	1353	" " " Slide Block.....
229d	782	" " " " " Cap Screw.....
12424	773	Oscillating Shaft Crank Slide Block Cap Screw Washer.....
988c	1353	Oscillating Shaft Crank Slide Block Screw Stud.....
1518e	783	Oscillating Shaft Crank Slide Block Screw Stud Nut.....
19449	1353	Oscillating Shaft Crank Slide Block complete, Nos. 229d, 988c, 12424 and 19448
688j	783	Pressure Regulating Thumb Screw.....
62559	8380	Ruffling Blade.....
22356	8380	" " Holder.....
226d	1344	" " " Cap Screw.....
22357	8380	" " " Hinge Stud.....
1550j	1344	" " " " " Nut...
24204	1344	" " " Spring.....
22361	8380	" " " " Stop.....
62560	8379	" Lever.....
62561	8380	" " Stud (eccentric).....
62562	8380	" " " Collar with two 465c
465c	783	" " " " Set Screw....
1701c	8380	" " " Nut.....
62563	8379	" Regulator.....
62564	8379	" " Bracket.....
171d	8380	" " " Screw (long)
971d	8380	" " " " (short)
62565	8379	" " Crank with two 453c
62566	8379	" " " Connecting Rod
61f	8380	" " " " " Hinge Screw (lower).....
1520e	783	Ruffling Regulator Crank Connecting Rod Hinge Screw (lower) Nut.....
50402c	8380	Ruffling Regulator Crank Connecting Rod Hinge Screw (upper).....

NO.	PLATE	NAME
1520E	783	Ruffling Regulator Crank Connecting Rod Hinge Screw (upper) Nut
453C	783	Ruffling Regulator Crank Set Screw
50403D	8380	" " Thumb Screw
1749C	8380	" " " " Nut
62567	8380	" " " " Sleeve
62568	8380	" " " " Washer
62569	8380	" Smoothing Blade
665D	1344	" " " Screw
2996	771	Shuttle Bobbin
15140	1353	" " Case Latch
2973	771	" " " " Lever
2974	771	" " " " " Fulcrum Pin
2975	771	Shuttle Bobbin Case Latch Spring
592E	782	" " " " Stop Screw
15141	——	Shuttle Bobbin Case Hinge, Nos. 2973, 2974 and 15140
7553	771	Shuttle Bobbin Case Position Finger
2523	771	" " " " " Rivet
24412	1361	" " " " Plate
391D	1366	" " " " " Screw
24074	771	Shuttle Bobbin Case complete, Nos. 591F, 592E, 2523, 2975, 7553, 15098 and 15141
12393	771	Shuttle Body
591F	782	" Tension Regulating Screw
15098	771	" " Spring
19292	771	Shuttle, $1\frac{11}{16}$ in. diam., Nos. 2996, 12393 and 24074
*12394	——	Shuttle Driver
12444	771	" " 12394 with two 1266C
2049	773	" " Pin
1266C	5806	" " Set Screw
2531	767	" Race Back
2532	772	" " " Position Pin
2533	767	" " " Spring
907D	782	" " " " Screw
24413	——	" " Body
25000	——	" " " 24413 with 24414 and two 1053D
24414	1362	Shuttle Race Cap
1053D	2006	" " " Screw
24415	1361	Shuttle Race complete, Nos. 907D, 2531, 2533, 24412, 25000 and two each 391D and 2532
145D	782	Shuttle Race Screw
12431	——	" " Slide

NO.	PLATE	NAME
12432	2004	Shuttle Race Slide complete, Nos. 4307, 12431 and two 725E
4307	772	Shuttle Race Slide Spring
725E	1387	" " " " Screw
2102	5806	Tension Disc
1560C	783	" Regulating Thumb Nut
32572	5806	" Releasing Disc
43944	5806	" " Lever
12398	773	" " " Hinge Pin
12329	772	" " " Spring
32574	5806	" " Pin
50327C	5806	" Screw Stud
44141	——	" " " 50327C with 1560C
43945	5806	" Spring
12149	2014	" Thread Guard
44118	——	Tension complete, Nos. 7336, 32572, 32574, 43945, 43946, 44141 and two 2102
52454	5842	Thread Retainer
50429C	——	" " Set Screw
12404	770	" Take-up Crank
3094	773	" " " Wedge
690E	782	" " " " Screw
12408	770	" " Lever
775E	782	" " " Cap Screw
12166	773	" " " Hinge Pin
12409	770	" " " Link
11204	770	" " " " Hinge Pin
435C	5806	" " " " " " Set Screw
12410	——	Thread Take-up Lever complete, Nos. 12166, 12408 and 12409
43946	5806	Thread Take-up Spring
7336	772	" " " Regulator
448C	783	" " " " Set Screw
62570	8376	Throat Plate with 62571 and two 1053D, for 62549
691F	782	Throat Plate Screw
62571	8376	" " Separating Blade
1053D	2006	" " " " Screw
24079	2644	Drip Pan with four 1 in. wire nails

IRON BASE

NO.	PLATE	NAME
24106	4761	Bed Frame Cushion (felt)
158E	1206	" " " Screw
24107	4761	" " Hinge Connection

NO.	PLATE	NAME
9261	4761	Bed Frame Hinge Connection Pin.....
970D	4761	" " Thumb Screw.....
24108	3538	Bed Frame with 970D, two each 9261, 24107, four each 158E, 24106 and six wood screws 1¼ in. No. 12.....
24908	8383	Drip Pan with two wood screws ½ in. No. 5 R. H. B.....

ATTACHMENTS AND ACCESSORIES

NO.	PLATE	NAME
687E	5843	Machine Hinge Bolt with 1524E.....
1524E	5843	" " " Nut.....
6055	5843	" " " " Washer.....
12361	772	" " Connection.....
44139	772	" " Plate.....
44140	——	Machine Hinge complete, Nos. 12361, 44139 and wood screw 1¼ in. No. 14.
44180	——	Machine Hinge complete, Nos. 687E, 6055, 12361 and 44139.....
12405	774	Machine Rest (felt).....
28084	——	" " Pin.....
41400	8381	" " " (wood) 3⅛ in. long...
36578	2045	Oiler (copper plated) with 36579.....
36579	2045	" Spout, 3½ in. long, with 120117....
120117	8381	" " Washer (leather).....
26026	2045	Screw Driver (machine).....
26485	2045	" " (shuttle tension).....
35018	2045	Tape Delivery Wire.....
8909	2045	Wrench for 1513, 1517, 1518 and 1524...
4822	2045	" " 1521 and 1528.....
8908	2045	" " 1519, 1520 and 1620.....
19221	2045	" " 936, 1516 and 1619.....
22003	2045	" " 1550 and 1749.....
20461	2045	" " 1582 and 1701.....

BELT GUARD

NO.	PLATE	NAME
41929	8383	Belt Guard.....
8418	5842	" " Button.....
8419	5842	" " " Washer (leather)....
8420	——	" " " 8418 with 8419 and wood screw 1¼ in. No. 9 R. H. B.....
41930	5842	Belt Guard Hinge.....

NO.	PLATE	NAME
41931	——	Belt Guard complete, Nos. 8420, 41929, two 41930 and four wood screws ¾ in. No. 9.....

BINDERS

When ordering Binders, send sample of the binding and the material to be bound.

BINDER (Adjustable)

SIZE 1

NO.	PLATE	NAME
25644	2024	Bed with 25645.....
25645	2024	Folder.....
25646	——	" Guide (lower) with 25855.....
25855	2038	" " " Screw Stud.....
25647	2024	" " (upper).....
1577D	2024	" " " Thumb Nut.....
25648	2024	Pressure Spring.....
334D	2038	" " Screw.....
7071	2021	" " " Washer.....
25650	2024	Binder (adjustable) complete, Nos. 334D, 1577D, 7071, 25644 and 25646 to 25648
190D	782	Binder Screw.....

BINDER (Adjustable)

SIZE 2

This Binder is the same as 25650 with the following exceptions:

NO.	PLATE	NAME
25651	——	Bed with 25652, in place of 25644.....
25652	——	Folder, in place of 25645.....
25653	——	Binder (adjustable) complete, Nos. 334D, 1577D, 7071, 25646 to 25648 and 25651

BINDER (Adjustable)

SIZE 3

This Binder is the same as 25650 with the following exceptions:

NO.	PLATE	NAME
25654	——	Bed with 25655, in place of 25644.....
25655	——	Folder, in place of 25645.....
25656	——	Binder (adjustable) complete, Nos. 334D, 1577D, 7071, 25646 to 25648 and 25654

BINDER (Adjustable)

FOR SOFT HATS

NO.	PLATE	NAME
36456	6254	Bed
36457	6254	Folder with 25669, 36458 and two 7476
36458	6254	" Guide Block
7476	2038	" " " Rivet
25669	——	" Slide with 25670 and 25671
25670	2038	" " Block
25671	2038	" " " Rivet
25672	6254	" " Carrier with 656E
656E	2038	" " " Adjusting Screw
1536D	6254	" " " " Thumb Nut
25673	6254	" " " " " " Guide
401E	2038	Folder Slide Carrier Adjusting Thumb Nut Guide Screw
334D	2038	Folder Slide Carrier Screw
36459	6254	Guide (back, lower)
36460	6254	" (back, upper)
233D	782	" (back) Screw
36461	6254	" (front, lower)
36462	6254	" (front, upper)
233D	782	" (front) Screw
25677	6254	Pressure Spring
334D	2038	" " Screw
36463	6254	Binder (adjustable) complete, Nos. 401E, 1536D, 25672, 25673, 25677, 36456, 36457, 36459 to 36462, two 233D and three 334D
190D	782	Binder Screw
28713	1391	Presser Foot, for soft hat binding

NOTE: Presser Foot No. 28713 is used with, but not included in, No. 36463.

BINDER (Adjustable)

FOR LEATHER BINDING, CANVAS BAGS, LEGGINGS, ETC.

NO.	PLATE	NAME
36340	5807	Bed with two each 1036C and 1266C
36341	5807	Edge Guide
671D	5807	" " Thumb Screw
36342	5807	Guide (lower)
36343	5807	" (upper)
286D	5807	" Thumb Screw
1036C	5806	Leveling Screw (back)

NO.	PLATE	NAME
1266C	5806	Leveling Screw (front)
36344	5807	Binder (adjustable) complete, Nos. 286D, 671D and 36340 to 36343

BINDER (Adjustable)

FOR 44-9 AND 44-23 MACHINES

NO.	PLATE	NAME
24344	1267	Feed Dog
*26951	——	Folder (lower)
*26952	——	" (upper)
26953	1379	Folder with Ribbon Tension complete, Nos. 26951, 26952, two each 193F, 7071 and nine 26486
193F	1379	Folder Screw
7071	1379	" " Washer
26954	1378	Lifting Presser Foot
26486	2022	Ribbon Tension Pin
26955	1378	Throat Plate with Extension for 24344
19376	1378	Vibrating Presser Foot
26956	——	Binder (adjustable) complete, Nos. 283D, 19376, 24344 and 26953 to 26955
283D	1379	Binder Thumb Screw

BINDER (Adjustable)

FOR CAP FRONTS

FOR 44-13 MACHINE

NO.	PLATE	NAME
26695	2024	Bed with 9558
25698	2024	Folder
9558	2038	" Steady Pin
26696	2024	Guide (lower) with 1141D and 9780
1141D	5806	" " Screw Stud
9780	2038	" " Stud
1566D	2024	" " Thumb Nut
26697	2024	" (upper)
152F	2038	" " Screw
7071	2021	" " " Washer
25703	2024	Pressure Spring with 26698
26698	2024	" " Lifting Button
334D	2038	" " Screw
7071	2021	" " " Washer
26694	2024	Binder (adjustable) complete, Nos. 334D, 1566D, 25698, 25703, 26695 to 26697, two 152F and three 7071

BINDER (Adjustable)

FOR 44-72 MACHINE

NO.	PLATE	NAME
24344	1267	Feed Dog
24480	2688	Feeding Foot, 16 teeth to the inch, with two 1019F
217D	2688	Feeding Foot Screw
*26951	——	Folder (lower)
*26952	——	" (upper)
26953	1379	Folder with Ribbon Tension complete, Nos. 26951, 26952, two each 193F, 7071 and nine 26486
193F	2688	Folder Screw
7071	1379	" " Washer
24481	2688	Lifting Presser Foot
26486	2022	Ribbon Tension Pin
26955	1378	Throat Plate with Extension for 24344
35072	——	Binder (adjustable) complete, Nos. 283D, 24344, 24480, 24481, 26953 and 26955
283D	1379	Binder Thumb Screw

BINDER (Adjustable)

FOR SLEEVE FACINGS ON MILITARY COATS

NO.	PLATE	NAME
120165	5839	Binder on 28971
28972	5839	Arm
940D	5742	" Hinge Screw
28973	5839	Hinge Plate
28971	2669	Shank
286D	783	" Thumb Screw
7071	2021	" " " Washer
120166	5839	Binder (adjustable) complete, Nos. 286D, 940D, 7071, 28972, 28973 and 120165

BINDER (Adjustable)

TO TURN IN UPPER EDGE ONLY, FOR LIGHT OR MEDIUM WEIGHT MATERIAL

NO.	PLATE	NAME
120242	7790	Bed with 1036C
120244	7790	Folder (upper)
120245	7790	Guide (centre)
120246	7790	" (lower)
286D	783	" Thumb Screw
1036C	7790	Leveling Screw

NO.	PLATE	NAME
120247	7790	Binder (adjustable) complete, Nos. 286D, 120242 and 120244 to 120246.....
35066	5644	Presser Foot for 120247.....
7298	2014	" " Hinge Pin.....
120143	——	" " Plate.....
19335	——	" " Shank.....
120144	5847	Presser Foot (hinged) complete for 120247, Nos. 7298, 19335 and 120143.....
26603	1381	Feed Dog for 120247.....
26605	2033	Throat Plate, large needle hole, for 26603

BINDER (Adjustable)

TO TURN IN BOTH EDGES, FOR LIGHT OR MEDIUM WEIGHT MATERIAL

NO.	PLATE	NAME
120242	7791	Bed with 1036C.....
120243	7791	Folder (lower).....
120244	7791	" (upper).....
120245	7791	Guide (centre).....
286D	783	" Thumb Screw.....
1036C	7790	Leveling Screw.....
120248	7791	Binder (adjustable) complete, Nos. 286D and 120242 to 120245.....
35066	5644	Presser Foot for 120248.....
7298	2014	" " Hinge Pin.....
120143	——	" " Plate.....
19335	——	" " Shank.....
120144	5847	Presser Foot (hinged) complete for 120248, Nos. 7298, 19335 and 120143.....
26603	1381	Feed Dog for 120248.....
26605	2033	Throat Plate, large needle hole, for 26603

BINDER (English)

(SMALL "D" FEED)

NO.	PLATE	NAME
12425	2021	Feed Dog.....
25721	2021	Folder.....
207F	2021	" Screw.....
7071	2021	" " Washer.....
25983	2021	Presser Foot.....
26614	2021	Ribbon Tension Pin (bent).....
26615	2021	" " " (straight).....
26616	2021	" " Plate.....
25722	2021	Ribbon Tension complete, Nos. 26614, 26616 and four 26615.....

NO.	PLATE	NAME
190D	782	Ribbon Tension Screw .....
7071	2021	" " " Washer.....
26249	2021	Throat Plate for 12425.....
26250	——	Binder complete, Nos. 190D, 207F, 12425, 25721, 25722, 25983, 26249 and two 7071

BINDER (English)

(LARGE "D" FEED)

This Binder is the same as 26250 with the following exceptions:

NO.	PLATE	NAME
12370	2023	Feed Dog, 15 teeth (16 teeth to the inch) in place of 12425.....
26465	2023	Throat Plate, large needle hole, for 12370, in place of 26249.....
35741	——	Throat Plate, small needle hole, for 12370, in place of 26249.....
26466	——	Binder complete, Nos. 190D, 207F, 12370, 25721, 25722, 25983, 26465 or 35741 and two 7071.....

BINDER (English)

This Binder is the same as 26250 with the following exceptions:

NO.	PLATE	NAME
12369	1382	Feed Dog, 12 teeth (12 teeth to the inch) in place of 12425.....
12457	1382	Feed Dog, 16 teeth (16 teeth to the inch) in place of 12425.....
28655	1382	Throat Plate, small needle hole, for 12369 or 12457, in place of 26249.....
28656	——	Throat Plate, large needle hole, for 12369 or 12457, in place of 26249.....
28657	——	Binder complete, Nos. 190D, 207F, 12369 or 12457, 25721, 25722, 25983, 28655 or 28656 and two 7071.....

BINDER (English)

FOR CUT CLOTH

NO.	PLATE	NAME
19474	2022	Feed Dog.....
25733	2022	Folder, for ½ in. binding.....
207F	2021	" Screw.....
7071	2021	" " Washer.....

NO.	PLATE	NAME
26400	2022	Presser Foot
26617	2022	Ribbon Tension Pin (bent)
26486	2022	" " " (straight)
26618	2022	" " Plate
25734	2022	Ribbon Tension complete, Nos. 26617, 26618 and seven 26486
190D	782	Ribbon Tension Screw
7071	2021	" " " Washer
26401	2022	Throat Plate for 19474
26402	——	Binder complete, Nos. 207F, 19474, 25733, 25734, 26400, 26401, two 190D and three 7071

BINDER (English)

NO.	PLATE	NAME
26603	1381	Feed Dog
120001	1381	" " (spiked teeth)
28334	1380	Folder
193F	1379	" Screw
7071	1379	" " Washer
28676	1381	Presser Foot
26617	2022	Ribbon Tension Pin (bent)
26486	2022	" " " (straight)
28336	——	" " Plate
28337	1380	Ribbon Tension complete, Nos. 26617, 28336 and eight 26486
233D	1380	Ribbon Tension Screw
28677	1381	Throat Plate for 26603 and 120001
28678	——	Binder complete, Nos. 193F, 7071, 26603 or 120001, 28334, 28337, 28676, 28677 and two 233D

BINDER (English)

(LARGE "D" FEED)

FOR CARPETS

This Binder is the same as 28678 with the following exceptions:

NO.	PLATE	NAME
12370	1382	Feed Dog, 15 teeth (16 teeth to the inch) in place of 26603
28775	1382	Throat Plate for 12370, in place of 28677
28776	——	Binder complete, Nos. 193F, 7071, 12370, 28334, 28337, 28676, 28775 and two 233D

BINDER (English)

FOR 44-9 MACHINE

NO.	PLATE	NAME
26699	1314	Feed Dog
25744	1314	Folder and Ribbon Tension with nine 26486, for ½ in. binding
25745	——	Folder and Ribbon Tension with nine 26486, for ⅛ in. binding
671D	1314	Folder and Ribbon Tension Thumb Screw
26702	1314	Lifting Presser Foot
26486	2022	Ribbon Tension Pin (straight)
26700	1314	Throat Plate with Extension for 26699
26703	1314	Vibrating Presser Foot
26701	——	Binder complete, Nos. 671D, 25744, 25745, 26699, 26700, 26702 and 26703

BINDER (English)

FOR 44-9 MACHINE

This Binder is the same as 26250 with the following exceptions:

NO.	PLATE	NAME
20106	1382	Feed Dog, in place of 12425
26702	1314	Lifting Presser Foot, in place of 25983
28783	1382	Throat Plate for 20106, in place of 26249
26703	1314	Vibrating Presser Foot
28784	——	Binder complete, Nos. 190D, 207F, 20106, 25721, 25722, 26702, 26703, 28783 and two 7071

BINDER FOR CIRCULAR BINDING

FOR SANDALS, SLIPPERS, SHOE TONGUES, ETC.
FOR 44-9 MACHINE

NO.	PLATE	NAME
28790	2645	Feed Dog
28366	2645	Folder
207F	2021	" Screw
7071	2021	" " Washer
28791	2645	Lifting Presser Foot
36620	2645	Ribbon Guide
337D	2645	" " Screw
7806	2645	" " " Washer
28792	2645	Throat Plate for 28790
28793	2645	Vibrating Presser Foot
28794	——	Binder complete, Nos. 207F, 337D, 7071, 7806, 28366, 28790 to 28793 and 36620

BINDER FOR CIRCULAR BINDING

(BIAS BINDING)

FOR SUSPENDER ENDS AND TABS, WITH MOVABLE FOLDER FOR FINISHING OFF

FOR 44-9 MACHINE

NO.	PLATE	NAME
28823	2646	Binder on Shank
207F	2021	" Screw
7071	2021	" " Washer
28824	2646	Feed Dog
28825	2646	Lifting Presser Foot
28826	2646	Throat Plate for 28824
28827	2646	Vibrating Presser Foot
28828	——	Binder complete, Nos. 207F, 7071 and 28823 to 28827

BINDER FOR CIRCULAR BINDING

(BIAS FOLDED STRIPS)

FOR LADIES' LAWN TIES, ETC.

FOR 44-13 MACHINE

NO.	PLATE	NAME
28790	2645	Feed Dog
28857	2645	Folder
207F	2021	" Screw
7071	2021	" " Washer
28858	2645	Presser Foot with 242D, 23219 and 28859
28859	2645	" " Edge Guide
23219	2645	" " " " Position Pin
242D	2645	" " " " Screw
28860	2645	Strip Guide
207F	2645	" " Screw
7071	2645	" " " Washer
28792	2645	Throat Plate for 28790
28861	——	Binder complete, Nos. 28790, 28792, 28857, 28858, 28860 and two each 207F and 7071

BINDER FOR BINDING SANDALS AND PUMPS

FOR 44-9 MACHINE

NO.	PLATE	NAME
36761	5660	Binder
228D	2038	" Screw
36762	5660	Feed Dog, for narrow binding
120072	5660	" " " wide binding

NO.	PLATE	NAME
36763	5660	Lifting Presser Foot.....
36764	5660	Throat Plate for 36762.....
36765	5660	Vibrating Presser Bar.....
36766	5660	" " Foot.....
36767	——	Binder complete, Nos. 36761, 36762 or 120072, 36763 to 36766 and two 228D

BINDER FOR BINDING SLIPPER AND SANDAL STRAPS

FOR 44-9 MACHINE

NO.	PLATE	NAME
36704	5659	Binder.....
228D	2038	" Screw.....
36705	5659	Feed Dog.....
36706	5659	Lifting Presser Foot.....
36707	5659	Throat Plate for 36705.....
36708	5659	Vibrating Presser Foot.....
36709	——	Binder complete, Nos. 36704 to 36708 and two 228D.....

BINDERS (Foot)

NO.	PLATE	NAME
28665	2606	Binder (foot).....
28666	2606	" " right hand.....
28667	2606	" " left hand.....
36700	5808	" " left.....
28717	1388	" " right.....
35069	2666	" " for strip, to turn the upper edge in, for skirt facings, etc.....
28769	1390	Binder (foot) to turn top only.....

BINDERS ON SHANK

NO.	PLATE	NAME
25705	——	Binder on Shank, for $\frac{3}{8}$ in. tape.....
25706	——	" " " " $\frac{7}{16}$ in. tape.....
25707	2605	" " " " $\frac{1}{2}$ in. tape.....
25708	——	" " " " $\frac{9}{16}$ in. tape.....
25709	——	" " " " $\frac{5}{8}$ in. tape.....
25710	——	" " " " $\frac{11}{16}$ in. tape.....
25711	——	" " " " $\frac{3}{4}$ in. tape.....
25712	——	" " " " $\frac{13}{16}$ in. tape.....
25713	——	" " " " $\frac{7}{8}$ in. tape.....
25714	——	" " " " $\frac{15}{16}$ in. tape.....
25715	——	" " " " 1 in. tape.....
28611	1396	" " " " suspender webs....
28612	1396	Presser Foot for 28611.....

NO.	PLATE	NAME
28631	2602	Binder on Shank.....
28632	2602	" " " to turn edges under....
28633	1399	" " " " " top edge only, for binding coats.....
28634	2602	Binder on Shank, to turn top edge only, for raw edge binding.....
28635	1398	Binder on Shank, for 7/8 in. binding.....
28636	2601	" " " to turn top edge only, for bottoms of men's trousers.....
28637	2626	Binder on Shank, for bias binding, to turn top edge only, with guide for inserting canvas strip.....
28638	2600	Binder on Shank, for dress shields.....
28639	2603	" " " to turn top edge only, for suspenders.....
28640	2627	Binder on Shank, for 1¼ in. binding, for soft blankets.....
28641	2603	Binder on Shank, for 11/16 in. binding.....
28643	2603	" " " with guide (wire) for mattress work.....
28693	2607	Binder on Shank, for binding the arm holes in cotton garments.....
28692	2607	Presser Foot for 28693.....
28704	2610	Binder on Shank.....
28724	2614	" " " for binding the neck of knit underwear.....
28938	2658	Presser Foot for 28724.....
28730	2615	Binder on Shank.....
28731	2616	" " " to turn under both edges of binding ⅛ in.....
28732	2627	Binder on Shank, to turn under both edges of binding.....
28733	2614	Binder on Shank, for binding corset covers
28734	2615	" " " with ribbon guide, for dress shields.....
28765	2622	Binder and Folder on Shank, for folding and binding sleeves.....
28766	2622	Presser Foot for 28765.....
28910	2659	Binder on Shank.....
28804	2619	" " " for binding dress shields
35040	2658	Presser Foot for 28804.....
28751	2618	Binder and Guide on Shank, for binding upper edge of button hole strip and guiding strip and body, for shirt waists
28752	2618	Presser Foot for 28751.....
28851	2648	Binder on Shank, for 3 in. strip of bobbinette material, to bind ¾ in. wide.....

NO.	PLATE	NAME
28970	2659	Binder on Shank, for bias binding, to turn both edges under.....
35065	2677	Binder on Shank, for strip, to turn in upper edge only, for skirt facings, etc..
19474	1258	Feed Dog for 35208.....
19475	1258	Throat Plate for 19474.....
35208	1971	Binder on Shank, to turn in both edges of bias or straight binding, for skirts, wrappers, shirt waists, etc.....
35066	2682	Presser Foot for 35065 and 35208.....
7298	2014	" " Hinge Pin.....
120143	——	" " Plate.....
19335	——	" " Shank.....
120144	5847	Presser Foot (hinged) complete for 35065 and 35208, Nos. 7298, 19335 and 120143
35082	2680	Binder on Shank, for raw edge bias binding, for wrappers, etc.....
35182	2684	Binder on Shank, for cut strip, with heavy cord stitch in centre of strip, for ladies' dressing sacques, etc.....
35183	2683	Presser Foot for 35182.....
26603	2033	Feed Dog for 28731.....
120001	1381	" " " " .....
35454	2616	Presser Foot for 28731.....
26605	2033	Throat Plate, large needle hole, for 26603
28731	2616	Binder on Shank, to turn under both edges of binding ⅛ in.....
26603	2033	Feed Dog for 35226.....
120001	1381	" " " " .....
35231	2683	Presser Foot for 35226.....
26605	2033	Throat Plate, large needle hole, for 26603
35226	1972	Binder on Shank, for mattress work.....
19474	2067	Feed Dog for 35325.....
35066	2067	Presser Foot for 35325.....
7298	2014	" " Hinge Pin.....
120143	——	" " Plate.....
19335	——	" " Shank.....
120144	5847	Presser Foot (hinged) complete for 35325, Nos. 7298, 19335 and 120143.....
35325	2067	Binder on Shank, to turn top edge only, for shirt bosoms, skirt trimmings, etc.
26603	2033	Feed Dog for 35354.....
120001	1381	" " " " .....
35444	——	Presser Foot Body.....
35445	——	" " Tension Plate with 35446...
35446	2669	" " " " Guide Pin....
93F	2669	" " " " Screw.. ....

NO.	PLATE	NAME
2656	2669	Presser Foot Tension Plate Spring.....
35447	2669	Presser Foot (tension plate) complete for 35354, Nos. 93F, 2656, 35444 and 35445
26605	2033	Throat Plate, large needle hole, for 26603
35352	970	Binder Folder on Shank.....
35353	970	" " Hinge Plate.....
1425B	5742	" " " Screw.....
2749	5742	" " " " Friction Washer
35354	970	Binder on Shank (hinged) complete, for mattress work, Nos. 1425B, 2749, 35352 and 35353.....
120257	5847	Binder with tension slots on Shank, for turning in both edges of bias cut binding, for light or medium weight material..
26603	2033	Feed Dog for 35226.....
35232	2674	Lifting Presser Foot for 35226.....
26605	2033	Throat Plate, large needle hole, for 26603
35233	2674	Vibrating Presser Foot for 35226.....
35226	1972	Binder on Shank, for mattress work.....
35716	1253	Binder on Shank, to turn in both edges of binding, for blankets, for 44-72 Machine

FOR 44-9 MACHINE

19474	1258	Feed Dog, for corset work, for 35209....
35210	2683	Lifting Presser Foot for 35209.....
19475	1258	Throat Plate, large needle hole, for 19474
35211	2683	Vibrating Presser Foot for 35209.....
35209	1972	Binder on Shank, to turn in both edges, for bias binding, for binding the inside of small circles, corsets, etc.....
36995	5659	Binder on Shank, for $\frac{3}{8}$ in. binding.....
36996	——	" " " " $\frac{7}{16}$ in. binding.....
36997	——	" " " " $\frac{5}{16}$ in. binding.....

BINDERS (Horn) ON SHANK

NO.	PLATE	NAME
28619	1399	Binder (horn) on Shank.....
28620	1399	Presser Foot for 28619.....
35067	2678	Binder (horn) on Shank, for strip, to turn both edges in, for ladies' collars, etc.....
35066	2682	Presser Foot for 35067.....
7298	2014	" " Hinge Pin.....
120143	——	" " Plate.....
19335	——	" " Shank.....
120144	5847	Presser Foot (hinged) complete for 35067, Nos. 7298, 19335 and 120143.....

NO.	PLATE	NAME
28642	2603	Binder (horn) on Shank.....
28941	2661	" " " " for bias binding, to turn under both edges of binding...
35062	2676	Binder (horn) on Shank, for 7/8 in. to 1½ in. wide, for tape, for mattresses.....
35063	2676	Presser Foot for 35062.....

BOX PLAITER PARTS

FOR 44-13 AND 44-20 MACHINES

NO.	PLATE	NAME
28343	2632	Centre Guide.....
		NOTE: When ordering No. 28343, give width of plait for which it is required.
28344	2632	Centre Guide Holder with 10165.....
190D	782	" " " Screw.....
7071	2021	" " " " Washer.....
10165	2633	" " Stop Pin.. .....
28345	2632	Folder Blade (left).....
28346	2632	" " (right).....
401E	2442	" " Screw.....
28347	2632	Sliding Bracket (left).....
28348	2632	" " (right).....
28349	2632	" " Arm (left) with 2301....
28350	2632	" " " (right) with 2301...
28351	2632	" " " Extension Bracket
200F	2633	" " " " " Screw.....
914F	2442	Sliding Bracket Arm Screw.....
26438	2632	" " Cap.....
233D	2442	" " " Screw.....
514C	2442	" " Locking Pin.....
26439	2442	" " " " Bushing with 468C.....
1564D	2442	Sliding Bracket Locking Pin Head.....
2297	2442	" " " " Spring.....
2296	2442	" " " " " Bushing.....
468C	2442	Sliding Bracket Locking Pin Spring Bushing Set Screw.....
2301	2442	Sliding Bracket Stop Pin.....
233D	2442	" " " Screw.....
28352	——	Box Plaiter complete, Nos. 28343 to 28351, two each 190D, 200F, 514C, 914F, 1564D, 2296, 2297, 7071, 26438, 26439, four 401E and six 233D.....

NO.	PLATE	NAME
28353	2633	Presser Foot with 28354, 28355 and two 665D
28354	2633	Presser Foot Guide (left)
28355	2633	" " " (right)
665D	2633	" " " Screw

CORDERS

When ordering Corders or parts thereof state size or number of cords to the inch.

CORDER (Adjustable)

FOR SHORT TURNS ON CUSHIONS

NO.	PLATE	NAME
26795	5839	Cord Guide
26796	5839	" " Arm with 26798 and three 6037
1044D	1377	" " " Hinge Screw
120206	5839	" " Bed with 457C
457C	5806	" " " Leveling Screw
26798	5839	" " Bracket
6037	1377	" " " Rivet
190D	1377	" " Screw
120207	5839	Corder complete, Nos. 190D, 1044D, 26795, 26796 and 120206
120001	1381	Feed Dog (spiked teeth)
120208	1381	Presser Foot (grooved)
26605	2033	Throat Plate for 120001

CORDER FOR TOP CORDING

NO.	PLATE	NAME
25788	2026	Arm with 25789
190D	2026	" Adjusting Screw
25791	2026	" Bracket
25790	2026	" Hinge Pin
879D	2026	" Locking Screw
25789	2026	" Tip
25792	2026	Arm and Bracket complete, Nos. 190D, 879D, 25788, 25790 and 25791
12372	778	Feed Dog, 13 teeth (12 teeth to the inch)
25984	2025	Presser Foot
12442	778	Throat Plate, small needle hole, for 12372
26328	——	Corder complete, Nos. 12372, 12442, 25792, 25984 and two 135D
135D	2026	Corder Screw

CORDER FOR TOP AND BOTTOM CORDING

This Corder is the same as No. 26328 with the following exceptions:

NO.	PLATE	NAME
26166	2025	Feed Dog, in place of 12372.....
26167	2025	Presser Foot, in place of 25984.....
26168	2025	Throat Plate for 26166, in place of 12442
26169	——	Corder complete, Nos. 25792, 26166 to 26168 and two 135D.....

CORDER FOR TOP AND BOTTOM CORDING

FOR 44-20 MACHINE

This Corder is the same as 26328 with the following exceptions:

NO.	PLATE	NAME
28748	1384	Feed Dog, in place of 12372.....
26167	2025	Presser Foot, in place of 25984.....
28749	1384	Throat Plate for 28748, in place of 12442
28750	——	Corder complete, Nos. 25792, 26167, 28748 28749 and two 135D.....

CORDER FOR TOP AND BOTTOM CORDING

This Corder is the same as 26328, with the following exceptions:

NO.	PLATE	NAME
28629	1384	Feed Dog, in place of 12372.....
26167	2025	Presser Foot, in place of 25984.....
28630	1384	Throat Plate for 28629, in place of 12442
28788	——	Corder complete, Nos. 25792, 26167, 28629, 28630 and two 135D.....

CORDER (Bow) FOR TOP CORDING

NO.	PLATE	NAME
26937	1385	Corder Bow.....
4604	1385	" " Rivet.....
25789	1385	" " Tip.....
26648	1385	Presser Foot.....
26938	1385	Corder (bow) complete, Nos. 4604, 25789, 26648 and 26937.....

CORDER FOR EDGE CORDING

NO.	PLATE	NAME
35026	2673	Corder on Shank.....
35027	2674	Feed Dog.....
35028	2674	Presser Foot..... .....
35029	2674	Throat Plate for 35027.....
35030	——	Corder complete, for edge cording plush, Nos. 35026 to 35029.....

FELLER

NO.	PLATE	NAME
26403	2029	Feller (foot).....

FINGER GUARD

NO.	PLATE	NAME
36818	5809	Finger Guard.....
36819	5809	" " Friction Washer.....
50316J	5809	" " Hinge Screw.....
36820	5809	" " Holder with 196J.....
196J	5809	" " " Clamping Screw...
36821	5809	Finger Guard complete, Nos. 36818 to 36820 and 50316J.....

EDGE FOLDERS ON SHANK

NO.	PLATE	NAME
28615	1397	Edge Folder with Cord Guide on Shank, to insert and sew on insertion in one operation.....
28616	1397	Presser Foot (grooved) for 28615.....
28903	2782	Edge Folder (left hand) with right hand upper guide on shank, to turn up the body of bobbinette curtains and sew on insertion in one operation.....
28625	2627	Edge Folder (double) with Strip Folder and Cord Tube on Shank, for inserting cord, folding strip and stitching between the two folded edges of goods.....
28626	1391	Presser Foot with groove on bottom to the right of needle hole, for 28625.....
28646	2604	Edge Folder (double) on Shank, for men's skeleton coat seams, to turn to outside
28649	2604	Edge Folder on Shank.....
28702	2609	" " " " with Understrip Edge Folder, for strip when stitched to project over edge of goods.....

NO.	PLATE	NAME
28703	2609	Presser Foot for 28702
28709	2628	Edge Folder (double) on Shank, for canvas
28735	2616	" " on Shank, for seaming umbrellas
28767	2620	Edge Folder (double) on Shank, the underfold to extend $\frac{1}{16}$ in. beyond edge of upper fold
26948	2601	Edge Folder on Shank, to turn edge of yoke and insert body of shirt
28753	2618	Edge Folder and Guide on Shank, for top fold only
12450	2690	Feed Dog, 11 teeth (18 teeth to the inch) for 35175
35176	2690	Presser Foot for 35175
12464	2690	Throat Plate, large needle hole, for 12450
12451	——	" " small needle hole, for 12450
35175	2690	Edge Folder on Shank
35255	2693	Feed Dog for 35253
35254	2693	Presser Foot for 35253
35256	2693	Throat Plate for 35255
35253	2693	Edge Folder (double) on Shank, for joining yokes to the back of shirts
28958	2668	Edge Folder and Binder (combination) for seaming ladies' skirts and making imitation plait
36292	5810	Edge Folder (double) on Shank 28971 for 36293
28972	5810	Edge Folder Holder
35610	2669	" " " Friction Washer
940F	1366	" " " Hinge Screw
28973	5810	" " " Shank
28971	2669	" " Shank
286D	783	" " Thumb Screw
7071	1379	" " " " Washer
36293	5810	Edge Folder (double) hinged, adjustable, complete, Nos. 286D, 940F, 7071, 28972, 28973, 35610 and 36292
12369	2699	Feed Dog, 12 teeth (12 teeth to the inch) for 36293
36294	5810	Presser Foot for 36293
12411	2699	Throat Plate, large needle hole, for 12369
120135	5846	Edge Folder (double) for turning in two edges and inserting loops in one operation
120136	5846	Presser Foot for 120135
120197	5848	Edge Folder (upper) with lower right hand guide on shank, for military uniforms

FOR 44-22 MACHINE

NO.	PLATE	NAME
28811	2625	Edge Folder (suspended) right hand, complete, for turning edge and ruffling folded edge on skirts.....
28833	2649	Edge Folder (left hand) on Shank with right hand upper folder and separating blade.....
28862	2649	Edge Folder (double) on Shank, right hand upper, left hand lower, with separating blade, for wrappers.....
28358	2624	Edge Folder (suspended) left hand, to turn edge under.....
28359	1395	Edge Folder (double) with Separating Blade on Shank, lower folder, to turn the edge of the goods under.....
28549	1395	Edge Folder (double) with Separating Blade on Shank, lower folder, to turn the edge of the goods up.....
28756	2619	Edge Folder (left hand) on Shank with right hand lower guide.....
35922	2619	Ruffling Blade for 28756.....
28755	2621	Edge Folder (left hand) on Shank with right hand upper guide and separating blade.....
28758	2620	Edge Folder (double) with Separating Blade on Shank, lower folder, to turn the edges of the goods up.....
28760	2627	Edge Folder (right hand) on Shank with left hand lower guide.....
28763	2621	Edge Folder (left hand) on Shank with right hand lower guide.....

FOR 44-9 MACHINE

35178	2692	Feed Dog.....
35179	2692	Lifting Presser Foot.....
35180	2692	Throat Plate for 35178.....
35181	2692	Vibrating Presser Foot.....
35177	2691	Edge Folder (double) on Shank, for oil cloth and leather.....

STRIP FOLDERS

NO.	PLATE	NAME
28613	1396	Strip Folder on Shank, for overall shoulder straps.....
28614	1396	Presser Foot for 28613.....

NO.	PLATE	NAME
28617	1398	Strip Folder on Shank, for inserting folded strip, for trimming mantles .....
28618	1398	Presser Foot (grooved) for strip, for 28617
28647	2626	Strip Folder on Shank.....
28648	2626	" " " " for making straps
28698	2608	" " " " with cord tube....
28699	2608	Presser Foot, grooved to the right of needle hole, for 28698.....
28708	2611	Strip Folder on Shank, for folding strip and stitching down centre.....
28764	2622	Strip Folder on Shank with left hand upper guide.....
28848	2648	Strip Folder on Shank, for folding overall straps.....
28849	1387	Presser Foot with guide on bottom to the left of needle hole, for 28848.....
19474	2067	Feed Dog for 35345.....
35346	2669	Presser Foot for 35345.....
24572	2067	Throat Plate, small needle hole, for 19474
35345	953	Strip Folder on Shank, for making straps
35347	970	" " (double) hinged, for turning in the right hand edges of strips, for making strip, for 35348.....
35348	970	Strip Folder, for turning in the upper and lower edges of strip made on 35347....
35349	970	Strip Folder Holder and Guide.....
190D	782	" " " " " Screw.....
7071	2021	" " " " " " Washer
19474	946	Feed Dog for 35351.....
35350	946	Presser Foot for 35351.....
24572	2067	Throat Plate, small needle hole, for 19474
35351	——	Attachment complete, for making two-piece apron straps, cloth suspenders, etc., Nos. 19474, 24572, 35347 to 35350 and two each 190D and 7071.....
35855	1253	Strip Folder on Shank, for collar bands...
26603	2033	Feed Dog for 35855.....
35856	2669	Presser Foot for 35855.....
26605	2033	Throat Plate, large needle hole, for 26603
28728	2628	Strip Folder on Shank, to turn in the raw edge on lower fold.....
120191	5845	Strip Folder on Shank, to turn in both edges.....
28754	2628	Strip Folder on Shank, for suspender straps, to turn both edges.....
28945	2666	Strip Folder on Shank, for making overall straps.....

FOR 44-9 MACHINE

NO.	PLATE	NAME
19474	2067	Feed Dog
35322	2697	Lifting Presser Foot
24572	2067	Throat Plate, small needle hole, for 19474
35323	2697	Vibrating Presser Foot
35324	2684	Strip Folder on Shank, for making four-ply bands, for ladies' stock collars, etc.

STRIP FOLDER (Foot)

NO.	PLATE	NAME
28705	2627	Strip Folder with Arm
28706	2627	" " Hinge Bracket with 448c and 2273
448c	783	Strip Folder Hinge Bracket Set Screw
96D	1394	" " " Screw
26173	1394	" " Lock Stud
26174	1394	" " " " Spring
228D	1394	" " " " " Screw
2273	1394	" " Stop Pin
28707	2627	Strip Folder (foot, hinged) complete, for folding and stitching plait on shirt bosom, Nos. 96D, 228D, 26173, 26174, 28705 and 28706

STRIP FOLDER ON SHANK

FOR 44-75 MACHINE

NO.	PLATE	NAME
120015	5688	Guide Wire with 120018
120016	8376	" " Clamp
703B	8376	" " " Thumb Screw
120017	5688	" " Extension
120018	5688	" " " Clamp with 207B and 793B
793B	8376	Guide Wire Extension Clamp Thumb Screw
207B	1375	Guide Wire Extension Set Screw
703B	8376	" " Thumb Screw
3146	1353	" " " " Washer
120019	5688	Strip Folder on Shank with 3146, 120015 to 120017 and two 703B
1423B	5742	Strip Folder Screw

GUIDES

NO.	PLATE	NAME
25866	2045	Guide, for flush throat plate
25874	2045	" " raised throat plate
35190	2697	" " 28967
25873	2045	" (combination)
28658	1377	" (roller) with 1852
1852	1377	" Roller
284D	1366	" Thumb Screw for 25874
732D	1366	" " " for 25866
3146	1353	" " " Washer for 25873
28674	2607	Lap Seam Guide on Shank

GUIDE (Adjustable, Hinged)

NO.	PLATE	NAME
28971	2669	Guide
28972	2669	" Holder
35610	2669	" " Friction Washer
940D	5742	" " Hinge Screw
28973	2669	" " Shank
286D	783	" Thumb Screw
7071	2021	" " " Washer
28969	2669	Guide (adjustable, hinged) complete, Nos. 286D, 940D, 7071, 28971 to 28973 and 35610

GUIDE WITH DISENGAGING LEVER

FOR MACHINE-TURNED WORK

FOR 44-29 MACHINE

NO.	PLATE	NAME
36115	5696	Guide on Slide with 36113
35838	5696	" Bed
36116	5696	" Disengaging Lever with 2113, 19045 and 35840
19045	——	Guide Disengaging Lever Handle
35840	——	" " " " Washer.
990F	5696	" " " Screw.
35841	5696	" " " Spring
2113	1388	" " " " Guide Pin
36113	5696	" Tip
36117	5696	Guide with Disengaging Lever complete, Nos. 990F, 35838, 35841, 36115 and 36116
35580	——	Feed Dog (sharp teeth)
35581	——	Presser Foot

NO.	PLATE	NAME
35582	——	Throat Plate for 35580.....
35583	——	" " Guide.....
337D	1383	" " " Screw.....

EDGE GUIDE

FOR 44-22 MACHINE

NO.	PLATE	NAME
28838	2650	Edge Guide (suspended) left hand.....

EDGE GUIDE (Roller)

NO.	PLATE	NAME
26803	1375	Edge Guide Bed with 2362.....
220D	1375	" " Leveling Screw.....
36760	1375	" " Slide with 26809, 51809 and two 12152.....
26805	1375	Edge Guide Slide Cap (left).....
207F	1375	" " " " " Screw.....
2362	1375	" " " " " Steady Pin..
26806	1375	" " " " (right).....
207F	1375	" " " " " Screw (large)
233D	1375	" " " " " " (small)
26807	1375	" " " Lever.....
94D	1375	" " " " Hinge Screw....
51809	1375	" " " Roller and Stud.....
26808	1375	" " " Spring.....
26809	1375	" " " " Cover.....
12152	1375	" " " " " Rivet....
26810	1375	Edge Guide (roller) complete, Nos. 94D, 233D, 26803, 26805 to 26808, 36760, two 207F and four 220D.....
190D	1375	Edge Guide Screw.....

EDGE GUIDE (Roller)

FOR GLOVE WORK

NO.	PLATE	NAME
36185	6252	Edge Guide Arm with 1988.....
36186	6252	" " " Friction Washer.....
1425D	6252	" " " Hinge Screw.....
1988	6252	" " " Roller and Screw Stud
36187	6252	" " Bed with four 465F.....
465F	6252	" " " Leveling Screw.....
36188	6252	Edge Guide (roller) complete, Nos. 1425D and 36185 to 36187.....

STRIP GUIDE

NO.	PLATE	NAME
28712	2612	Strip Guide on Shank.....

HEMMERS

HEMMER WITH LEVER, FOR OPENING THE FOLDER AND RELEASING THE HEM, SO THAT IT CAN BE FINISHED WITHOUT REMOVING THE HEMMER FROM MACHINE. FOR SKIRTS, OVERALLS OR SIMILAR CLOSED ARTICLES.

NO.	PLATE	NAME
28679	1376	Hemmer Bed with 28681.....
28680	1376	" Folder (left).....
233D	1376	" " " Screw.....
2362	1376	" " " Steady Pin.....
28681	1376	" " (right).....
28685	1376	" " Disengaging Lever.....
94D	1376	" " " " Hinge Screw.....
2362	1376	Hemmer Folder Disengaging Lever Stop Pin.....
28682	1376	Hemmer Slide with 28687 and two each 2362 and 12152.....
28683	1376	Hemmer Slide Cap (left).....
28684	1376	" " " (right).....
207F	1376	" " " Screw (back).....
233D	1376	" " " " (front).....
28686	1376	" " Spring.....
28687	1376	" " " Cover.....
12152	1376	" " " " Rivet.....
28688	1376	Hemmer complete, Nos. 94D, 28679, 28680, 28682 to 28686, two 207F and three 233D.....
190D	1376	Hemmer Screw.....
18055	1394	Presser Foot Hinge Pin.....
28689	——	" " Plate.....
28690	——	" " Shank.....
26231	1353	" " Spring.....
28691	1391	Presser Foot (spring hinged) complete, Nos. 18055, 26231, 28689 and 28690...

HEMMERS (Foot)

NO.	PLATE	NAME
28663	2028	Hemmer (foot) $\frac{1}{16}$ in. hem, for 12372, 12455, 20002, 20117 and 20151.....
25919	——	Hemmer (foot) $\frac{5}{64}$ in. hem, for 12372, 12455, 20002, 20117 and 20151.....

NO.	PLATE	NAME
25920	2028	Hemmer (foot) $\frac{1}{8}$ in. hem, for 12372, 12455, 20002, 20117 and 20151.....
25921	——	Hemmer (foot) long, $\frac{1}{8}$ in. hem, for shirts, for 12372, 12455, 20002, 20117 and 20151.....
25922	2028	Hemmer (foot) $\frac{3}{16}$ in. hem, for 12369 and 12457.....
25923	——	Hemmer (foot) long, $\frac{3}{16}$ in. hem, for shirts, for 12369 and 12457.....
25924	——	Hemmer (foot) $\frac{1}{4}$ in. hem, for 12369 and 12457.....
26428	2028	Hemmer (foot) $\frac{1}{8}$ in. hem, for 12437 and 20147.....
36085	——	Hemmer (foot) $\frac{1}{16}$ in. hem, slotted for lace
28664	——	" " $\frac{3}{32}$ in. hem, slotted for lace
28662	2028	" " $\frac{1}{8}$ in. hem, slotted for lace
28661	2028	" " $\frac{3}{16}$ in. hem, for gusset work
28741	2028	" " $\frac{1}{8}$ in. hem, for bagging...
28669	2606	" Spring for 28670.....
26459	5806	" " Rivet.....
28670	2606	" (foot) $\frac{1}{4}$ in. hem, with 28669 and two 26459.....
28742	1388	Hemmer (foot) to make stitch in centre of hem.....
26607	1387	Presser Foot Body for 26610, 26611 and 35016.....
35016	——	Hemmer, $\frac{1}{16}$ in. hem, for 26607.....
26610	1387	" $\frac{1}{8}$ in. hem, for 26607.....
26611	——	" $\frac{3}{16}$ in. hem, for 26607.....
35710	1252	" (foot) $\frac{3}{32}$ in. hem, with guide on bottom to the right of needle hole.....
35682	——	Hemmer (foot) $\frac{1}{8}$ in. hem, with guide on bottom to the right of needle hole.....
36524	——	Hemmer (foot) $\frac{5}{32}$ in. hem, with guide on bottom to the right of needle hole.....
35997	——	Hemmer (foot) $\frac{3}{16}$ in. hem, with guide on bottom to the right of needle hole.....
36309	——	Hemmer (foot) $\frac{7}{32}$ in. hem, with guide on bottom to the right of needle hole.....
36072	——	Hemmer (foot) $\frac{1}{4}$ in. hem, with guide on bottom to the right of needle hole.....
35711	1252	Feed Dog for 35712.....
35712	1252	Throat Plate, small needle hole, for 35711, for 35682, 35710, 35997 and 36072.....

NOTE: When ordering No. 35712, state width of hem for which it is required.

NO.	PLATE	NAME
		Nos. 36980 to 36983 for 12437 and 20147
36980	——	Hemmer (foot) $\frac{3}{32}$ in. hem.....
36981	——	" " $\frac{5}{32}$ in. hem.....
36982	——	" " $\frac{3}{16}$ in. hem.....
36983	——	" " $\frac{1}{4}$ in. hem.....

HEMMER (Foot) ADJUSTABLE

FOR TENNIS SHOES

NO.	PLATE	NAME
120073	——	Hemmer Block with 39395.....
50441D	5839	" " Hinge Screw.....
39395	5839	" " Pin.....
120074	——	" " Spring.....
651D	1353	" " " Screw.....
120075	——	" Guide.....
50169D	5839	" " Screw.....
120076	——	" Plate.....
219D	774	" " Screw.....
120077	——	" Shank.....
120078	5839	Hemmer (foot) adjustable, complete, Nos. 219D, 651D, 50169D, 50441D and 120073 to 120077.....

HEMMERS (Foot) PLAIN BOTTOM

NO.	PLATE	NAME
28795	——	Hemmer (foot) plain bottom, $\frac{1}{16}$ in. hem..
26160	——	" " " " $\frac{3}{32}$ in. hem..
26161	2028	" " " " $\frac{1}{8}$ in. hem..
26162	——	" " " " $\frac{3}{16}$ in. hem..
26163	——	" " " " $\frac{1}{4}$ in. hem..
6267	2028	" Folder.....
25888	2028	" Tongue.....

Note: When ordering Nos. 6267 or 25888, state width of hem and No. of Hemmer for which it is required.

HEMMERS ON SHANK

NO.	PLATE	NAME
12450	777	Feed Dog, 11 teeth (18 teeth to the inch)
26656	2030	Presser Foot for 26655.....
12464	777	Throat Plate, large needle hole, for 12450
12451	——	" " small needle hole, for 12450
26652	——	Hemmer, $\frac{3}{32}$ in. hem.....
26654	2032	" Rivet.....
26653	2032	" Shank.....

NO.	PLATE	NAME
26655	2031	Hemmer on Shank complete, Nos. 26652 to 26654
26659	——	Hemmer for 26660
26660	2031	Hemmer on Shank complete, $\frac{3}{32}$ in. hem, for umbrella work, Nos. 26653, 26654 and 26659
26661	——	Hemmer (wide) for 26662
26662	2031	Hemmer on Shank complete, Nos. 26653, 26654 and 26661
26663	——	Hemmer for 26664
26664	2030	Hemmer on Shank complete, for raw edge silk, Nos. 26653, 26654 and 26663
26665	——	Hemmer, ⅛ in. hem, for 26666
26666	2030	Hemmer on Shank complete, Nos. 26653, 26654 and 26665
26934	——	Hemmer (narrow) for 26935
26935	1386	Hemmer on Shank complete, Nos. 26653, 26654 and 26934
28947	——	Hemmer for 28948
28948	1386	Hemmer on Shank complete, for one fold, with right hand lower guide, for lace, Nos. 26653, 26654 and 28947
36520	——	Hemmer, ¼ in. hem
36521	5811	Hemmer on Shank complete, Nos. 26653, 26654 and 36520
36711	——	Hemmer, ¼ in. hem
36712	5811	Hemmer on Shank complete, for umbrella work, Nos. 26653, 26654 and 36711
28623	2602	Hemmer and Corder on Shank, to take goods from above to cord bottom
28624	2602	Presser Foot with groove on bottom to the right of needle hole, for 28623
28627	2600	Hemmer on Shank, for ⅜ in. hem, for Marseilles quilts
28628	2600	Presser Foot for 28627
28650	2604	Hemmer on Shank, for hemming heavy Canton flannel
28651	2605	Hemmer on Shank, for turning tops and bottoms of canvas leggings
28652	2605	Hemmer on Shank, $1\frac{9}{16}$ in. to 2 in. hem
28653	——	" " " $2\frac{9}{16}$ in. to 3 in. hem
28700	2609	Hemmer (short head) on Shank, for hemming stable blankets
28701	1391	Presser Foot (tube) for laying braid on stable blankets, for 28700
36589	——	Presser Foot for 28700

NO.	PLATE	NAME
28710	2612	Hemmer on Shank, ⅛ in. hem.....
28711	2607	" " " $\frac{3}{16}$ in. hem, for hemming towels.....
28719	2613	Hemmer on Shank, ¼ in. to ½ in. hem..
120287	2613	Hemmer.....
120288	2613	" Shank.....
28720	2613	Hemmer on Shank, ¾ in. to 1 in. hem, complete, Nos. 120287 and 120288.....
28721	——	Hemmer on Shank, 1¼ to 2 in. hem.....
36776	——	" " " 2¼ in. to 3 in. hem..
28722	2613	" " " for heavy woven goods
28723	2614	" " " with guide for hemming and stitching on lace in one operation..
28736	2617	Hemmer on Shank, for umbrella work...
28737	2615	" " " for soft material, to turn the hem under.....
28738	2617	Hemmer on Shank, ⅜ in. hem, to turn the hem under.....
28739	2626	Hemmer on Shank, 3 in. hem, for sheets and pillow slips, to turn the hem under
28935	2661	Hemmer on Shank, for bobbinette material, to turn the hem under.....
35022	1386	Hemmer on Shank, $\frac{1}{16}$ in. hem, with right hand lower guide, for lace.....
35475	976	Hemmer on Shank, $\frac{5}{32}$ in. hem, with right hand lower guide, for lace.....
35023	2672	Hemmer on Shank, $\frac{1}{16}$ in. hem, with left hand lower guide, for lace.....
35064	2661	Hemmer on Shank, 1 in. to 2 in. hem, for general work.....
35104	2684	Hemmer on Shank, for bottom of shirt waists, for inserting drawing or shirring string.....
35063	2676	Presser Foot for 35104.....
35832	2669	" " " heavy work, for 35104...
35166	2694	Hemmer on Shank, 1 in. hem, to turn the goods under.....
120289	——	Hemmer on Shank, 2 in. hem, to turn the goods under.....
28614	1396	Presser Foot for 35166.....
19474	2695	Feed Dog for 35236.....
35063	2676	Presser Foot for 35236.....
19475	2695	Throat Plate, large needle hole, for 19474
35236	1971	Hemmer on Shank, for bottom of shirt waists.....
19474	2695	Feed Dog for 35241.....

NO.	PLATE	NAME
35066	2695	Presser Foot for 35241
7298	2014	" " Hinge Pin
120143	——	" " Plate
19335	——	" " Shank
120144	5847	Presser Foot (hinged) complete for 35241, Nos. 7298, 19335 and 120143
19475	2695	Throat Plate, large needle hole, for 19474
35241	2695	Hemmer on Shank, for Canton flannel, etc.
26603	5644	Feed Dog for 35863
35066	5644	Presser Foot for 35863
26605	5644	Throat Plate, large needle hole, for 26603
35863	5644	Hemmer on Shank, for canvas work
35679	932	" Folder on Shank for 35681
35353	932	" " Hinge Plate for 35681
1425B	932	" " " Screw
36006	932	" " " " Washer
35681	932	Hemmer on Shank (hinged) complete, for mattress work, Nos. 1425B, 35353, 35679 and 36006
26603	932	Feed Dog for 35681
35066	932	Presser Foot for 35681
26605	932	Throat Plate, large needle hole, for 26603
28777	2623	Hemmer (double) on Shank, for headings
28778	2623	Presser Foot for 28777
28779	2623	Ruffling Blade for 28777
35700	1250	Hemmer (left hand) with right hand lower guide on Shank, for 44-22 Machine

HEMSTITCHER

NO.	PLATE	NAME
28671	1392	Hemstitcher

LAP SEAM FELLER

NO.	PLATE	NAME
28673	2607	Lap Seam Feller (right hand) on Shank, to fold top only
28674	2607	Lap Seam Guide on Shank

PRESSER FOOT

NO.	PLATE	NAME
25985	2029	Presser Foot (single toe) for gathering
26638	2029	" " (double toe) for gathering
26639	——	" " with 228D, for 26641
26640	2029	" " Adjustable Guide for 26641

NO.	PLATE	NAME
228D	2038	Presser Foot Adjustable Guide Screw...
26641	2029	" " 26639 with Adjustable Guide, No. 26640, for tailor work.....
26642	——	Presser Foot.....
26643	2029	" " Guide.....
26644	1394	" " " Hinge Pin.....
26645	1394	" " " Spring.....
337D	1388	" " " " Screw.....
26646	2029	Presser Foot (spring guide) complete, Nos. 337D and 26642 to 26645.....
26650	2029	Presser Foot, for braiding.....
26651	2032	" " " folding umbrella straps.
26801	1387	" " Adjustable Guide for 26802
725D	1387	" " " " Screw...
26802	1387	Presser Foot with two adjustable guides No. 26801 and two 725D.....
26936	1387	Presser Foot, for etching.....
26978	1391	" " Graduated Adjustable Guide for 26977.....
335D	1317	Presser Foot Graduated Adjustable Guide Screw.....
26977	1391	Presser Foot with Graduated Adjustable Guide No. 26978 and 335D, for tailor work.....
28668	2606	Presser Foot (strip folding).....
28672	1391	" " two grooves to the right of needle hole, for cording.....
28675	1391	Presser Foot (pointed toe) for stitching box plaiting on body of material.....
28714	2611	Presser Foot (strip folding) for shirt-waist work.....
28715	1391	Presser Foot (tube) for laying fringe-edged braid.....
28716	2610	Presser Foot (strip folding) for raw edge strip, to turn edges under, for ⅜ in. to 1 in. strip.....
35877	——	Presser Foot (strip folding) for raw edge strip, to turn edges under, for $1\frac{1}{16}$ in. to 2 in. strip.....
28725	1388	Presser Foot Spring Guide for 28726.....
665D	1388	" " " " Screw.....
28726	1388	Presser Foot (right hand, spring guide) with 665D and 28725, for $\frac{1}{32}$ in. to ¼ in. gauge.....

NOTE: When ordering Nos. 28725 or 28726, state required distance from edge of goods to seam.

NO.	PLATE	NAME
28743	1388	Presser Foot (grooved) with tube, for cording.....
28744	1389	Presser Foot (strip folding) grooved, with two cord tubes, for making double corded strip.....
28745	1389	Presser Foot (strip folding) to fold both edges of strip.....
28746	1388	Presser Foot (tube) for guiding and stitching the left hand edge of ribbon.....
28747	1389	Presser Foot, for bias binding, the velveteen to project $\frac{3}{16}$ in.....
28768	1390	Presser Foot (strip folding) for folding a 2½ in. strip to a 1 in. strip, to be stitched on shirt bosoms, for imitation tuck....
28830	1387	Presser Foot (grooved) for cording, for carriage work.....
28908	2658	Presser Foot Spring Guide for 28909.....
665D	1388	" " " " Screw.....
28909	2658	" " (left hand, spring guide) with 665D and 28908.....
28920	1387	Presser Foot, for braiding, to stitch braid on right hand edge.....
28944	2665	Presser Foot (strip folding) for making raw edge straps of bias chiffon.....
35189	2697	Feed Dog for 28967.....
35190	2697	Guide for 28967.....
28964	——	Presser Foot Body.....
28965	2658	" " Knife.....
28966	2658	" " " Clamp.....
198D	2658	" " " " Screw.....
15072	2658	" " " " Steady Pin...
28967	2658	Presser Foot complete, for grooving insoles, Nos. 198D, 15072 and 28964 to 28966..
35191	2697	Throat Plate, for under braiding, for 35189
2532	772	Presser Foot Hinge Pin.....
24488	——	" " Plate.....
19223	——	" " Shank.....
24489	1309	Presser Foot (hinged) complete, for heavy work, Nos. 2532, 19223 and 24488.....
28770	——	Presser Foot.....
28771	1388	" " Guide.....
15072	1388	" " " Hinge Pin.....
28772	1388	" " " Spring.....
337D	1388	" " " " Screw.....
2113	1388	" " " " Steady Pin...
28773	1388	Presser Foot (spring guide) for gores, Nos. 337D, 2113, 15072 and 28770 to 28772

NO.	PLATE	NAME
35129	2682	Presser Foot (strip folding) for covering cord with folded strip.....
35184	2682	Presser Foot, for darning.....
35172	2682	" " (tube) for guiding and stitching the right hand edge of ribbon.....
35242	2698	Feed Dog for 35243.....
35243	2698	Presser Foot (strip folding) with tube for inserting cord, for making loops for dressing gowns.....
35244	2698	Throat Plate for 35242.....
35690	1246	Presser Foot (strip folding) for making straps from 1 in. to 1½ in. wide.....
44158	5842	Feed Dog.....
26276	1394	Presser Foot Hinge Pin.....
44159	——	" " Plate.....
44160	——	" " Shank.....
44161	5842	Presser Foot (hinged) complete, Nos. 26276, 44159 and 44160.....
44162	5842	Throat Plate for 44158.....
35995	5645	Presser Foot with right hand folder, for folding and stitching facing to shoe lining.....
36022	5645	Presser Foot with 665D and 36023, for blind stitch cording, for 12 to 44 ligne cord, for ornamental cording on skirts, suits, etc.....
36023	5645	Presser Foot Cord Guide for 36022.....

NOTE: When ordering Nos. 36022 or 36023, state the size or send sample of cord for which it is to be used.

665D	5645	Presser Foot Cord Guide Screw.....
36182	5808	" " with 665D and 36183, for blind stitch braiding, for soutache braid
36183	5808	Presser Foot Braid Guide.....

NOTE: When ordering Nos. 36182 or 36183, send sample of braid for which it is to be used.

665D	1388	Presser Foot Braid Guide Screw.....
36622	5808	" " for 36623.....
36623	5808	" " 36622 with 36576 and two 50202D.....
36576	5808	Presser Foot Finger Guard.....
50202D	5808	" " " " Screw.....

PRESSER FEET (Glass Plate)

NO.	PLATE	NAME
26607	1387	Presser Foot Body
26608	1387	" " Plate (glass)
26609	——	Presser Foot (glass plate) complete, Nos. 26607 and 26608

PRESSER FEET WITH GRADUATED ADJUSTABLE GUIDES

NO.	PLATE	NAME
28949	——	Presser Foot
28950	2658	" " Graduated Adjustable Guide
28951	2671	" " " " " Clamping Lever
2653	2671	Presser Foot Graduated Adjustable Guide Clamping Lever Hinge Pin
28952	2671	Presser Foot Graduated Adjustable Guide Clamping Lever Spring
26092	2671	Presser Foot Graduated Adjustable Guide Clamping Lever Spring Rivet
28953	2658	Presser Foot Graduated Adjustable Guide complete, for tailor work, Nos. 2653, 26092 and 28949 to 28952
35134	2671	Presser Foot
35002	2671	" " Extension
35003	2671	" " Graduated Adjustable Guide (long, left)
35004	2671	Presser Foot Graduated Adjustable Guide (long, right)
35005	2671	Presser Foot Graduated Adjustable Guide (short, right)
35006	2671	Presser Foot Graduated Adjustable Guide (short, right) flush
35135	2671	Presser Foot Graduated Adjustable Guide Clamp
35136	2671	Presser Foot Graduated Adjustable Guide Clamp Lever
337B	2671	Presser Foot Graduated Adjustable Guide Clamp Screw
36696	2671	Presser Foot Graduated Adjustable Guide Clamp Steady Pin
35137	——	Presser Foot with Extension and Graduated Adjustable Guide complete, Nos. 337B, 35002 to 35006, 35134 to 35136 and 36696

FOR 44-22 MACHINE

NO.	PLATE	NAME
28761	1390	Presser Foot with 219F and 28762, for stitching ribbon and net material.....
28762	1390	Presser Foot Ribbon Guide.....
219F	774	" " " " Screw.....

PRESSER FOOT EXTENSIONS

NO.	PLATE	NAME
12435	780	Presser Foot with 228D.....
2532	1371	" " Hinge Pin.....
20155	——	" " Plate.....
20156	——	" " Shank.....
20157	780	Presser Foot (hinged) complete, Nos. 228D, 2532, 20155 and 20156.....
26279	——	Presser Foot Extension, $\frac{1}{16}$ in., for 12435 and 20157.....
26280	——	Presser Foot Extension, ⅛ in., for 12435 and 20157.....
26281	1387	Presser Foot Extension, ¼ in., for 12435 and 20157.....
26282	——	Presser Foot Extension, ⅜ in., for 12435 and 20157.....
26283	——	Presser Foot Extension, ½ in., for 12435 and 20157.....
228D	2038	Presser Foot Extension Screw for 12435 and 20157.....
44158	5842	Feed Dog.....
26276	1394	Presser Foot Hinge Pin.....
44159	——	" " Plate.....
44160	——	" " Shank.....
44161	5842	Presser Foot (hinged) complete, Nos. 26276, 44159 and 44160.....
44162	5842	Throat Plate for 44158.....

PRESSER FOOT STRIP GAUGE

NO.	PLATE	NAME
12435	780	Presser Foot with 228D.....
2532	1371	" " Hinge Pin.....
20155	——	" " Plate.....
20156	——	" " Shank.....
20157	780	Presser Foot (hinged) complete, Nos. 228D, 2532, 20155 and 20156.....
25967	1387	Presser Foot Strip Gauge for 12435 and 20157.....
228D	2038	Presser Foot Strip Gauge Screw.....

PIPING ATTACHMENTS

NO.	PLATE	NAME
28621	1397	Piping Attachment and Strip Folder on Shank, for car-seat cushions.....
28622	1397	Presser Foot (grooved) for 28621.....
28740	2617	Piping Attachment on Shank.....
28803	2619	" " " " for flannel without cord.....
28974	2661	Piping Attachment on Shank.....
28975	2658	Presser Foot, 16 teeth, for 28974.....
12457	2699	Feed Dog, 16 teeth (16 teeth to the inch) for 35245.....
35246	2699	Presser Foot for 35245.....
12411	2699	Throat Plate for 12457.....
35245	2699	Piping Attachment on Shank.....
36129	5812	" " (double, adjustable) on Shank with upper edge folder.....
36131	5812	Presser Foot for 36129.....

QUILTERS

NO.	PLATE	NAME
25991	2029	Quilter Guide for 25990.....
25992	2029	" " Holder with two 207F.....
207F	2021	" " " Set Screw.....
207F	2021	" " Set Screw.....
25990	2029	Quilter complete, Nos. 25991 and 25992
28659	1392	" Guide for 28660.....
25992	1392	" " Holder with two 207F.....
207F	2021	" " " Set Screw.....
207F	2021	" " Set Screw.....
28660	1392	Quilter complete, Nos. 25992 and 28659..

RUFFLERS

RUFFLER (Power)

NO.	PLATE	NAME
26005	984	Driving Lever.....
69D	5742	" " Hinge Screw.....
35019	984	" " Spring.....
1666D	984	" " " Adjusting Nut....
26007	984	Foot.....
207F	2021	" Screw.....
26016	984	Frame.....
26017	984	Needle Clamp with 808F.....
808F	782	" " Screw.....

NO.	PLATE	NAME
26010	984	Ruffling Blade with 8505
811D	5742	" " Hinge Screw
26011	984	" " Lever with 26189 and 26629
812B	984	" " " Adjusting Thumb Screw
1621E	984	" " " " " " Nut
26629	2014	Ruffling Blade Lever Protector
26189	2014	" " " " Rivet
8505	773	" " Rivet
26018	984	Ruffler complete, Nos. 69D, 207F, 811D, 812B, 1621E, 1666D, 26005, 26007, 26010, 26011, 26016, 26017 and 35019
24303	1344	Feed Dog
24306	1344	Throat Plate for 24303

RUFFLER (Power)

NO.	PLATE	NAME
25997	984	Driving Lever
69D	5742	" " Hinge Screw
25998	984	" " Spring
1582D	984	" " " Adjusting Nut
25993	984	Frame with 25994 to 25996 and 26001
25995	2014	" Block
25996	2014	" " Rivet
25994	2014	" Stud
207F	2021	" " Set Screw
26718	1370	Needle Clamp Body
1943	1370	" " Roller
1115F	1370	" " Screw
26719	984	Needle Clamp complete, Nos. 1115F, 1943 and 26718
25999	984	Ruffling Blade
26002	2014	" " Clamp
337D	1388	" " " Screw
26000	984	" " Lever
560B	984	" " " Adjusting Thumb Screw
1603E	984	" " " " " " Nut
26001	2014	Ruffling Blade Lever Stop Pin
26229	984	" Presser Foot
26230	984	Ruffler complete, Nos. 69D, 207F, 560B, 1582D, 1603E, 25993, 25997 to 26000, 26002, 26229, 26719 and two 337D

RUFFLER (Power)

WITH RIGHT AND LEFT GUIDES, SEPARATING BLADES AND DISENGAGING LEVER TO THROW RUFFLING BLADE OUT OF ACTION

NO.	PLATE	NAME
26722	2035	Driving Lever
1101c	2035	" " Hinge Screw
26668	2035	" " Spring
1640c	2035	" " " Adjusting Nut
26669	2035	Frame
26670	2034	Guide (left) with 26679 and two 662D
26671	2035	" (right) with 26679 and two 662D
223D	2035	" Screw
26718	1370	Needle Clamp Body
1943	2034	" " Roller
1115F	2034	" " Screw
26719	2034	Needle Clamp complete, Nos. 1115F, 1943 and 26718
26675	2035	Ruffling Blade
26676	2035	" " Clamp
337D	2035	" " " Screw
26723	2034	" " Lever
812B	2035	" " " Adjusting Thumb Screw
1621E	2035	" " " " " " Nut
26678	2035	Ruffling Blade Lever Disengaging Lever
102D	2035	" " " " " Hinge Screw
2301	2035	Ruffling Blade Lever Disengaging Lever Stop Pin
26679	2035	Separating Blade
662D	2035	" " Screw
26724	2034	Ruffler complete, Nos. 102D, 223D, 812B, 1101c, 1621E, 1640c, 2301, 26668 to 26671, 26675, 26676, 26678, 26719, 26722, 26723 and two 337D

RUFFLER (Power)

WITH LEVER FOR THROWING RUFFLING BLADE INTO ACTION FOR INTERMITTENT RUFFLING, SUCH AS YOKING SKIRTS, ETC.

NO.	PLATE	NAME
28590	1371	Driving Lever
1101c	1371	" " Hinge Screw
1647c	1371	" " " " Nut

NO.	PLATE	NAME
28591	1371	Driving Lever Spring
28592	1371	" " " Collar
28593	1371	Frame
26718	1370	Needle Clamp Body
1943	1370	" " Roller
1115F	1370	" " Screw
26719	1370	Needle Clamp complete, Nos. 1115F, 1943 and 26718
28594	1371	Presser Foot (left)
185H	1371	" " " Screw
2532	1371	" " (right) Hinge Pin
28813	1371	" " " Plate
28596	1371	" " " Shank
28597	1371	" " " " Cap
198D	1371	" " " " " Screw
2656	1371	" " " " Spring
706D	1371	" " " " Stop Screw
2521	1371	" " " Spring
28814	——	Presser Foot (right) complete, Nos. 2521, 2532, 28596 and 28813
28815	1371	Ruffling Blade
24203	1371	" " Holder
226D	1371	" " " Cap Screw
24204	1371	" " " Spring
24205	1371	" " " " Stop
24206	1371	" " " Stud
1550J	1371	" " " " Nut
28607	1371	" " " Stop
28600	1371	" " Lever
560B	1371	" " " Adjusting Thumb Screw
1603E	1371	" " " " " " Nut
1049D	1371	Ruffling Blade Lever Stop Screw
665D	1371	" " Screw
28601	1371	Starting Lever with 190D
190D	1371	" " Clamping Screw
28816	1370	Ruffler complete, Nos. 185H, 226D, 560B, 706D, 1049D, 1101C, 1550J, 1603E, 1647C, 2656, 24203 to 24206, 26719, 28590 to 28594, 28597, 28600, 28601, 28607, 28814, 28815, two 665D and three 198D
28603	1370	Feed Dog for 28816
28817	1370	Throat Plate for 28603
28605	1372	Edge Folder (upper, right hand) with left hand lower guide and separating blade on shank, to fold top band only, for making yokes, for 28816

NO.	PLATE	NAME
28818	1372	Double Edge Folder (right hand) with separating blade, for ruffling shirt body and putting in yoke, for 28816.....

SEAMER

NO.	PLATE	NAME
26657	——	Seamer, for umbrella work.....
26361	——	" Edge Guide.....
26654	2032	" Rivet.....
26653	2032	" Shank.....
26658	2032	Seamer complete, Nos. 26361, 26653, 26654 and 26657.....

SEPARATING BLADE (Hinged)

FOR 44-22 MACHINE

NO.	PLATE	NAME
35279	2062	Separating Blade.....
35272	2061	" " Arm.....
35273	2061	" " " Bracket.....
76D	2061	" " " Hinge Screw.....
35274	2061	" " " Latch Lever with 35275.....
102D	2061	Separating Blade Arm Latch Lever Hinge Screw.....
10135	2061	Separating Blade Arm Latch Lever Spring
239D	2061	" " " " " " Screw.....
35275	2061	Separating Blade Arm Latch Lever Stud..
35276	2061	" " Holder.....
102D	2061	" " " Hinge Screw....
35277	2061	" " " Spring.....
108D	2061	" " " " Screw....
4604	2061	" " " " Stop Pin..
14026	2061	" " " Stop Pin.....
337D	2061	" " Screw.....
35280	——	Separating Blade (hinged) complete, Nos. 76D, 108D, 4604, 10135, 14026, 35272 to 35274, 35276, 35277, 35279, two each 102D, 239D and 337D.....
35283	2062	Edge Folder (lower, right hand) on Shank
35284	2064	" " (upper, left hand).....
217F	2061	" " Screw.....
35282	2064	" Guide (upper, left hand).....
217F	2061	" " " Screw.....
35285	2062	Presser Foot.....
35286	2062	Ruffling Blade.....

SPOOL HOLDER (Disc)

NO.	PLATE	NAME
26763	1352	Bracket with 219F and 287D.....
219F	774	" Screw.....
287D	2636	" Thumb Screw.....
19066	1352	Spindle.....
19067	1352	" Thread Guiding Disc.....
691F	782	" " " " Screw.....
26764	1352	Spool Holder (disc) complete, Nos. 691F, 19066, 19067 and 26763.....

THROAT PLATES

NO.	PLATE	NAME
26080	1383	Throat Plate Needle Plate for 26760 and 28342.....
337D	1383	Throat Plate Needle Plate Screw.....
26760	1383	" " with 337D and 26080, for 12369 or 12457, for underbraiding, for 44-1 and 44-13 Machines.....
28342	1383	Throat Plate with 337D and 26080, for 12450, for underbraiding, for 44-1 and 44-13 Machines.....
12450	1383	Feed Dog, 11 teeth (18 teeth to the inch) for 44-1, 44-13 and 44-20 Machines....
12369	1383	Feed Dog, 12 teeth (12 teeth to the inch)
12457	1383	" " 16 teeth (16 teeth to the inch)
28654	1383	Throat Plate, for underbraiding, for 12369 and 12457.....
19474	5813	Feed Dog.....
36906	5813	Throat Plate with under guide, for rick-rack, for 19474.....

TUBULAR TRIMMING ATTACHMENT

NO.	PLATE	NAME
35879	5643	Strip Wire.....
35880	5643	Feed Dog.....
35881	5643	Presser Foot (strip folding) with tube....
35018	5643	Tape Delivery Wire.....
35882	5643	Throat Plate for 35880.....
35883	——	Tubular Trimming Attachment complete, for making $\frac{1}{8}$ in., $\frac{5}{32}$ in. and $\frac{3}{16}$ in. trimmings, Nos. 35018 and 35879 to 35882

TUCKER

NO.	PLATE	NAME
26775	2036	Driving Lever.....
26129	2036	Foot.....

NO.	PLATE	NAME
26089	2036	Frame
5604	2036	" Rivet
26090	2036	Rocking Bar
26514	2036	" " Lifting Spring
26555	2036	" " Protector
26093	2036	Stop Bracket
26094	2036	Tuck Guide
658B	2036	" " Thumb Screw
26096	2036	" Marker Guide Clamp
561B	2036	" " " " Thumb Screw
26097	2036	" " " Rod
233B	2036	" " " " End Screw
26095	2036	" Marking Plate
26098	2036	" Smoothing Spring
26517	2036	Tucker complete, Nos. 233B, 561B, 658B, 5604, 26089, 26090, 26093 to 26098, 26129, 26514, 26555 and 26775

TUCKER (Power)

NO.	PLATE	NAME
26099	2037	Bed
26100	2037	Cloth Guide
291D	2038	" " Thumb Screw
26101	2037	" " Slide with 26102 and two 26092
4604	2038	Cloth Guide Slide Rivet
401E	2038	" " " Screw
26378	2037	Leveling Plate
12143	2037	Presser Foot
26368	2037	Tuck Marking Bar
26369	——	Tuck Marking Bar complete, Nos. 26368 and 26370 to 26372
26105	2037	Tuck Marking Bar Bracket
26106	2038	" " " " Hinge Pin
220D	2038	" " " " " " Set Screw
26107	2037	Tuck Marking Bar Lifting Spring
26108	2037	" " " Pressure Spring
26109	2037	" " " " " Clamp with 196F
196F	2038	Tuck Marking Bar Pressure Spring Clamp Set Screw
334D	2038	Tuck Marking Bar Set Screw
26370	2038	" " Pin
26371	2038	" " " Guide Pin
26372	2038	" " " Spring
26102	2037	" " Plate

NO.	PLATE	NAME
26092	2038	Tuck Marking Plate Rivet.....
26111	2037	" Smoothing Spring.....
4604	2038	" " " Rivet.....
26377	2037	Tucker complete, Nos. 220D, 291D, 334D, 401E, 12143, 26099 to 26101, 26105 to 26109, 26111, 26369, 26378 and three 4604.....
176D	2038	Tucker Screw.....

TUCKER (Long Arm)

FOR 44-1 AND 44-13 MACHINES

NO.	PLATE	NAME
26568	2635	Edge Guide.....
26569	2635	" " Slide.....
287D	2636	" " " Thumb Screw.....
7071	2636	" " " " " Washer..
939D	2636	" " Thumb Screw.....
26597	——	Edge Guide complete, Nos. 287D, 7071, 26568 and 26569.....
26686	2636	Presser Foot.....
26570	2634	Tuck Guide Plate.....
26571	2634	" " " Arm with 5944.....
58D	2636	" " " " Hinge Screw.....
26684	2634	" " " Bracket.....
732D	2636	" " " " Thumb Screw
5944	2636	" " " Guide Pin.....
287D	2636	" " " Thumb Screw.....
7071	2636	" " " " " Washer
26683	——	Tuck Guide Plate complete, Nos. 58D, 287D, 732D, 7071, 26570, 26571, 26684 and two wood screws 1 in. No. 12.....
26685	——	Tucker complete, Nos. 939D, 26597, 26683 and 26686.....

NOTE: Bed Frame No. 24108 is used with, but not included in, No. 26685.

TUCKER (Power)

FOR 44-20 MACHINE

This Tucker is the same as 26377 with the following exceptions:

NO.	PLATE	NAME
26123	2037	Tuck Marking Bar Pressure Spring, in place of 26108.....

NO.	PLATE	NAME
26687	——	Tucker complete, Nos. 220D, 291D, 334D, 401E, 12143, 26099 to 26101, 26105 to 26107, 26109, 26111, 26123, 26369 and three 4604.....

UNIVERSAL FELLING ATTACHMENTS

NO.	PLATE	NAME
26604	2033	Universal Felling Attachment complete..
35100	2682	Universal Felling Attachment with First Seam Guide, complete.....
26603	2033	Feed Dog.....
28360	2033	" " (15 conical teeth).....
120001	1381	" " (spiked teeth).....
7298	1378	Presser Foot Hinge Pin.....
19334	——	" " Plate.....
19335	——	" " Shank.....
19336	1378	Presser Foot (hinged) complete, Nos. 7298, 19334 and 19335.....
26605	2033	Throat Plate, large needle hole, for 26603, 28360 and 120001.....
26606	——	Throat Plate, small needle hole, for 26603, 28360 and 120001.....

NOTE: Nos. 19336, 26603, 28360 or 120001, 26605 or 26606 are used with, but not included in, Nos. 26604 or 35100.

SEAMING GUIDE

Used with Universal Felling Attachment No. 26604

NO.	PLATE	NAME
26777	1374	Arm.....
26778	1374	" Guide (upper).....
104D	1374	" " " Hinge Screw.....
26779	1374	" " " Spring.....
26780	1374	" Hinge Stud.....
26781	1374	" Locking Stud.....
26782	1374	" " " Spring.....
212D	1374	" Screw.....
26783	1374	Bracket with 196F.....
196F	1374	" Set Screw.....
26776	1374	Seaming Guide complete, Nos. 104D, 212D and 26777 to 26783.....

WELT GUIDE

(ADJUSTABLE) WITH SWITCH

NO.	PLATE	NAME
26143	2039	Bed
26144	2039	Cap
238D	2039	" Screw
26145	2039	Carrier
26146	——	" Slide
26344	2039	" " Stop
240D	2039	" " " Adjusting Screw
26147	2039	" Tongue
26148	——	Carrier complete, Nos. 233D, 26145 to 26147 and 26149
26138	2039	Carrier Slide Switch Cam with Shaft
26139	2039	" " " " Shaft Head with Lever with 337D
337D	2039	Carrier Slide Switch Cam Shaft Head Set Screw
910F	2039	Welt Guide Adjusting Screw
26149	2039	Width Guide
233D	2039	" " Screw
26150	2039	Welt Guide complete, Nos. 240D, 910F, 26138, 26139, 26143, 26144, 26148, 26344 and three 238D
190D	782	Welt Guide Screw
7071	2021	" " " Washer
26681	2039	Presser Foot
1928	2039	Roller, 1¼ in. diam., fine, with 386D and 1528J
16573	2039	Roller Arm
386D	5842	" Screw
1528J	5842	" " Nut
19394	——	Roller Presser complete, 1¼ in. fine roller, Nos. 1928 and 16573

NOTE: Presser Foot No. 26681 and Roller Presser No. 19394 are used with, but not included in, No. 26150.

BOBBIN WINDERS

BOBBIN WINDER

FOR 4370

NO.	PLATE	NAME
15072	2014	Bobbin Position Pin
12168	2003	Bracket
692D	783	" Screw

NO.	PLATE	NAME
12169	2003	Frame.....
12171	2003	Frame complete, Nos. 333D, 5960, 5961, 5963, 12169 and 15077.....
32D	782	Frame Hinge Screw.....
5960	768	Friction Wheel (leather).....
5961	768	" " Washer.....
333D	782	" " " Screw.....
15077	773	Spindle with 15072.....
5963	768	" Flange.....
12170	773	Spring.....
180F	782	" Screw.....
12172	——	Bobbin Winder complete, Nos. 32D, 180F, 12168, 12170 and 12171.....

BOBBIN WINDER

FOR 2135 AND 2862

This Bobbin Winder is the same as 12172 with the following exceptions:

NO.	PLATE	NAME
12201	2003	Frame complete, Nos. 333D, 5960, 5961, 5963, 12169 and 15077, in place of 12171
12202	——	Bobbin Winder complete, Nos. 32D, 180F, 12168, 12170 and 12201.....

BOBBIN WINDER

FOR 12358

This Bobbin Winder is the same as 12172 with the following exceptions:

NO.	PLATE	NAME
20307	8381	Frame, in place of 12169.....
20308	1311	Frame complete, Nos. 333D, 5960, 5961, 5963, 15077 and 20307, in place of 12171
20309	——	Bobbin Winder complete, Nos. 32D, 180F, 12168, 12170 and 20308.....

BOBBIN WINDER

(HAMBURG)

FOR 2135 AND 2862

This Bobbin Winder is the same as 12172 with the following exceptions:

NO.	PLATE	NAME
43981	6119	Frame, in place of 12169.....
43982	6119	Frame complete, Nos. 5960, 5961, 5963, 12336, 15077 and 43981, in place of 12171.....

NO.	PLATE	NAME
12336	2003	Spindle for spool, in place of 333D.....
12337	——	Bobbin Winder complete, Nos. 32D, 180F, 12168, 12170 and 43982.....

BOBBIN WINDER

(HAMBURG)
FOR 4370

This Bobbin Winder is the same as 12172 with the following exceptions:

NO.	PLATE	NAME
43981	6119	Frame, in place of 12169.....
43983	6119	Frame complete, Nos. 5960, 5961, 5963, 12336, 15077 and 43981, in place of 12171.....
12336	2003	Spindle for spool, in place of 333D.....
20498	——	Bobbin Winder complete, Nos. 32D, 180F, 12168, 12170 and 43983.....

BOBBIN WINDER

(SWINGING AUTOMATIC, RIGHT HAND)
FOR 2996
FOR POWER TABLE

NO.	PLATE	NAME
27552	1162	Base.....
15072	2014	Bobbin Position Pin.....
27302	1162	Frame.....
50356D	5806	" Hinge Screw.....
1620J	5806	" " " Nut.....
27303	773	" Spring.....
27553	1162	Pulley.....
27538	1162	Spindle with 15072.....
27306	1162	Spool Pin.....
27307	1162	" Stand.....
27308	1162	Spool Stand complete, Nos. 418E, 1562J, 2106, 10141, 11241, 27306, 27307 and two each 2455 and wood screws 1 in. No. 10.....
11241	2003	Spool Washer (cloth).....
27312	2003	Stop Latch.....
35D	1366	" " Hinge Screw.....
2455	2014	Tension Disc.....
1562J	2014	" Regulating Thumb Nut.....
418E	2014	" Screw Stud.....
10141	2014	" Spring.....
2106	2014	" Thread Guide.....

NO.	PLATE	NAME
27650	——	Bobbin Winder, Nos. 35D, 1620J, 27302, 27303, 27312, 27538, 27552, 27553, 50356D and two wood screws 1 in. No. 7
27554	——	Bobbin Winder (swinging automatic, right hand) complete, Nos. 27308 and 27650

BOBBIN WINDER

(SWINGING AUTOMATIC, RIGHT HAND)
FOR 2996
FOR STAND

This Bobbin Winder is the same as 27554 with the following exceptions:

NO.	PLATE	NAME
27540	2445	Base, in place of 27552.....
27541	2445	Pulley, in place of 27553.....
27647	2445	Bobbin Winder, Nos. 35D, 1620J, 27302, 27303, 27312, 27538, 27540, 27541, 50356D and two wood screws 1 in. No. 7, in place of 27650.....
27544	——	Bobbin Winder (swinging automatic, right hand) complete, Nos. 27308 and 27647

BOBBIN WINDER

(SWINGING AUTOMATIC, RIGHT HAND)
FOR 19131
FOR POWER TABLE

This Bobbin Winder is the same as 27554 with the following exceptions:

NO.	PLATE	NAME
27587	1162	Stop Latch, in place of 27312.....
27651	1162	Bobbin Winder, Nos. 35D, 1620J, 27302, 27303, 27538, 27552, 27553, 27587, 50356D and two wood screws 1 in. No. 7, in place of 27650.....
27588	——	Bobbin Winder (swinging automatic, right hand) complete, Nos. 27308 and 27651

BOBBIN WINDER

(SWINGING AUTOMATIC, RIGHT HAND)
FOR 19131
FOR STAND

This Bobbin Winder is the same as 27554 with the following exceptions:

NO.	PLATE	NAME
27540	2445	Base, in place of 27552.....

NO.	PLATE	NAME
27541	2445	Pulley, in place of 27553
27587	1162	Stop Latch, in place of 27312
27875	——	Bobbin Winder, Nos. 35D, 1620J, 27302, 27303, 27538, 27540, 27541, 27587, 50356D and two wood screws 1 in. No. 7, in place of 27650
27876	——	Bobbin Winder (swinging automatic, right hand) complete, Nos. 27308 and 27875

BOBBIN WINDER

(SWINGING AUTOMATIC, RIGHT HAND) FOR 24051 FOR 44-20 MACHINE

This Bobbin Winder is the same as 27554 with the following exceptions:

NO.	PLATE	NAME
27699	2003	Stop Latch, in place of 27312
27700	——	Bobbin Winder, Nos. 35D, 1620J, 27302, 27303, 27538, 27552, 27553, 27699, 50356D and two wood screws 1 in. No. 7, in place of 27650
27701	——	Bobbin Winder (swinging automatic, right hand) complete, Nos. 27308 and 27700

BOBBIN WINDER

(SWINGING AUTOMATIC, RIGHT HAND) FOR 2996, 19131 AND 24051 FOR POWER TABLE

NO.	PLATE	NAME
*225451	——	Bobbin Holder
225463	3469	" Winder and Tension Bracket Base
225453	3470	Frame with 202277 and 225438
225454	3471	" Hinge Pin
202277	3471	" Oil Packing (wick)
225438	3471	" " Well Cap
225455	3471	" Spring
225456	3471	" " Plunger
202473	3470	Pulley with 200380c
200380c	3471	" Set Screw
*225443	——	Spindle
225452	3470	" 225443 with 225451
225444	3471	Stop Latch
200056E	3471	" " Screw
225458	3471	" " Thumb Lever
225459	3471	" " " " Hinge Stud
225460	3471	" " " " Joint Stud
202478	3471	" " Trip Lever

NO.	PLATE	NAME
200299H	3471	Stop Latch Trip Lever Hinge Screw.....
225461	3471	Tension Bracket with 201499B.....
200082D	3471	" " Screw.....
202104	3471	" " " Washer.....
2102	3471	" Disc.....
202407	3471	" Spring.....
201499B	3471	" Stud.....
201572B	3471	" " Thumb Nut.....
225462	——	Tension Bracket complete, Nos. 201572B, 202407, 225461 and two 2102.....
225436	3469	Bobbin Winder (swinging automatic, right hand) complete, Nos. 200056E, 200082D, 200299H, 202104, 202473, 202478, 225444, 225452 to 225456, 225458 to 225460, 225462, 225463 and two wood screws ¾ in. No. 13 R. H. B.....

DRIVING ATTACHMENT

FOR 44-1 TO 44-3, 44-8, 44-9, 44-23, 44-28, 44-72 AND 44-75 MACHINES

NO.	PLATE	NAME
16592	1230	Balance Wheel (friction) with 7958, 16524 and two 435C.....
16524	——	Balance Wheel Friction Ring (leather)...
7958	5843	" " " " Stop Pin...
24355	1315	" " Oil Cover.....
210D	1343	" " " " Screw.....
435C	5806	" " Set Screw.....
15072	2014	Bobbin Position Pin for 15077.....
16514	768	" Winder Frame.....
32D	782	" " " Hinge Screw.....
16515	768	Bobbin Winder Frame complete, Nos. 333D, 5960, 5961, 5963, 15077 and 16514
5960	768	Bobbin Winder Friction Wheel (leather)...
5961	768	" " " " Washer....
333D	782	" " " " " Screw
15077	773	" " Spindle with 15072.....
5963	768	" " " Flange.....
27306	1162	" " Spool Pin.....
27307	1162	" " " Stand.....
27308	1162	Bobbin Winder Spool Stand complete, Nos. 418E, 1562J, 2106, 10141, 11241, 27306, 27307 and two each 2455 and wood screws 1 in. No. 10.....
11241	2003	Bobbin Winder Spool Washer (cloth)....
12170	773	" " Spring.....

NO.	PLATE	NAME
180F	782	Bobbin Winder Spring Screw
16516	774	" " Stop Latch with 152F and 1550J
152F	782	Bobbin Winder Stop Latch Adjusting Screw
1550J	783	Bobbin Winder Stop Latch Adjusting Screw Nut
75D	782	Bobbin Winder Stop Latch Hinge Screw
27303	773	" " " " Spring
2269	773	" " " " Stop Pin
2455	2014	" " Tension Disc
1562J	2014	" " " Regulating Thumb Nut
418E	2014	Bobbin Winder Tension Screw Stud
10141	2014	" " " Spring
2106	2014	" " " Thread Guide
16530	1230	Bracket
692D	783	" Screw
16528	1230	Drip Pan with four 1 in. wire nails
16518	1230	Driving Arm with 2269, 2928 and two 15132
2928	774	Driving Arm Brake (leather)
15132	773	" " " Rivet
12178	774	" " Friction Plug (wood)
427E	783	" " " " Adjusting Screw
1508C	783	Driving Arm Friction Plug Adjusting Screw Nut
693D	782	Driving Arm Hinge Screw
1579C	783	" " " " Nut
16519	1348	" " Pitman
16520	768	" " " Crank with 803C and 1520E
803C	782	Driving Arm Pitman Crank Adjusting Screw
1520E	783	Driving Arm Pitman Crank Adjusting Screw Nut
2022	773	Driving Arm Pitman Crank Pin
16521	768	" " " " Spring
24528	8381	" " " " " Adjusting Collar with three 448C
448C	783	Driving Arm Pitman Crank Spring Adjusting Collar Set Screw
65D	782	Driving Arm Pitman Hinge Screw

NO.	PLATE	NAME
16522	——	Driving Arm complete, Nos. 32D, 75D, 180F, 427E, 693D, 1508C, 1579C, 12170, 12178, 16515, 16516, 16518, 16530 and 27303
16594	1230	Driving Friction Pulley, $2\frac{5}{16}$ in. diam., with 861D and two 10236
10236	774	Driving Friction Pulley Centre Bearing
861D	5742	" " " Oil Hole Plug Screw
27072	——	Shaft Driving Pulley (sectional, grooved) 12 in. diam., $1\frac{3}{16}$ in. bore, with two 597C
597C	——	Shaft Driving Pulley Clamping Screw
12189	768	Starting Crank
2022	773	" " Pin
16525	1350	" " Shaft
24529	8381	" " " Bracket with 24528
130D	782	" " " " Screw
24530	——	Starting Crank Shaft Bracket complete, Nos. 12189, 16520, 16521, 16525, 24529 and two 2022
27636	363	Treadle
9082	773	" Bearing Cotter Pin
27637	1230	" Pitman Rod (lower)
27638	5841	" " " " Spring
6055	5843	" " " " " Washer
2877	1230	" " " (upper) for 15130
14081	1230	" " " " " 14233
9079	2638	" " " Clamp with 354C
354C	2638	" " " " Screw
15130	1230	Treadle Pitman complete, Nos. 2762, 2877, 6055, 9079, 27637 and 27638
14233	1230	Treadle Pitman complete, for bench stand, Nos. 2762, 6055, 9079, 14081, 27637 and 27638
2878	363	Treadle Stand
27642	——	Treadle complete, Nos. 2878, 9082, 27636 and four wood screws 1 in. No. 16
15131	——	Treadle and Pitman complete, Nos. 15130 and 27642
14234	——	Treadle and Pitman complete, Nos. 14233 and 27642
2762	1206	Treadle Stop Collar with 362F
362F	2009	" " " Set Screw
16531	——	Driving Attachment with Bobbin Winder and Treadle complete, Nos. 210D, 692D, 14234 or 15131, 16519, 16522, 16592, 16594, 24355, 24530, 27072, 27308, two 65D and three 130D

DRIVING ATTACHMENT

FOR 44-13, 44-17, 44-20, 44-22, 44-24, 44-29 AND 44-74 MACHINES

This Driving Attachment is the same as 16531 with the following exceptions:

NO.	PLATE	NAME
19258	2009	Bobbin Winder Stop Latch with 152F and 1550J, in place of 16516.....
19260	——	Driving Arm complete, Nos. 32D, 75D, 180F, 427E, 693D, 1508C, 1579C, 12170, 12178, 16515, 16518, 16530, 19258 and 27303, in place of 16522.....
24073	——	Driving Attachment with Bobbin Winder and Treadle complete, Nos. 210D, 692D, 14234 or 15131, 16519, 16592, 16594, 19260, 24355, 24530, 27072, 27308, two 65D and three 130D.....

FOOT LEVER PARTS

NO.	PLATE	NAME
24378	2637	Foot Lever with two 1157C.....
24379	2637	" " 24378 with 5671, 24380, 24381 and four wood screws 1 in. No. 12.....
24380	2637	Foot Lever Bracket.....
5671	2638	" " Hinge Pin.....
24381	2637	" Rest with 24382.....
24382	2638	" " Pin.....
1157C	2638	" " Set Screw.....
24383	2637	Pitman Rod (lower) 17 in. long.....
24384	2638	" " " Stop Collar with 1157C
1157C	2638	" " " " " " Set Screw
24385	2637	" " (upper) 17 in. long, with 2761
2761	2638	" " " Cap.....
24386	2637	" " " Guide Bracket with three wood screws 1 in. No. 12.....
9079	2638	Pitman Rod Clamp with 354C.....
354C	2638	" " " Screw.....
24387	——	Foot Lever complete, Nos. 9079, 24379, 24383, 24385, 24386 and two 24384....

FOOT LIFTER PARTS

NO.	PLATE	NAME
5596	768	Bell Crank.....
56848	——	" " 5596 with 5599 and 5601.....
5599	768	" " Bracket.....

NO.	PLATE	NAME
178E	782	Bell Crank Bracket Screw
5601	773	" " Hinge Pin
5735	1353	" " Spring
5598	768	Bell Crank complete, Nos. 5735 and 56848
5670	——	Chain, length 26 in. to 35 in.
		NOTE: When ordering No. 5670, state length required.
4879	2004	Chain Connecting Link
16510	766	Lifting Lever with 448c, for 19331
16585	1315	" " " " " 24426
19371	1311	" " " " " 24427, 62573 and 62697
12415	768	Lifting Lever Connecting Rod for 19331, 24426, 24427 and 62573
20255	8381	Lifting Lever Connecting Rod for 62697
12416	774	" " " " Joint
76D	782	" " " " " Hinge Screw
1521E	772	Lifting Lever Connecting Rod Lock Nut
802D	782	" " Hinge Screw
12241	772	" " Link for 19331 and 24426
21301	1353	" " " " 24427, 62573 and 62697
766D	782	Lifting Lever Link Hinge Screw
12240	772	" " Pin for 19331
16586	5843	" " " " 24426
19372	1313	" " " " 24427 and 62697
62572	8381	" " " " 62573
448c	783	" " " Set Screw
2763	1231	Rock Shaft
12242	1231	" " Hanger with two wood screws, 1 in. No. 10
6337	1231	Rock Shaft Lifting Bracket with two 356c
12243	1231	" " " " Hook for 4880
7125	1231	" " " " " " "
356c	783	" " " " " Set Screw
356c	783	" " " " Set Screw
2770	1231	" " Stop Dog with 356c
356c	783	" " " " Set Screw
4880	1231	Rock Shaft complete, Nos. 2763, 2770, 7125, 12243 and two each 6337 and 12242
4881	1231	Treadle
4882	2004	" Shaft
4883	2004	" Spring
4884	1231	" Stand

NO.	PLATE	NAME
4885	1231	Treadle complete, Nos. 4879, 4881 to 4884 and two wood screws 1 in. No. 16.....
19331	——	Foot Lifter complete for 44-1 to 44-3, 44-13, 44-17, 44-20, 44-22, 44-24 and 44-29 Machines, Nos. 76D, 766D, 802D, 1521E, 4880, 4885, 5598, 5670, 12240, 12241, 12415, 12416, 16510 and two 178E.....
24426	——	Foot Lifter complete for 44-8 and 44-28 Machines, Nos. 76D, 766D, 802D, 1521E, 4880, 4885, 5598, 5670, 12241, 12415, 12416, 16585, 16586 and two 178E.....
24427	——	Foot Lifter complete for 44-9 and 44-23 Machines, Nos. 76D, 766D, 802D, 1521E, 4880, 4885, 5598, 5670, 12415, 12416, 19371, 19372, 21301 and two 178E.....
62573	——	Foot Lifter complete for 44-75 Machine, Nos. 76D, 766D, 802D, 1521E, 4880, 4885, 5598, 5670, 12415, 12416, 19371, 21301, 62572 and two 178E.....
62697	——	Foot Lifter complete for 44-72 Machine, Nos. 76D, 766D, 802D, 1521E, 4880, 4885, 5598, 5670, 12416, 19371, 19372, 20255, 21301 and two 178E.....

KNEE LIFTER PARTS

NO.	PLATE	NAME
5596	768	Bell Crank.....
56848	——	" " 5596 with 5599 and 5601.....
5599	768	" " Bracket.....
178E	782	" " " Screw.....
5601	773	" " Hinge Pin.....
5735	1353	" " Spring.....
5598	768	Bell Crank complete, Nos. 5735 and 56848
16510	766	Lifting Lever with 448C, for 16512 and 24161.....
19371	1311	Lifting Lever with 448C, for 19373, 24482 and 62574.....
16585	1315	Lifting Lever with 448C, for 16587.....
12415	768	" " Connecting Rod for 16512, 16587, 19373, 24161 and 62574.....
20255	8381	Lifting Lever Connecting Rod for 24482...
12416	774	" " " " Joint.....
76D	782	" " " " " Hinge Screw.....
1521E	772	Lifting Lever Connecting Rod Lock Nut..

NO.	PLATE	NAME
802D	782	Lifting Lever Hinge Screw.....
12241	772	" " Link for 16512, 16587 and 24161.....
21301	1353	Lifting Lever Link for 19373, 24482 and 62574.....
766D	782	Lifting Lever Link Hinge Screw.....
12240	772	" " Pin for 16512 and 24161...
16586	5843	" " " " 16587.....
19372	1313	" " " " 19373 and 24482...
62572	8381	" " " " 62574.....
448C	783	" " " Set Screw.....
2759	1348	" Rod with 2761.....
2761	2638	" " Cap (washer).....
2762	1206	" " Collar with 362C.....
362C	2009	" " " Set Screw.....
2760	——	Lifting Rod complete for 19168, Nos. 2759 and 2762.....
2763	766	Rock Shaft.....
12242	766	" " Hanger with two wood screws 1 in. No. 10.....
2765	766	Rock Shaft Knee Arm for 2768.....
6335	1348	" " " " " 6336.....
2766	766	" " " " Hub with 356C...
356C	783	" " " " " Set Screw...
2768	——	Rock Shaft Knee Arm complete for 2777, Nos. 2765 to 2767.....
6336	——	Rock Shaft Knee Arm complete for 19168, Nos. 2766, 2767 and 6335.....
2767	766	Rock Shaft Knee Plate with 356C.....
356C	783	" " " " Set Screw.....
2769	1348	" " Lifting Arm with 356C.....
356C	783	" " " " Set Screw.....
6337	766	" " " Bracket with two 356C
2778	766	" " " " Hook.....
356C	783	" " " " " Set Screw
356C	783	" " " " Set Screw.....
2770	766	" " Stop Dog with 356C.....
356C	783	" " " " Set Screw.....
2777	766	Rock Shaft complete for 16512, 16587, 19373, 24482 and 62574, Nos. 2763, 2768, 2770, 2778, 6337 and two 12242
19168	——	Rock Shaft complete for 24161, Nos. 2760, 2763, 2769, 6336 and two each 2770 and 12242.....

NO.	PLATE	NAME
16512	——	Knee Lifter complete (power table) for 44-1 to 44-3, 44-17, 44-20, 44-22, 44-24 and 44-29 Machines, Nos. 76D, 766D, 802D, 1521E, 2777, 5598, 12240, 12241, 12415, 12416, 16510 and two 178E.....
16587	——	Knee Lifter complete (power table) for 44-8 and 44-28 Machines, Nos. 76D, 766D, 802D, 1521E, 2777, 5598, 12241, 12415, 12416, 16585, 16586 and two 178E
19373	——	Knee Lifter complete (power table) for 44-9 and 44-23 Machines, Nos. 76D, 766D, 802D, 1521E, 2777, 5598, 12415, 12416, 19371, 19372, 21301 and two 178E
24161	——	Knee Lifter complete (bench stand) for 44-1 to 44-3, 44-13, 44-17, 44-20, 44-22, 44-24 and 44-29 Machines, Nos. 76D, 766D, 802D, 1521E, 5598, 12240, 12241, 12415, 12416, 16510, 19168 and two 178E
24482	——	Knee Lifter complete (power table) for 44-72 Machine, Nos. 76D, 766D, 802D, 1521E, 2777, 5598, 12416, 19371, 19372, 20255, 21301 and two 178E.....
62574	——	Knee Lifter complete (power table) for 44-75 Machine, Nos. 76D, 766D, 802D, 1521E, 2777, 5598, 12415, 12416, 19371, 21301, 62572 and two 178E.....

KNIFE GRINDER

FOR 5726

NO.	PLATE	NAME
27565	1104	Emery Wheel, 2 in. diam.....
1508C	1105	" " Clamping Nut.....
27822	1105	" " " " Washer....
27567	1105	" " Shaft.....
60934	——	" " " 27567 with 1508E, 27565, 27569 and 27822.....
27568	1105	Emery Wheel Shaft Oil Hole Cover (rubber).....
27569	1105	Emery Wheel Shaft Pulley.....
310F	1105	" " " Screw Centre.....
1516D	1105	" " " " " Nut...
27564	1104	Frame with 27574.....
899D	1105	Knife Clamping Screw.....
27657	——	" Holder Body for 27658.....
27679	——	" " " " 27681.....
27680	——	" " " " 27682.....

NO.	PLATE	NAME
27658	1105	Knife Holder complete for 5726 for 27661, Nos. 899D, 27657 and 27660
27681	6255	Knife Holder complete, Nos. 899D, 11833, 27660 and 27679
27682	6255	Knife Holder complete, Nos. 899D, 11833, 27660 and 27680
27323	1105	Knife Holder Guide Bar
27572	1104	" " " " Bracket with 27574
310F	1105	Knife Holder Guide Bar Bracket Screw Centre
1516D	1105	Knife Holder Guide Bar Bracket Screw Centre Nut
27573	1105	Knife Holder Guide Bar Bracket Spring
27574	1105	" " " " " " Hook
27659	1105	Knife Holder Stop Collar with 237F
237F	1105	" " " " Set Screw
27660	6255	" Position Pin for 27658
27660	6255	" " " (lower) for 27681 and 27682
11833	6255	Knife Position Pin (upper) for 27681 and 27682
261D	1105	Knife Regulating Thumb Screw
60583	——	Knife Grinder, Nos. 261D, 27323, 27564, 27572, 27573, 27659, 60934, two 27568 and four each 310F and 1516D
27661	——	Knife Grinder complete, Nos. 27662, 60583, either 27658, 27681 or 27682 and three wood screws 1 in. No. 10
27662	1104	Wrench for 1508 and 1516

STAND

ROCKING TREADLE, BALL BEARING PITMAN

NO.	PLATE	NAME
25301	3825	Band Wheel, 16 in. diam., with 972C
46519	3825	" " Crank
46520	——	Band Wheel Crank and Pitman (ball bearing) complete, Nos. 1520R, 25371, 46506 to 46509, 46519, 46523, 46630, 46655 and six 25362
296C	3826	Band Wheel Crank Screw Centre
46661	——	" " " " " 296C with 1507J
1507J	3826	Band Wheel Crank Screw Centre Nut
972C	3826	" " Set Screw

NO.	PLATE	NAME
25016	——	Belt, size ¼ in., length 69½ in., with 25127
25127	3826	" Hook
46533	6142	Brace with 46661 and two 46629
748E	3826	" Screw
46662	6142	Brace (sectional) complete, Nos. 46528, 46663 and three 880E
46528	6142	Brace Section (left) with 46629
46663	6142	" " (right) with 46629 and 46661
880E	5843	" " Screw
46522	3825	Leg
25362	3826	Pitman Ball, size $\frac{3}{16}$ in.
46506	3826	" " Bearing Adjusting Screw Ring
46507	3826	" " " " " " Locking Washer (brass)
46508	3826	Pitman Ball Bearing Ring
46509	3826	" " Case
46655	3826	" " Separator
46523	3825	" Rod with 25360
*25360	——	" " Ball
25371	3826	" " " Bushing
25361	3826	" " " Screw Bearing
46630	——	" " " " " 25361 with 1670E
1670E	3826	Pitman Rod Ball Screw Bearing Nut
1520R	3826	" " Lock Nut
46524	3825	Treadle
297C	3826	" Screw Centre
46629	——	" " " 297C with 1507J
1507J	3826	" " " Nut
25086	3825	Wrench for 1507 and 1670
25200	3825	" " 972
25265	——	Stand (iron work) rocking treadle, ball bearing pitman, complete, Nos. 25086, 25200, 25301, 46520, 46524, 46533, two 46522 and four 748E

STAND

FOR ELECTRIC MOTOR

NO.	PLATE	NAME
296C	3826	Band Wheel Crank Screw Centre
46661	——	" " " " " 296C with 1507J
1507J	3826	Band Wheel Crank Screw Centre Nut
25490	——	Belt, size ¼ in., length 36 in., with 25127
25127	3826	" Hook

NO.	PLATE	NAME
46533	6142	Brace with 46661 and two 46629.....
748E	3826	" Screw.....
46662	6142	Brace (sectional) complete, Nos. 46528, 46663 and three 880E.....
46528	6142	Brace Section (left) with 46629.....
46663	6142	" " (right) with 46629 and 46661
880E	5843	" " Screw.....
46522	3825	Leg.....
7958	8380	Pitman Pin.....
25082	8382	Treadle.....
297C	3826	" Screw Centre.....
46629	——	" " " 297C with 1507J...
1507J	3826	" " " Nut.....
25086	3825	Wrench for 1507.....
25279	——	Stand (iron work) complete, Nos. 7958, 25082, 25086, 46533, two 46522 and four 748E.....

STAND

ROCKING TREADLE, BALL BEARING PITMAN. FOR FOOT POWER AND S. D. 11 OR S. D. 12 ELECTRIC MOTORS

NO.	PLATE	NAME
25301	3825	Band Wheel, 16 in. diam., with 972C.....
46519	3825	" " Crank.....
46656	——	Band Wheel Crank and Pitman (ball bearing) complete, Nos. 1520R, 25371, 46506 to 46509, 46519, 46630, 46655, 46658J to 46660J and six 25362.....
296C	3826	Band Wheel Crank Screw Centre.....
46661	——	" " " " " 296C with 1507J.....
1507J	3826	Band Wheel Crank Screw Centre Nut...
972C	3826	" " Set Screw.....
25016	——	Belt, size ¼ in., length 69½ in., with 25127, from band wheel to machine.....
46657	——	Belt, size ¼ in., length 36½ in., with 25127, from motor to machine.....
25127	3826	Belt Hook.....
46533	6142	Brace with 46661 and two 46629.....
748E	3826	" Screw.....
46662	6142	Brace (sectional) complete, Nos. 46528, 46663 and three 880E.....
46528	6142	Brace Section (left) with 46629.....
46663	6142	" " (right) with 46629 and 46661
880E	5843	" " Screw.....

NO.	PLATE	NAME
46522	3825	Leg
25362	3826	Pitman Ball, size $\frac{3}{16}$ in.
46506	3826	" " Bearing Adjusting Screw Ring
46507	3826	" " " " " " Locking Washer (brass)
46508	3826	Pitman Ball Bearing Ring
46509	3826	" " Case
46655	3826	" " Separator
46658	5843	" Rod (lower) with 25360
*25360	——	" " " Ball
25371	3826	" " " " Bushing
25361	3826	" " " " Screw Bearing
46630	——	" " " " " " 25361 with 1670E
1670E	3826	Pitman Rod (lower) Ball Screw Bearing Nut
46659	5841	Pitman Rod (upper)
1520R	3826	" " " Lock Nut
46660	5843	" " Coupling
46524	3825	Treadle
297C	3826	" Screw Centre
46629	——	" " " 297c with 1507J
1507J	3826	" " " Nut
10875	5841	Wrench for 46660
25086	3825	" " 1507 and 1670
25200	3825	" " 972
25284	——	Stand (iron work) rocking treadle, ball bearing pitman, complete, Nos. 10875, 25086, 25200, 25301, 46524, 46533, 46656, two 46522 and four 748E
67175	5843	Hook for 67072
67176	8383	Treadle Pitman Rod (lower)
67086	8383	" " " (upper)
9079	8383	" " " Clamp with 354c
354c	774	" " " " Screw
67177	8383	Treadle Pitman complete, Nos. 9079, 67086 and 67176

TRIMMINGS FOR END AND BACK LEAF TABLE

NO.	PLATE	NAME
25001	3825	Back Leaf Bracket with two wood screws 1 in. No. 10
25002	3825	Back Leaf Scroll Bracket with ¾ in. No. 9 and two 1 in. No. 12 wood screws

NO.	PLATE	NAME
25003	3825	Back Leaf Sliding Hinge, Nos. 25149, three 25151 and six wood screws ¾ in. No. 8
25151	3825	Back Leaf Sliding Hinge Plate.....
25149	3825	" " " " Rod.....
25057	3825	End Leaf Support complete, Nos. 25143, 25168, 25169 and two wood screws ⅝ in. No. 7.....
25168	3825	End Leaf Support Bracket.....
25060	3825	" " " Button with wood screw 1½ in. No. 12 R. H. B.....
25169	3825	End Leaf Support Lever.....
25143	5742	" " " " Hinge Pin.....
20022	5742	Machine Rest (felt) for machine on stand

THREAD UNWINDERS

THREAD UNWINDER

FOR ONE LARGE SPOOL OR ONE LARGE CONE OF THREAD

NO.	PLATE	NAME
27623	2836	Spool Pin.....
155c	5843	" " Set Screw.....
41526	2836	" Rest.....
60701	——	" " 41526 with 155c and 1149c...
41527	——	" " 60701 with 27623.....
1149c	5742	" " Set Screw.....
27940	2836	" Stand with 453c.....
41514	2836	" Weight, 4 in. diam., with 41515....
41515	5742	" " Centre Pin.....
27739	2836	Thread Cone (wood).....
41630	2836	" Guard with 208E and 41569.....
41569	5842	" " Eyelet.....
41637	2836	" " Rod (lower).....
41638	2836	" " " (upper).....
41639	2836	" " " Coupling with two 456c
456c	773	" " " " Set Screw....
41640	——	Thread Guard Rod complete, 30 in. long, Nos. 41637 to 41639.....
453c	783	Thread Guard Rod Set Screw.....
208E	782	" " Screw.....
41529	2836	Thread Unwinder complete, Nos. 27739, 27940, 41514, 41527, 41630, 41640 and three wood screws 1 in. No. 12.....

THREAD UNWINDER

FOR TWO LARGE SPOOLS OR TWO LARGE CONES OF THREAD

NO.	PLATE	NAME
27623	2837	Spool Pin
155c	5843	" " Set Screw
41530	2837	" Rest
60455	——	" " 41530 with 1149c and two 155c
41531	——	" " 60455 with two 27623
1149c	5742	" " Set Screw
27940	2837	" Stand with 453c
41514	2837	" Weight, 4 in. diam., with 41515
41515	5742	" " Centre Pin
27739	2837	Thread Cone (wood)
41631	2837	" Guard with 208E and two 41569
41569	5842	" " Eyelet
41637	2837	" " Rod (lower)
41638	2837	" " " (upper)
41639	2837	" " " Coupling with two 456c
456c	773	" " " " Set Screw
41640	——	Thread Guard Rod complete, 30 in. long, Nos. 41637 to 41639
453c	783	Thread Guard Rod Set Screw
208E	782	" " Screw
41533	2837	Thread Unwinder complete, Nos. 27940, 41531, 41631, 41640, two each 27739, 41514 and three wood screws 1 in. No. 12

OBSOLETE PARTS

NO.	PLATE	NAME
26755	953	Adjustable Edge and Strip Guide with Separating Blade complete for 44-22 Machine
16532	1369	Arm Dowel Pin
16502	——	" Shaft for 44-1 Machine
19219	1206	Bed Frame Cushion (leather) for 19218 and 19399
12405	774	Bed Frame Cushion (felt) for 16554
180c	782	" " " Screw
19220	1206	" " " Spring for 19218 and 19399
19226	1206	Bed Frame Hinge Connection for 19228 and 19398
19227	1369	Bed Frame Hinge Connection Cap for 19228, use 19397

NO.	PLATE	NAME
19397	1206	Bed Frame Hinge Connection Cap for 19398
211F	1206	Bed Frame Hinge Connection Cap Screw
19228	——	Bed Frame Hinge Connection complete, Nos. 211F, 19226 and 19227, use 19398
19398	——	Bed Frame Hinge Connection complete for 19399, Nos. 211F, 19226 and 19397
16555	1206	Bed Frame Hinge Plate for 16554, 19218 and 19399
14010	1206	Bed Frame Hinge Plate Rivet
16554	——	" " with two 16555, four each 180C, 12405 and six wood screws 1¼ in. No. 10, use 24108
19218	——	Bed Frame with two 16555, four each 19219, 19220, six each 14010, wood screws 1¼ in. No. 10 and eight 158C, use 24108
19399	1231	Bed Frame complete, Nos. 970D, two each 16555, 19398, four each 19219, 19220, six each 14010, wood screws 1¼ in. No. 10 and eight 158C, use 24108
5602	772	Bell Crank Spring for 5598
12484	2003	Bobbin Winder Spring for 12172, 12202 and 12337
12365	1350	Crank Connecting Rod with 14013 and two 896E, for 375
12496	1350	Crank Connecting Rod with 14013 and two 896E, for 908, use 20197
*14013	——	Crank Connecting Rod Cap for 12365 and 12496
375C	782	Crank Connecting Rod Hinge Screw
1518E	783	" " " " " Nut for 375
24030	——	Face Plate
24031	1351	Face Plate complete for 44-20 Machine, Nos. 934E, 9545, 12150, 12152, 24030, 24033, 24072 and two 24032
24032	1369	Face Plate Thread Retainer Disc
24072	1369	" " " " " Cover
934E	——	" " " " " " Screw
9545	1369	Face Plate Thread Retainer Disc Spring
24033	1369	" " " " Thread Guard
20009	1258	Feed Dog, for tailor work, for 44-1 Machine
12371	779	" " " shirt work, for 44-2 Machine
19400	1268	" " " " " " 44-13 Machine, use 20117

NO.	PLATE	NAME
19408	1268	Feed Dog, for shirt work, for 44-13 Machine, use 20138
19411	1268	Feed Dog, for shirt work, for 44-13 Machine, use 20147
19414	1268	Feed Dog, for shirt work, for 44-13 Machine, use 20151
19417	1268	Feed Dog, for shirt work, for 44-13 Machine, use 20158
12428	767	Feed and Feed Lifting Eccentric with 446c
16505	——	Feed Lifting Rock Shaft complete for 44-1 to 44-3, 44-8, 44-9, 44-13, 44-17, 44-22 to 44-24 and 44-28 Machines, Nos. 3043, 12376 and 16504, use 24970
2269	773	Feed Regulator Thumb Screw Stop Pin for 44-3, 44-17 and 44-29 Machines
16507	——	Feed Rock Shaft complete for all machines except 44-23, Nos. 3043 and 16506, use 24376
24347	——	Feed Rock Shaft complete for 44-23 Machine, Nos. 3043 and 24346, use 24377
3043	770	Feed Rock Shaft Crank for 16505, 16507 and 24347
24474	2687	Feed (upper) Shaft for 44-72 Machine
24478	2688	" " " Crank (front) Connection Hinge Pin for 44-72 Machine
19363	1312	Lifting Presser Bar Guide Bracket with 453c, for 44-9 and 44-75 Machines
16561	1352	Knife Bar with 2301, for 19104
16562	1315	" " Crank with 191c, for 16589
897c	——	" " " Coupling Pin for 16589
16589	——	Knife Bar Crank complete for 24110, Nos. 897c, 1564d, 2297 and 16562, use 24432
24110	——	Knife Bar Driving Crank Bracket complete for 44-8 and 44-28 Machines, Nos. 2022, 16563, 16564 and 16589, use 24433
16565	1369	Knife Bar Handle for 19104, 19300 and 19393
19298	1369	Knife Bar Lifting Spring for 44-8 Machine.
19299	——	" " " " Hook for 19393
2266	——	" " " " " " 19104
19104	——	Knife Bar complete for 44-8 Machine, Nos. 621d, 2266, 16561, 16565, 19105 and two 335h, use 19300
19300	——	Knife Bar complete for 44-8 Machine, Nos. 621d, 16565, 19105, 19297 and two 335h, use 19393

NO.	PLATE	NAME
19393	——	Knife Bar complete for 44-8 Machine, Nos. 621D, 16565, 19297, 19299, 19391, 24109 and three 335H
19105	——	Knife Holder with two 335D, for 19104 and 19300, use 19391
24039	1369	Needle Bar Bushing for 44-20 Machine, use 24090
24090	1341	Needle Bar Bushing with 29532, for 44-20 and 44-29 Machines, use 24442
453C	783	Needle Bar Bushing Set Screw for 44-20, 44-29 and 44-30 Machines
1012E	1366	Needle Bar Connecting Link Adjusting Screw for 24040
20368	770	Needle Bar Connecting Stud complete, Nos. 453C, 12383 and 20367, use 12384
20367	770	Needle Bar Connecting Stud Slide Block for 20368
12385	767	Needle Bar Crank with 855C and 858C, use 20188
24042	1340	Needle Bar Crank with 855C, 858C, 1036C and 1037C, for 44-20 Machine, use 24052
855C	783	Needle Bar Crank Position Screw for 12385
696E	782	Needle Bar Plug Screw for all machines except 44-20, 44-29 and 44-30
12495	2014	Needle Bar Plug Screw Rivet for all machines except 44-20, 44-29 and 44-30
12386	767	Oscillating Rock Shaft for 375 for 12387
12387	——	Oscillating Rock Shaft complete, Nos. 4784, 12386 and 12388
12497	1350	Oscillating Rock Shaft for 908 and 1902, use 24104
12498	——	Oscillating Rock Shaft complete, Nos. 4784, 12388 and 12497, use 24105
12443	772	Oscillating Rock Shaft Oil Pad for 16508
16508	772	" " " " " Holder with 12443
238D	782	Oscillating Rock Shaft Oil Pad Holder Screw
12390	771	Oscillating Shaft Crank complete, Nos. 457C, 1518E, 1902 and 19496
1902	783	Oscillating Shaft Crank Roller and Screw Stud
1518E	783	Oscillating Shaft Crank Roller and Screw Stud Nut
19106	——	Presser Foot for 44-8 Machine, use 19392
19224	——	" " Plate

NO.	PLATE	NAME
19225	1308	Presser Foot (hinged) complete for 12425, 19474 and 20119, Nos. 2532, 19223 and 19224, use 24546
24545	——	Presser Foot Shank
24546	780	Presser Foot (spring hinged) complete for 12425, 19474 and 20119, Nos. 24544, 24545, 26231 and 62527, use 24983
24198	1369	Ruffling Arm with 190D, for 44-22 Machine, use 26890
24307	1369	Ruffling Arm with 190D, for 44-22 Machine, use 26890
24209	1324	Ruffling Eccentric Connection for 44-22 Machine
24117	2006	Shuttle Bobbin Case Guide Plate for 24120 and 24121
1053D	2006	Shuttle Bobbin Case Guide Plate Screw for 24120 and 24121
15003	771	Shuttle Bobbin Case Hinge for 12417 and 19293, Nos. 2972 to 2974
20595	2012	Shuttle Bobbin Case Position Finger for 20651
12417	——	Shuttle Bobbin Case complete for 12392, Nos. 591F, 592E, 2523, 2526, 2975, 7553 and 15003, use 19293
19293	771	Shuttle Bobbin Case complete for 19292, Nos. 591F, 592E, 2523, 2975, 7553, 15003 and 15098, use 24074
20651	2012	Shuttle Bobbin Case complete for 20655, Nos. 591F, 592E, 2523, 2975, 20595, 20650 and 20654
20596	2012	Shuttle Body for 20655
19401	——	" Driver for 44-13 Machine, use 19406
12392	——	Shuttle, $1\frac{11}{16}$ in. diam., Nos. 2996, 12393 and 12417, use 19292
20655	2012	Shuttle, $1\frac{11}{16}$ in. diam., Nos. 19131, 20596 and 20651, for 44-13, 44-17, 44-22 and 44-24 Machines
648D	782	Shuttle Race Back Spring Screw
19402	——	" " Body for 19404
19489	——	" " " " 19490
24008	——	" " " " 62623
24011	——	" " " " 24012
24118	——	" " " " 24120
24119	——	" " " " 24121
5708	——	" " " " 5707
19187	——	" " " " 19188

NO.	PLATE	NAME
24063	——	Shuttle Race Body for 24065.....
62623	——	" " " 24008 with 24009 and two 1053D for 24010.....
5709	767	Shuttle Race Cap for 5707 and 19188....
19403	2006	" " " " 19404 and 19490...
4621	2442	" " " Steady Pin for 19404 and 19490.....
5707	767	Shuttle Race complete for 44-1, 44-2, 44-8 and 44-23 Machines, Nos. 648D, 2531, 2533, 5708, 5709 and two each 662D and 2532.....
19188	1356	Shuttle Race complete for 44-3 Machine, Nos. 648D, 2531, 2533, 5709, 19187 and two each 662D and 2532, use 24417....
19404	1356	Shuttle Race complete for 44-13 Machine, Nos. 648D, 662D, 2419, 2533, 4621, 19402, 19403 and two 2532, use 24325
19490	——	Shuttle Race complete for 44-17 Machine, Nos. 648D, 662D, 2419, 2533, 4621, 19403, 19489 and two 2532, use 24327
24010	1357	Shuttle Race complete for 44-13 Machine, Nos. 648D, 2419, 2533, 62623 and two 2532, use 24325.....
24012	1357	Shuttle Race complete for 44-17 Machine, Nos. 648D, 2419, 2533, 24009, 24011 and two each 1053D and 2532, use 24327
24120	2006	Shuttle Race complete for 44-13 Machine, Nos. 907D, 2419, 2533, 24009, 24117, 24118, two 2532 and four 1053D, use 24325.....
24121	1358	Shuttle Race complete for 44-17 Machine, Nos. 907D, 2419, 2533, 24009, 24117, 24119, two 2532 and four 1053D, use 24327.....
24065	1342	Shuttle Race complete for 44-20 and 44-29 Machines, Nos. 648D, 2533, 24062 to 24064 and two each 1053D and 2532, use 24438.....
662D	782	Shuttle Race Cap Screw.....
647F	774	" " Screw, use 145D.....
240D	782	" " Slide Spring Screw for 12432
2526	5842	" Tension Spring for 12417, use 15098.....
24066	1340	Slack Thread Regulator for 44-20 and 44-29 Machines, use 20060.....

NO.	PLATE	NAME
20314	1353	Tension Releaser for 44-1 to 44-3, 44-13, 44-17, 44-20, 44-22, 44-24 and 44-29 Machines.....
29549	1353	Tension Releasing Lever for 44-1 to 44-3 Machines.....
		Nos. 20061 to 20063 for 44-1 to 44-3, 44-13, 44-17, 44-20, 44-22, 44-24 and 44-29 Machines.
20061	1353	Tension Screw Stud Bushing.....
448c	783	" " " " Set Screw...
20062	1353	" " " Flange.....
20063	1353	" " " " Collar.....
24078	1343	Thread Guard (side of arm) for 44-1 to 44-3, 44-13, 44-17, 44-22 and 44-24 Machines.....
		Nos. 12400 to 12402 for 12399
12400	773	Thread Retainer Sleeve.....
12401	773	" " Spring.....
12402	773	" " Stud.....
12399	——	Thread Retainer complete for 44-1 to 44-3, 44-8, 44-9, 44-13, 44-17, 44-20, 44-22 to 44-24, 44-28, 44-29 and 44-72 Machines, Nos. 12400 to 12402.....
24067	1369	Thread Take-up Crank for 44-20 Machine
24069	1369	" " " Lever Link for 44-20 Machine, use 24099.....
430c	783	Thread Take-up Lever Link Hinge Pin Set Screw.....
24019	2014	Thread Take-up Spring, use 8511.....
12413	779	Throat Plate, large needle hole, for 12371
12441	——	" " small needle hole, for 12371
20010	1258	" " large needle hole, for 20009, use 44137.....
20024	——	Throat Plate, small needle hole, for 20009, use 44138.....
20154	1266	Throat Plate Thread Guard for 20123. ..
2080	1266	" " " " Rivet.. ....

NUMERICAL LIST OF PARTS

FOR

MACHINES

Nos. 44-1 to 44-3, 44-8, 44-9, 44-13, 44-17, 44-20, 44-22 to 44-24, 44-28, 44-29, 44-72, 44-74, and 44-75

NUMERICAL LIST OF PARTS

NO. PLATE		NAME
32D	782	Bobbin Winder Frame Hinge Screw for 12172, 12202, 12337, 16522, 19260, 20309 and 20498
32D	8378	Bobbin Winder Stop Latch Hinge Screw for 62587
35D	1366	Bobbin Winder Stop Latch Hinge Screw for 27647, 27650, 27651, 27700 and 27875
58D	2636	Tucker Tuck Guide Plate Arm Hinge Screw for 26683
61F	8380	Ruffling Regulator Crank Connecting Rod Hinge Screw (lower) for 44-75 Machine
65D	782	Driving Attachment Driving Arm Pitman Hinge Screw for 16531 and 24073
69D	5742	Ruffler Driving Lever Hinge Screw for 26018 and 26230
75D	782	Bobbin Winder Stop Latch Hinge Screw for 16522 and 19260
76D	782	Lifting Lever Connecting Rod Joint Hinge Screw (Foot and Knee Lifters)
76D	2061	Separating Blade Arm Hinge Screw for 35280
93F	2669	Presser Foot Tension Plate Screw for 35447
94D	1375	Edge Guide Slide Lever Hinge Screw for 26810
94D	1376	Hemmer Folder Disengaging Lever Hinge Screw for 28688
96D	1394	Strip Folder Hinge Screw for 28707
102D	2035	Ruffler Ruffling Blade Lever Disengaging Lever Hinge Screw for 26724
102D	2061	Separating Blade Arm Latch Lever Hinge Screw for 35280
102D	2061	Separating Blade Holder Hinge Screw for 35280
104D	1374	Seaming Guide Arm Guide (upper) Hinge Screw for 26776
108D	2061	Separating Blade Holder Spring Screw for 35280
130D	782	Driving Attachment Starting Crank Shaft Bracket Screw for 16531 and 24073
134D	2688	Feed (upper) Shaft Bracket Screw for 44-75 Machine
134D	2688	Feed (upper) Shaft Bracket (back) Screw for 44-72 Machine

NO.	PLATE	NAME
135D	2026	Corder Screw for 26169, 26328, 28750 and 28788
144D	782	Arm Shaft Screw
145D	1324	Ruffling Arm Shaft Bracket (right) Screw for 44-22 and 44-28 Machines
145D	782	Shuttle Race Screw
152F	2038	Binder Guide (upper) Screw for 26694
152F	782	Bobbin Winder Stop Latch Adjusting Screw for 16516 and 19258
155C	5843	Thread Unwinder Spool Pin Set Screw for 60455 and 60701
157J	782	Feed Lifting Rock Shaft Crank Clamping Screw for 12376
157J	782	Feed Lifting Rock Shaft Crank (front) Clamping Screw for 12376
157J	782	Feed Rock Shaft Crank Clamping Screw for 29633
158E	1206	Bed Frame Cushion Screw for 19218, 19399 and 24108
159D	1324	Ruffling Arm Shaft Bracket (left) Screw for 44-22 and 44-28 Machines
171D	2688	Feed (upper) Shaft Bracket (front) Screw for 44-72 Machine
171D	8380	Ruffling Regulator Bracket Screw (long) for 44-75 Machine
175D	5736	Lifting Presser Bar Guide Bracket Support Screw for 44-9, 44-72 and 44-75 Machines
176D	2038	Tucker Screw for 26377 and 26687
178E	782	Bell Crank Bracket Screw (Foot and Knee Lifters)
180C	782	Bed Frame Cushion Screw for 16554, obsolete
180F	782	Bobbin Winder Spring Screw for 12172, 12202, 12337, 16522, 19260, 20309 and 20498
181D	1323	Ruffling Regulator Stop Screw for 44-22 and 44-28 Machines
183D	8378	Hand Attachment Body Bracket Screw for 62587
185H	1371	Presser Foot (left) Screw for 28816
190D	782	Binder Ribbon Tension Screw for 26250, 26402, 26466, 28657 and 28784
190D	782	Binder Screw for 25650, 25653, 25656 and 36463
190D	782	Box Plaiter Centre Guide Holder Screw for 28352

NO.	PLATE	NAME
190D	2026	Corder Arm Adjusting Screw for 25792...
190D	1377	" Cord Guide Screw for 120207....
190D	1375	Edge Guide Screw for 26810.....
190D	782	Face Plate Screw for 44-1 to 44-3, 44-13, 44-17, 44-20, 44-22, 44-24, 44-29 and 44-74 Machines.....
190D	2688	Feed (upper) Shaft Regulator Crank Clamping Screw for 20247.....
190D	1376	Hemmer Screw for 28688.....
190D	782	Lifting Presser Foot Screw for 44-75 Machine.....
190D	782	Presser Foot Screw for 44-1 to 44-3, 44-8, 44-13, 44-17, 44-20, 44-22, 44-24, 44-28, 44-29 and 44-74 Machines.....
190D	782	Ruffler Starting Lever Clamping Screw for 28601.....
190D	782	Ruffling Arm Clamping Screw for 24198, 24307 and 26889.....
190D	782	Strip Folder Holder and Guide Screw for 35351.....
190D	782	Welt Guide Screw for 26150.....
191C	1366	Feed (upper) Shaft Crank (back) Set Screw for 20254.....
191C	1366	Knife Bar Crank Set Screw for 16562 and 24431..... .....
193F	1379	Binder Folder Screw for 26953, 28678 and 28776. .....
193D	1312	Lifting Presser Foot Screw for 44-9, 44-23 and 44-72 Machines.....
196J	5809	Finger Guard Holder Clamping Screw for 36820.....
196F	772	Needle Clamp Screw for 24453.....
196F	1374	Seaming Guide Bracket Set Screw for 26783
196F	2038	Tucker Tuck Marking Bar Pressure Spring Clamp Set Screw for 26109.....
198D	2658	Presser Foot Knife Clamp Screw for 28967
198D	1371	" " (right) Shank Cap Screw for 28816.....
199D	1312	Feed Bar (upper) Cap Screw for 24901...
199D	1312	Lifting Presser Bar Bell Crank Cap Screw for 24716, 24901 and 44-23 Machine...
199D	1312	Lifting Presser Bar Bell Crank Connecting Link Cap Screw for 24716, 24901 and 44-23 Machine.....
199D	1312	Vibrating Presser Bar Cap Screw for 19366
200F	2633	Box Plaiter Sliding Bracket Arm Extension Bracket Screw for 28352.....

NO.	PLATE	NAME
205D	8378	Bobbin Winder Tension Bracket Screw for 24807
207F	2021	Binder Folder Screw for 26250, 26402, 26466, 28657, 28784, 28794 and 28861
207F	2021	Binder Screw for 28828
207F	2645	" Strip Guide Screw for 28861
207F	1375	Edge Guide Slide Cap (left) Screw for 26810
207F	1375	" " " " (right) Screw (large) for 26810
207F	1341	Feed Pressure Spring Screw for 44-23 Machine
207F	1376	Hemmer Slide Cap Screw (back) for 28688
207D	1341	Needle Bar Connecting Stud Clamping Screw for 24041
207F	2021	Quilter Guide Holder Set Screw for 25992
207F	2021	" " Set Screw for 25992
207F	2021	Ruffler Foot Screw for 26018
207F	2021	" Frame Stud Set Screw for 26230
207F	1344	Ruffling Arm Adjusting Screw for 26890
207B	1375	Strip Folder Guide Wire Extension Set Screw for 120018
208E	782	Feed Dog Screw for 44-1 to 44-3, 44-8, 44-9, 44-13, 44-17, 44-20, 44-22, 44-24, 44-28, 44-29, 44-72, 44-74 and 44-75 Machines
208E	782	Feed Dog (lower) Screw for 44-23 Machine
208E	782	Thread Unwinder Thread Guard Screw for 41630 and 41631
210D	1343	Balance Wheel Oil Cover Screw
210D	1343	Driving Attachment Balance Wheel Oil Cover Screw for 16531 and 24073
211F	1206	Bed Frame Hinge Connection Cap Screw for 19228 and 19398, obsolete
211A	8378	Hand Attachment Gear Cover Screw for 62587
212D	1374	Seaming Guide Arm Screw for 26776
217F	2061	Edge Folder Screw for 35283 and 35284
217F	2061	" Guide (upper) Screw for 35282
217D	1312	Face Plate Screw for 44-8 and 44-28 Machines
217D	2688	Feeding Foot Screw for 44-72 and 44-75 Machines
217D	1312	Vibrating Presser Foot Screw for 44-9 Machine
219D	774	Arm Side Cap Screw for 44-1 to 44-3, 44-13, 44-17, 44-20, 44-22, 44-24, 44-29 and 44-74 Machines

NO.	PLATE	NAME
219D	774	Face Plate Screw for 44-9, 44-23, 44-72 and 44-75 Machines
219D	774	Feed Bar (upper) Cap Screw for 19367
219D	774	Hemmer Plate Screw for 120078
219F	774	Presser Foot Ribbon Guide Screw for 28761
219F	774	Ruffling Arm Set Screw for 26889
219F	774	Spool Holder Bracket Screw for 26763
219F	774	Vibrating Presser Bar Cap Screw for 19367
220D	1375	Edge Guide Leveling Screw for 26810
220D	2038	Tucker Tuck Marking Bar Bracket Hinge Pin Set Screw for 26377 and 26687
223F	1317	Knife Screw for 19391
223D	2035	Ruffler Guide Screw for 26724
225F	1323	Ruffling Regulator Set Screw for 24211
225F	1323	Slack Thread Regulator Adjusting Screw for 44-1 to 44-3, 44-13, 44-17, 44-20, 44-22, 44-24, 44-29 and 44-74 Machines
226D	1371	Ruffler Ruffling Blade Holder Cap Screw for 28816
226D	1344	Ruffling Blade Holder Cap Screw for 28845 and 44-75 Machine
228D	2038	Binder Screw for 36709 and 36767
228D	2038	Presser Foot Adjustable Guide Screw for 26639
228D	2038	Presser Foot Extension Screw for 12435 and 20157
228D	2038	Presser Foot Strip Gauge Screw for 12435 and 20157
228D	1394	Strip Folder Lock Stud Spring Screw for 28707
229D	2688	Feed (upper) Shaft Regulator Crank Roller Cap Screw for 1942
229D	782	Oscillating Shaft Crank Slide Block Cap Screw for 19449 and 24050
233D	782	Binder Guide (back) Screw for 36463
233D	782	" " (front) Screw for 36463
233D	1380	" Ribbon Tension Screw for 28678 and 28776
233D	2442	Box Plaiter Sliding Bracket Cap Screw for 28352
233D	2442	Box Plaiter Sliding Bracket Stop Screw for 28352
233D	1375	Edge Guide Slide Cap (right) Screw (small) for 26810
233D	1376	Hemmer Folder (left) Screw for 28688
233D	1376	" Slide Cap Screw (front) for 28688

NO.	PLATE	NAME
233D	782	Needle Bar Thread Guard Screw for 44-1 to 44-3, 44-9, 44-13, 44-17, 44-22, 44-24 and 44-74 Machines.....
233B	2036	Tucker Tuck Marker Guide Rod End Screw for 26517.....
233D	2442	Tuck Folder Sliding Bracket Cap Screw for 26895 and 26899.....
233D	2442	Tuck Folder Sliding Bracket Stop Screw for 26895 and 26899.....
233D	2039	Welt Guide Width Guide Screw for 26148
236F	773	Throat Plate Slide Adjusting Screw for 24429..... .....
237F	1105	Knife Grinder Knife Holder Stop Collar Set Screw for 27659.....
238D	782	Oscillating Rock Shaft Oil Pad Holder Screw, obsolete.....
238D	2039	Welt Guide Cap Screw for 26150.....
239D	2061	Separating Blade Arm Latch Lever Spring Screw for 35280.....
240B	8378	Hand Attachment Driver Finger Lock Spring Screw for 62632.....
240D	782	Shuttle Race Slide Spring Screw for 12432, obsolete.....
240D	2039	Welt Guide Carrier Slide Stop Adjusting Screw for 26150.....
242D	2645	Presser Foot Edge Guide Screw for 28858
261D	1105	Knife Grinder Knife Regulating Thumb Screw for 60583.....
283D	1379	Binder Thumb Screw for 26956 and 35072
284D	1366	Guide Thumb Screw for 25874.....
286D	783	Arm Side Cover Thumb Screw.....
286D	5807	Binder Guide Thumb Screw for 36344, 120247 and 120248.....
286D	783	Binder Shank Thumb Screw for 120166..
286D	783	Edge Folder Thumb Screw for 36293....
286D	783	Face Plate Thumb Screw for 44-1 to 44-3, 44-13, 44-17, 44-20, 44-22, 44-24, 44-29 and 44-74 Machines.....
286D	783	Guide Thumb Screw for 28969.....
287D	2636	Spool Holder Bracket Thumb Screw for 26763.....
287D	2636	Tucker Edge Guide Slide Thumb Screw for 26597.....
287D	2636	Tucker Tuck Guide Plate Thumb Screw for 26683.....
291D	2038	Tucker Cloth Guide Thumb Screw for 26377 and 26687.....

NO.	PLATE	NAME
296c	3826	Band Wheel Crank Screw Centre for 46661
297c	3826	Treadle Screw Centre for 46629.....
307c	783	Feed Lifting Rock Shaft Screw Centre for 56814.....
307c	783	Feed Rock Shaft Screw Centre for 56814
310f	1105	Knife Grinder Emery Wheel Shaft Screw Centre for 60583.....
310f	1105	Knife Grinder Knife Holder Guide Bar Bracket Screw Centre for 60583.....
313c	783	Feed Bar (lower) Screw Centre for 56813
313c	783	" " Screw Centre for 56813.....
330d	1366	" Dog (upper) Screw for 44-23 Machine
333d	782	Bobbin Winder Friction Wheel Washer Screw for 12171, 12201, 16515, 20308 and 24800.....
334d	2038	Binder Folder Slide Carrier Screw for 36463.....
334d	2038	Binder Pressure Spring Screw for 25650, 25653, 25656, 26694 and 36463.....
334d	2038	Tucker Tuck Marking Bar Set Screw for 26377 and 26687.....
335h	1317	Knife Holder Handle Screw for 24128....
335h	1317	" " Screw for 19104, 19300, 19393 and 24128.....
335d	1317	Presser Foot Graduated Adjustable Guide Screw for 26977.....
335d	1313	Vibrating Presser Bar Spring Screw for 44-9 Machine.....
337d	2645	Binder Ribbon Guide Screw for 28794...
337b	2671	Presser Foot Graduated Adjustable Guide Clamp Screw for 35137.....
337d	1388	Presser Foot Guide Spring Screw for 26646 and 28773.....
337d	1388	Ruffler Ruffling Blade Clamp Screw for 26230 and 26724.....
337d	2061	Separating Blade Screw for 35280.....
337d	1383	Throat Plate Needle Plate Screw for 26760 and 28342.....
337d	1383	Throat Plate Guide Screw for 35583.....
337d	2442	Tuck Folder (upper, left) Screw for 26895 and 26899.....
337d	2039	Welt Guide Carrier Slide Switch Shaft Head Set Screw for 26139.....
354c	2638	Driving Attachment Treadle Pitman Rod Clamp Screw for 9079.....
354c	2638	Foot Lever Pitman Rod Clamp Screw for 9079.....

NO.	PLATE	NAME
354c	774	Treadle Pitman Rod Clamp Screw for 9079
356c	783	Rock Shaft Knee Arm Hub Set Screw for 2766
356c	783	Rock Shaft Knee Plate Set Screw for 2767
356c	783	" " Lifting Arm Set Screw for 2769
356c	783	" " " Bracket Hook Set Screw for 6337
356c	783	Rock Shaft Lifting Bracket Set Screw for 6337
356c	783	Rock Shaft Stop Dog Set Screw for 2770
362F	2009	Driving Attachment Treadle Stop Collar Set Screw for 2762
362c	2009	Lifting Rod Collar Set Screw for 2762
375c	782	Crank Connecting Rod Hinge Screw, obsolete
375c	782	Feed Connecting Link Hinge Screw
375c	782	" Forked Connection Hinge Screw
375c	782	" Lifting Rock Shaft Crank Connecting Rod Hinge Screw
375c	782	Lifting Presser Bar Bell Crank Driving Arm Eccentric Connection Hinge Screw for 44-9, 44-23, 44-72 and 44-75 Machines
386D	5842	Roller Screw for 1928
391D	1366	Shuttle Bobbin Case Position Plate Screw for 24325, 24327, 24415, 24417, 24419 and 24438
401E	2038	Binder Folder Slide Carrier Adjusting Thumb Nut Guide Screw for 36463
401E	2442	Box Plaiter Folder Blade Screw for 28352
401E	2038	Tucker Cloth Guide Slide Screw for 26377 and 26687
401E	2442	Tuck Folder Guide (under, left) Screw for 26895 and 26899
401E	2442	Tuck Folder (under, right) Screw for 26895
413c	783	Tension Screw Stud for 33892
418E	2014	Bobbin Winder Tension Screw Stud for 27308
427E	783	Driving Attachment Driving Arm Friction Plug Adjusting Screw for 16522 and 19260
430c	783	Thread Take-up Lever Link Hinge Pin Set Screw, obsolete
435c	5806	Driving Attachment Balance Wheel Set Screw for 16592
435c	5806	Thread Take-up Lever Link Hinge Pin Set Screw

NO.	PLATE	NAME
446c	783	Feed and Feed Lifting Eccentric Set Screw for 12428 and 20283
448c	783	Arm Shaft Flanged Bushing (back) Set Screw
448c	783	Balance Wheel Set Screw for 4370, 24296 and 24328
448c	783	Driving Attachment Driving Arm Pitman Crank Spring Adjusting Collar Set Screw for 24528
448c	783	Feed and Feed Lifting Eccentric Set Screw for 24035
448c	783	Lifting Lever Pin Set Screw for 16510, 16585 and 19371
448c	783	Needle Bar Crank and Lifting Eccentric Set Screw for 19365 and 62558
448c	783	Needle Bar Crank Set Screw for 16569
448c	783	Oscillating Rock Shaft Hinge Pin Set Screw
448c	783	Strip Folder Hinge Bracket Set Screw for 28706
448c	783	Tension Screw Stud Bushing Set Screw for 44-1 to 44-3, 44-13, 44-17, 44-20, 44-22, 44-24 and 44-29 Machines, obsolete
448c	783	Thread Take-up Spring Regulator Set Screw
452c	8380	Feed (upper) Shaft Crank (front) Connection Set Screw for 62550
453c	8378	Bobbin Winder Frame Hinge Stud Set Screw for 24797
453c	8378	Bobbin Winder Stop Latch Arm Set Screw for 24804
453c	783	Lifting Presser Bar Guide Bracket Set Screw for 19363 and 24589
453c	783	Needle Bar Bushing Set Screw for 44-20, 44-29 and 44-30 Machines, obsolete
453c	783	Needle Bar Connecting Stud Set Screw for 12384 and 20368
453c	783	Oscillating Shaft Crank Set Screw for 44135
453c	783	Presser Bar Guide Bracket Set Screw for 12326 and 20059
453c	1323	Ruffling Eccentric Collar Set Screw for 24208
453c	1323	Ruffling Eccentric Set Screw for 24207
453c	783	" Regulator Crank Set Screw for 62565

NO.	PLATE	NAME
453c	783	Thread Unwinder Thread Guard Rod Set Screw for 27940.....
454c	2688	Feed (upper) Shaft Crank (front) Set Screw for 24476 and 62615.....
456c	2688	Feed (upper) Shaft Collar Set Screw for 20251.....
456c	773	Thread Unwinder Thread Guard Rod Coupling Set Screw for 41639.....
457c	5806	Corder Cord Guide Bed Leveling Screw for 120206.....
457c	783	Oscillating Shaft Crank Set Screw for 12390 and 19447.....
460c	2688	Feed (upper) Shaft Crank (front) Connection Hinge Pin Set Screw for 62552
460c	2688	Feed (upper) Shaft Crank (front) Hinge Pin Set Screw for 24476.....
460c	1323	Ruffling Arm Shaft Collar Set Screw for 6533.....
462c	773	Feed Lifting Rock Shaft Crank (back) Set Screw for 16556.....
462c	773	Oscillating Shaft Crank Set Screw for 24049.....
462c	773	Shuttle Driver Set Screw for 24061.....
465F	6252	Edge Guide Bed Leveling Screw for 36187
465c	783	Ruffling Lever Stud Collar Set Screw for 62562 .....
468c	2442	Box Plaiter Sliding Bracket Locking Pin Spring Bushing Set Screw for 26439...
468c	2442	Tuck Folder Sliding Bracket Locking Pin Spring Bushing Set Screw for 26439...
514c	2442	Box Plaiter Sliding Bracket Locking Pin for 28352.....
514c	2442	Tuck Folder Sliding Bracket Locking Pin for 26895 and 26899.....
560B	984	Ruffler Ruffling Blade Lever Adjusting Thumb Screw for 26230 and 28816....
561B	2036	Tucker Tuck Marker Guide Clamp Thumb Screw for 26517.....
578D	8376	Throat Plate Cutting Bar Screw for 5732 and 24429.....
578D	8376	Throat Plate Slide Adjusting Screw for 5732.....
591F	782	Shuttle Tension Regulating Screw for 12417, 19293, 20651, 20756, 24056 and 24074.....

NO.	PLATE	NAME
592E	782	Shuttle Bobbin Case Latch Stop Screw for 12417, 19293, 20651, 20756, 24056 and 24074.....
597C	——	Driving Attachment Shaft Driving Pulley Clamping Screw for 27072.....
620C	782	Feed (upper) Lifting Bar Hinge Pin Set Screw for 24343.....
620F	782	Knife Adjusting Screw for 19391.....
620F	782	Needle Bar Thread Guard Set Screw for 16568.....
621D	1317	Knife Bar Lifting Spring Guide Bracket Screw for 19104, 19300, 19393 and 24128
647C	774	Knife Bar Driving Crank Bracket Screw for 44-8 and 44-28 Machines.....
647F	774	Shuttle Race Screw, obsolete, use 145D...
648D	782	" " Back Spring Screw for 5707, 19188, 19404, 19490, 24010, 24012, 24065, 24415, 24417, 24419 and 24438, obsolete.....
651D	1353	Hemmer Block Spring Screw for 120078...
651D	1353	Needle Clamp Thread Guide Screw for 24103.....
656E	2038	Binder Folder Slide Carrier Adjusting Screw for 25672.....
658D	2442	Tuck Guide Thumb Screw for 26895 and 26899.....
658D	2036	Tucker Tuck Guide Thumb Screw for 26517.....
659D	8378	Hand Attachment Gear Screw Stud for 62587.....
660D	8378	Hand Attachment Pinion Screw Stud for 62587.....
662D	2035	Ruffler Separating Blade Screw for 26670 and 26671.....
662D	782	Shuttle Race Cap Screw for 5707, 19188, 19404 and 19490, obsolete.....
665D	1388	Presser Foot Braid Guide Screw for 36182
665D	5645	" " Cord Guide Screw for 36022
665D	2633	" " Guide Screw for 28353.....
665D	1388	" " Spring Guide Screw for 28726 and 28909.....
665D	1371	Ruffler Ruffling Blade Screw for 28816...
665D	1344	Ruffling Blade Screw for 28845.....
665D	1344	" Smoothing Blade Screw for 44-75 Machine.....
671D	5807	Binder Edge Guide Thumb Screw for 36344.....

NO.	PLATE	NAME
671D	1314	Binder Folder and Ribbon Tension Thumb Screw for 26701.....
687E	5843	Machine Hinge Bolt with 1524E, for 44180
688J	783	Pressure Regulating Thumb Screw.....
689C	782	Lifting Presser Bar Lifter Screw for 44-9, 44-23, 44-72 and 44-75 Machines.....
689C	782	Presser Bar Lifter Screw for 44-1 to 44-3, 44-8, 44-13, 44-17, 44-20, 44-22, 44-24, 44-28, 44-29 and 44-74 Machines.....
690E	782	Thread Take-up Crank Wedge Screw for 44-1 to 44-3, 44-8, 44-9, 44-13, 44-17, 44-22 to 44-24, 44-28, 44-72, 44-74 and 44-75 Machines.....
691F	782	Spool Holder Spindle Thread Guiding Disc Screw for 26764.....
691F	782	Throat Plate Screw.....
691F	2442	Tuck Folder Arm Screw for 44-24 Machine.....
692D	783	Bobbin Winder Bracket Screw for 12172, 12202, 12337, 20309 and 20498.....
692D	783	Driving Attachment Bracket Screw for 16531 and 24073.....
692D	783	Hand Attachment Screw for 24807.....
693D	782	Driving Attachment Driving Arm Hinge Screw for 16522 and 19260.....
696E	782	Needle Bar Plug Screw for all machines except 44-20, 44-29 and 44-30, obsolete
703B	8376	Strip Folder Guide Wire Clamp Thumb Screw for 120019.....
703B	8376	Strip Folder Guide Wire Thumb Screw for 120019.....
706D	1371	Presser Foot (right) Shank Stop Screw for 28816.....
711C	1366	Feed Bar (lower) Hinge Pin Screw Bearing
725D	1387	Presser Foot Adjustable Guide Screw for 26802.....
725E	1387	Shuttle Race Slide Spring Screw for 12432
732D	1366	Guide Thumb Screw for 25866.....
732D	2636	Tucker Tuck Guide Plate Bracket Thumb Screw for 26683.....
742E	1323	Ruffling Eccentric Connection Cap Screw for 24219.....
743C	1313	Needle Bar Crank and Lifting Eccentric Position Screw for 19365 and 62558....
743C	1317	Needle Bar Crank Position Screw for 16569.....
748E	782	Arm Screw (back).....

NO.	PLATE	NAME
748E	3826	Brace Screw for 25265, 25279 and 25284..
756E	2442	Tuck Folder (under, right) Screw for 26899
766D	782	Lifting Lever Link Hinge Screw (Foot and Knee Lifters).....
775E	782	Needle Bar Connecting Link Cap Screw for 44-20 and 44-29 Machines.....
775E	782	Thread Take-up Lever Cap Screw for 44-1 to 44-3, 44-8, 44-9, 44-13, 44-17, 44-22 to 44-24, 44-28, 44-72, 44-74 and 44-75 Machines.....
793B	8376	Strip Folder Guide Wire Extension Clamp Thumb Screw for 120018.....
794E	782	Needle Bar Connecting Link Adjusting Screw for 12382 and 24040.....
802D	782	Lifting Lever Hinge Screw (Foot and Knee Lifters).....
803C	782	Driving Attachment Driving Arm Pitman Crank Adjusting Screw for 16520.....
808F	782	Needle Clamp Screw for 4303 and 24103
808F	782	Ruffler Needle Clamp Screw for 26017...
811D	5742	" Ruffling Blade Hinge Screw for 26018.....
812B	984	Ruffler Ruffling Blade Lever Adjusting Thumb Screw for 26018 and 26724....
818D	783	Feed Regulator Thumb Screw.....
855C	783	Needle Bar Crank Position Screw for 12385 and 24042, obsolete.....
858C	783	Needle Bar Crank Set Screw for 12385, 20188, 24042 and 24052.....
861D	5742	Driving Attachment Driving Friction Pulley Oil Hole Plug Screw for 16594.....
862D	1341	Needle Bar Hole Plug Screw for 44-20 and 44-29 Machines.....
868E	1366	Arm Screw (front).....
878J	783	Oscillating Rock Shaft Hinge Pin Oil Hole Stop Screw.....
879D	2026	Corder Arm Locking Screw for 25792....
880E	5843	Brace Section Screw for 46662.....
896E	773	Crank Connecting Rod Cap Screw for 12365, 12496, 20197 and 24028.....
897C	——	Knife Bar Crank Coupling Pin for 16589, obsolete.....
899D	1105	Knife Grinder Knife Clamping Screw for 27658, 27681 and 27682.....
907D	782	Shuttle Race Back Spring Screw for 24120, 24121, 24325, 24327, 24415, 24417, 24419 and 24438.....

NO.	PLATE	NAME
908c	773	Crank Connecting Rod Hinge Screw.....
910F	2039	Welt Guide Adjusting Screw for 26150...
914F	2442	Box Plaiter Sliding Bracket Arm Screw for 28352.....
934E	——	Face Plate Thread Retainer Disc Cover Screw for 24031, obsolete.....
936E	773	Needle Bar Screw Bushing for 44-1 to 44-3, 44-9, 44-13, 44-17, 44-22 to 44-24, 44-72, 44-74 and 44-75 Machines.....
939D	2636	Tucker Edge Guide Thumb Screw for 26685.....
940D	5742	Binder Arm Hinge Screw for 120166.....
940F	1366	Edge Folder Holder Hinge Screw for 36293
940D	5742	Guide Holder Hinge Screw for 28969....
965D	1312	Lifting Presser Bar Bell Crank Driving Arm Shaft Bracket Screw for 44-9, 44-23, 44-72 and 44-75 Machines.....
966E	5806	Feed Lifting Rock Shaft Crank Connecting Rod Cap Screw for 12430 and 43976
970D	4761	Bed Frame Thumb Screw for 19399 and 24108.....
971D	8380	Ruffling Regulator Bracket Screw (short) for 44-75 Machine.....
972c	3826	Band Wheel Set Screw for 25301.....
988c	1353	Oscillating Shaft Crank Slide Block Screw Stud for 19449.....
990F	5696	Guide Disengaging Lever Screw for 36117
1012E	1366	Needle Bar Connecting Link Adjusting Screw for 24040, obsolete.....
1019F	2688	Feed (upper) Shaft Crank (front) Connection Hinge Pin Set Screw for 24480 and 24725.....
1035c	1343	Oscillating Shaft Crank Slide Block Screw Stud for 24050.....
1036c	7790	Binder Leveling Screw for 120242.....
1036c	5806	" " " (back) for 36340..
1036c	1341	Thread Take-up Crank Set Screw for 24042 and 24052.....
1037c	1341	Thread Take-up Crank Position Screw for 24042 and 24052.....
1044D	1377	Corder Cord Guide Arm Hinge Screw for 120207.....
1049D	1371	Ruffler Ruffling Blade Lever Stop Screw for 28816.....
1053D	2006	Shuttle Bobbin Case Guide Plate Screw for 24120 and 24121, obsolete.....

NO.	PLATE	NAME
1053D	2006	Shuttle Race Cap Screw for 24012, 24065, 24120, 24121, 24417, 24998, 25000, 62502, 62510, 62513 and 62623.....
1053D	2006	Throat Plate Separating Blade Screw for 62570.....
1065C	1366	Needle Bar Crank Position Screw for 20188 and 24052.....
1072F	1317	Needle Set Screw for 16568.....
1101C	2035	Ruffler Driving Lever Hinge Screw for 26724 and 28816.....
1108F	1323	Ruffling Regulator Thumb Screw for 44-22 and 44-28 Machines.....
1115F	1370	Ruffler Needle Clamp Screw for 26719...
1128E	2009	Feed Regulator Hinge Screw.....
1133E	8376	Needle Bar Bushing Set Screw for 44-20 and 44-29 Machines.....
1141D	5806	Binder Guide (lower) Screw Stud for 26696
1149C	5742	Thread Unwinder Spool Rest Set Screw for 60455 and 60701.....
1157C	2638	Foot Lever Foot Rest Set Screw for 24378
1157C	2638	" " Pitman Rod (lower) Stop Collar Set Screw for 24384.....
1162C	1366	Knife Bar Crank Coupling Pin for 24432
1266C	5806	Binder Leveling Screw (front) for 36340..
1266C	5806	Shuttle Driver Set Screw for 12444 and 19406.....
1317D	8378	Bobbin Winder Stop Latch Arm Thumb Screw for 62587.....
1423D	5742	Ruffling Separating Blade Screw for 44-22 and 44-28 Machines.....
1423B	5742	Strip Folder Screw for 120019.....
1425B	5742	Binder Folder Hinge Screw for 35354....
1425D	6252	Edge Guide Arm Hinge Screw for 36188
1425B	932	Hemmer Folder Hinge Screw for 35681
1507J	3826	Band-Wheel Crank Screw Centre Nut for 46661.....
1507J	3826	Treadle Screw Centre Nut for 46629.....
1508C	783	Driving Attachment Driving Arm Friction Plug Adjusting Screw Nut for 16522 and 19260.....
1508C	1105	Knife Grinder Emery Wheel Clamping Nut for 60934.....
1513J	783	Feed Lifting Rock Shaft Screw Centre Nut for 56814.....
1513J	783	Feed Rock Shaft Screw Centre Nut for 56814.....

NO.	PLATE	NAME
1516D	1105	Knife Grinder Emery Wheel Shaft Screw Centre Nut for 60583.....
1516D	1105	Knife Grinder Knife Holder Guide Bar Bracket Screw Centre Nut for 60583...
1517E	1366	Feed Bar (lower) Hinge Pin Nut for 44-23 Machine.....
1517E	1366	Feed Bar (lower) Hinge Pin Screw Bearing Nut for 44-23 Machine.....
1518E	783	Crank Connecting Rod Hinge Screw Nut for 375, obsolete.....
1518E	783	Feed Connecting Link Hinge Screw Nut
1518E	783	" Forked Connection Hinge Screw Nut
1518E	783	" Lifting Rock Shaft Crank Connecting Rod Hinge Screw Nut.....
1518E	2688	Feed (upper) Shaft Regulator Crank Roller and Screw Stud Nut for 20247
1518E	783	Lifting Presser Bar Bell Crank Driving Arm Eccentric Connection Hinge Screw Nut for 44-9, 44-23, 44-72 and 44-75 Machines.....
1518E	783	Oscillating Shaft Crank Roller and Screw Stud Nut for 12390, obsolete.....
1518E	783	Oscillating Shaft Crank Slide Block Screw Stud Nut for 19447 and 44135.....
1519J	783	Feed Bar Screw Centre Nut for 56813...
1519J	783	" " (lower) Screw Centre Nut for 56813.....
1520E	783	Driving Attachment Driving Arm Pitman Crank Adjusting Screw Nut for 16520
1520E	783	Lifting Presser Bar Lifter Screw Nut for 44-9, 44-23, 44-72 and 44-75 Machines
1520R	3826	Pitman Rod Lock Nut for 46520.....
1520R	3826	" " (upper) Lock Nut for 46656
1520E	783	Presser Bar Lifter Screw Nut for 44-1 to 44-3, 44-8, 44-13, 44-17, 44-20, 44-22, 44-24, 44-28, 44-29 and 44-74 Machines
1520E	783	Ruffling Regulator Crank Connecting Rod Hinge Screw (lower) Nut for 44-75 Machine.....
1520E	783	Ruffling Regulator Crank Connecting Rod Hinge Screw (upper) Nut for 44-75 Machine.....
1521E	772	Lifting Lever Connecting Rod Lock Nut (Foot and Knee Lifters).....
1524E	5843	Machine Hinge Bolt Nut for 687E.....
1528J	5842	Roller Screw Nut for 1928.....

NO.	PLATE	NAME
1536D	6254	Binder Folder Slide Carrier Adjusting Thumb Nut for 36463
1550J	783	Bobbin Winder Stop Latch Adjusting Screw Nut for 16516 and 19258
1550J	1371	Ruffler Ruffling Blade Holder Stud Nut for 28816
1550J	1344	Ruffling Blade Holder Hinge Stud Nut for 44-75 Machine
1550J	1344	Ruffling Blade Holder Stud Nut for 28845
1560C	783	Tension Regulating Thumb Nut for 33892 and 44141
1562J	2014	Bobbin Winder Tension Regulating Thumb Nut for 27308
1564D	2442	Box Plaiter Sliding Bracket Locking Pin Head for 28352
1564D	2442	Knife Bar Crank Coupling Pin Head for 16589 and 24432
1564D	2442	Tuck Folder Sliding Bracket Locking Pin Head for 26895 and 26899
1566D	2024	Binder Guide (lower) Thumb Nut for 26694
1577D	2024	Binder Folder Guide (upper) Thumb Nut for 25650, 25653 and 25656
1579C	783	Driving Attachment Driving Arm Hinge Screw Nut for 16522 and 19260
1582D	984	Ruffler Driving Lever Spring Adjusting Nut for 26230
1603E	984	Ruffler Ruffling Blade Lever Adjusting Thumb Screw Nut for 26230 and 28816
1619E	773	Crank Connecting Rod Hinge Screw Nut
1620J	5806	Bobbin Winder Frame Hinge Screw Nut for 27647, 27650, 27651, 27700 and 27875
1621E	984	Ruffler Ruffling Blade Lever Adjusting Thumb Screw Nut for 26018 and 26724
1636E	1343	Oscillating Shaft Crank Slide Block Screw Stud Nut for 24049
1640C	2035	Ruffler Driving Lever Spring Adjusting Nut for 26724
1641E	1323	Ruffling Regulator Stop Screw Nut for 44-22 and 44-28 Machines
1641E	1323	Ruffling Regulator Thumb Screw Nut for 44-22 and 44-28 Machines
1647C	1371	Ruffler Driving Lever Hinge Screw Nut for 28816
1666D	984	Ruffler Driving Lever Spring Adjusting Nut for 26018

NO.	PLATE	NAME
1670E	3826	Pitman Rod Ball Screw Bearing Nut for 46630
1670E	3826	Pitman Rod (lower) Ball Screw Bearing Nut for 46630
1701C	8380	Ruffling Lever Stud Nut for 44-75 Machine
1749C	8380	Ruffling Regulator Thumb Screw Nut for 44-75 Machine
1813	783	Feed Lifting Rock Shaft Crank Roller and Stud for 12376
1813	783	Feed Lifting Rock Shaft Crank (front) Roller and Stud for 12376
1852	1377	Guide Roller for 28658
1902	783	Oscillating Shaft Crank Roller and Screw Stud for 12390, obsolete
1904	770	Feed (upper) Shaft Regulator Crank Roller (roller only) for 1942
1904	770	Needle Bar Connecting Stud Roller (roller only) for 12384
1928	2039	Roller, 1¼ in. diam., fine, with 386D and 1528J, for 19394
1942	2688	Feed (upper) Shaft Regulator Crank Roller and Screw Stud with 229D, 1904 and 12424, for 20247
1943	1370	Ruffler Needle Clamp Roller for 26719
1988	6252	Edge Guide Arm Roller and Screw Stud for 36185
2022	773	Driving Attachment Driving Arm Pitman Crank Pin for 24530
2022	773	Driving Attachment Starting Crank Pin for 24530
2022	773	Knife Bar Crank Pin for 24110 and 24433
2049	773	Feed Lifting Rock Shaft Crank (back) Pin for 16588
2049	773	Feed (upper) Shaft Crank (back) Pin for 44-72 and 44-75 Machines
2049	773	Lifting Presser Bar Bell Crank Driving Arm Pin for 19361, 24352 and 62555
2049	773	Oscillating Shaft Crank Pin for 44-1 to 44-3, 44-8, 44-9, 44-13, 44-17, 44-22 to 44-24, 44-28, 44-72, 44-74 and 44-75 Machines
2049	773	Shuttle Driver Pin for 44-1 to 44-3, 44-8, 44-9, 44-13, 44-17, 44-22 to 44-24, 44-28, 44-72, 44-74 and 44-75 Machines

NO.	PLATE	NAME
2062	771	Presser Bar Lifter for 44-1 to 44-3, 44-8, 44-13, 44-17, 44-20, 44-22, 44-24, 44-28, 44-29 and 44-74 Machines.....
2080	1266	Throat Plate Thread Guard Rivet for 20154, obsolete.....
2102	3471	Bobbin Winder Tension Disc for 225462
2102	5806	Tension Disc for 24984 and 44118.....
2106	2014	Bobbin Winder Tension Thread Guide for 27308.....
2113	1388	Guide Disengaging Lever Spring Guide Pin for 36116.....
2113	1388	Presser Foot Guide Spring Steady Pin for 28773.....
2266	——	Knife Bar Lifting Spring Hook for 19104, obsolete.....
2269	773	Bobbin Winder Stop Latch Spring Stop Pin for 16518.....
2269	773	Feed Regulator Thumb Screw Stop Pin for 44-3, 44-17 and 44-29 Machines, obsolete.....
2269	773	Oscillating Shaft Crank Pin for 44-20 and 44-29 Machines.....
2269	773	Shuttle Driver Pin for 44-20 and 44-29 Machines.....
2273	1394	Strip Folder Stop Pin for 28706.....
2291	1317	Knife Screw Washer for 19391.....
2291	1344	Ruffling Arm Adjusting Screw Washer for 26890.....
2296	2442	Box Plaiter Sliding Bracket Locking Pin Spring Bushing for 28352.....
2296	2442	Tuck Folder Sliding Bracket Locking Pin Spring Bushing for 26895 and 26899...
2297	2442	Box Plaiter Sliding Bracket Locking Pin Spring for 28352.....
2297	2442	Knife Bar Crank Coupling Pin Spring for 16589 and 24432.....
2297	2442	Tuck Folder Sliding Bracket Locking Pin Spring for 26895 and 26899.....
2301	2442	Box Plaiter Sliding Bracket Stop Pin for 28349 and 28350.....
2301	1317	Knife Bar Stop Pin for 16561 and 19297
2301	2035	Ruffler Ruffling Blade Lever Disengaging Lever Stop Pin for 26724.....
2301	2442	Tuck Folder Sliding Bracket Stop Pin for 26437 and 26449.....
2301	2442	Tuck Guide Guide Pin for 26893.....

NO.	PLATE	NAME
2362	1375	Edge Guide Slide Cap (left) Steady Pin for 26803
2362	1376	Hemmer Folder Disengaging Lever Stop Pin for 28682
2362	1376	Hemmer Folder (left) Steady Pin for 28682
2419	2006	Shuttle Race Back for 19404, 19490, 24010, 24012, 24120, 24121, 24325 and 24327
2455	8378	Bobbin Winder Tension Disc for 24806 and 27308
2457	8378	Bobbin Winder Tension Disc Stud for 24806
2521	1371	Presser Foot (right) Spring for 28814
2523	1317	Knife Bar Lifting Spring Guide Pin for 24906
2523	771	Shuttle Bobbin Case Position Finger Rivet for 12417, 19293, 20651, 20756, 24056 and 24074
2526	5842	Shuttle Tension Spring for 12417, obsolete, use 15098
2531	767	Shuttle Race Back for 5707, 19188, 24415, 24417 and 24419
2532	8378	Hand Attachment Pinion Dowel Pin for 62676
2532	772	Presser Foot Hinge Pin for 19225, 20157, 20311, 20346, 20474 and 24489
2532	1371	Presser Foot (right) Hinge Pin for 28814
2532	772	Shuttle Race Back Position Pin for 5707, 19188, 19404, 19490, 24010, 24012, 24065, 24120, 24121, 24325, 24415, 24417, 62517, 62519 and 62522
2533	767	Shuttle Race Back Spring for 5707, 19188, 19404, 19490, 24010, 24012, 24065, 24120, 24121, 24325, 24327, 24415, 24417, 24419 and 24438
2653	2671	Presser Foot Graduated Adjustable Guide Clamping Lever Hinge Pin for 28953
2656	1371	Presser Foot (right) Shank Spring for 28816
2656	2669	Presser Foot Tension Spring for 35447
2749	5742	Binder Folder Hinge Screw Friction Washer for 35354
2759	1348	Lifting Rod with 2761, for 2760
2760	——	Lifting Rod complete for 19168, Nos. 2759 and 2762
2761	2638	Foot Lever Pitman Rod (upper) Cap for 24385
2761	2638	Lifting Rod Cap (washer) for 2759

NO.	PLATE	NAME
2762	1206	Driving Attachment Treadle Stop Collar with 362F, for 14233 and 15130.....
2762	1206	Lifting Rod Collar with 362c, for 2760...
2763	1231	Rock Shaft for 2777, 4880 and 19168....
2765	766	" " Knee Arm for 2768.....
2766	766	" " " " Hub with 356c, for 2768 and 6336.....
2767	766	Rock Shaft Knee Plate with 356c, for 2768 and 6336.....
2768	——	Rock Shaft Knee Arm complete for 2777, Nos. 2765 to 2767.....
2769	1348	Rock Shaft Lifting Arm with 356c, for 19168.....
2770	1231	Rock Shaft Stop Dog with 356c, for 2777, 4880 and 19168.....
2777	766	Rock Shaft complete for 16512, 16587, 19373, 24482 and 62574, Nos. 2763, 2768, 2770, 2778, 6337 and two 12242.....
2778	766	Rock Shaft Lifting Bracket Hook for 2777
2827	773	Face Plate Thread Guard (upper) with 8505, for 16550, 19355 and 20058.....
2877	1230	Driving Attachment Treadle Pitman Rod (upper) for 15130.....
2878	363	Driving Attachment Treadle Stand for 27642.....
2921	771	Tension Disc for 44147.....
2923	771	" Spring for 44147.....
2928	774	Driving Attachment Driving Arm Brake (leather) for 16518.....
2973	771	Shuttle Bobbin Case Latch Lever for 15003, 15141 and 20650.....
2974	771	Shuttle Bobbin Case Latch Lever Fulcrum Pin for 15003, 15141 and 20650.....
2975	771	Shuttle Bobbin Case Latch Spring for 12417, 19293, 20651, 20756, 24056 and 24074.....
2996	771	Shuttle Bobbin for 12392, 19292 and 24890
3033	770	Feed Connecting Link.....
3039	768	" Regulator.....
3043	770	" Rock Shaft Crank for 16505, 16507 and 24347, obsolete.....
3094	773	Thread Take-up Crank Wedge for 44-1 to 44-3, 44-8, 44-9, 44-13, 44-17, 44-22 to 44-24, 44-28, 44-72, 44-74 and 44-75 Machines.....
3146	1353	Guide Thumb Screw Washer for 25873...

NO.	PLATE	NAME
3146	1353	Strip Folder Guide Wire Thumb Screw Washer for 120019
4302	773	Needle Bar Thread Guard for 44-1 to 44-3, 44-9, 44-13, 44-17, 44-22, 44-24 and 44-74 Machines
4303	773	Needle Clamp with 808F, for 12381 for 44-1 to 44-3, 44-9, 44-13, 44-17, 44-22, 44-24 and 44-74 Machines
4307	772	Shuttle Race Slide Spring for 12432
4370	1348	Balance Wheel (power) heavy rim, 2¾ in. pulley, with two 448C, for 44-74 Machine
4604	1385	Corder Bow Rivet for 26938
4604	1385	Ruffling Separating Blade Rivet for 24410
4604	2061	Separating Blade Holder Spring Stop Pin for 35280
4604	2038	Tucker Cloth Guide Slide Rivet for 26377 and 26687
4604	2038	Tucker Tuck Smoothing Spring Rivet for 26377 and 26687
4621	2442	Shuttle Race Cap Steady Pin for 19404 and 19490, obsolete
4621	2442	Tuck Folder (upper, left) Guide Pin for 26895 and 26899
4621	2442	Tuck Folder Guide (under, left) Rivet for 26894 and 26898
4653	1354	Feed Bar (lower) Hinge Pin for 44-23 Machine
4784	1353	Oscillating Rock Shaft Oil Pad for 12387, 12498, 24044 and 24105
4822	2045	Wrench for 1521 and 1528
4855	1312	Lifting Presser Bar Lifter for 44-9 and 44-23 Machines
4879	2004	Chain Connecting Link for 4885
4880	1231	Rock Shaft complete, Nos. 2763, 2770, 7125, 12243 and two each 6337 and 12242 (Foot Lifters)
		Nos. 4881 to 4884 for 4885
4881	1231	Treadle
4882	2004	" Shaft
4883	2004	" Spring
4884	1231	" Stand
4885	1231	Foot Lifter Treadle complete, Nos. 4879, 4881 to 4884 and two wood screws 1 in. No. 16 (Foot Lifters)
5596	768	Bell Crank for 56848

NO.	PLATE	NAME
5598	768	Bell Crank complete, Nos. 5735 and 56848 (Foot and Knee Lifters).....
5599	768	Bell Crank Bracket for 56848.....
5601	773	" " Hinge Pin for 56848.....
5602	772	" " Spring for 5598, obsolete.....
5604	2036	Tucker Frame Rivet for 26517.....
5670	——	Chain, length 26 in. to 35 in. (Foot Lifters)
5671	2638	Foot Lever Hinge Pin for 24379.....
5707	767	Shuttle Race complete for 44-1, 44-2, 44-8 and 44-23 Machines, Nos. 648D, 2531, 2533, 5708, 5709 and two each 662D and 2532, obsolete.....
5708	——	Shuttle Race Body for 5707, obsolete....
5709	767	" " Cap for 5707 and 19188....
5726	1271	Knife for 44-8 and 44-28 Machines.....
5729	——	Throat Plate Body for 5732.....
5730	1271	" " Cutting Bar for 5732 and 24429.....
5731	1271	Throat Plate Slide for 5732 and 24429...
5732	1271	Throat Plate complete for 19103 and 24573, Nos. 5729 to 5731 and three 578D.....
5735	1353	Bell Crank Spring for 5598.....
5944	2636	Tucker Tuck Guide Plate Guide Pin for 26571.....
5960	768	Bobbin Winder Friction Wheel (leather) for 12171, 12201, 16515, 20308, 24800, 43982 and 43983.....
5961	768	Bobbin Winder Friction Wheel Washer for 12171, 12201, 16515, 20308, 24800, 43982 and 43983.....
5963	768	Bobbin Winder Spindle Flange for 12171, 12201, 16515, 20308, 24800, 43982 and 43983.....
6037	1377	Corder Cord Guide Bracket Rivet for 26796.....
6055	5843	Driving Attachment Treadle Pitman Rod (lower) Spring Washer for 14233 and 15130.....
6055	5843	Machine Hinge Bolt Nut Washer for 44180
6267	2028	Hemmer Folder.....
6335	1348	Rock Shaft Knee Arm for 6336.....
6336	——	Rock Shaft Knee Arm complete for 19168, Nos. 2766, 2767 and 6335.....
6337	1231	Rock Shaft Lifting Bracket with two 356C, for 2777 and 4880.....
6533	1323	Ruffling Arm Shaft Collar with 460C, for 44-22 and 44-28 Machines.....

NO.	PLATE	NAME
7071	1379	Binder Folder Screw Washer for 26250, 26402, 26466, 26953, 28657, 28678, 28776, 28784, 28794 and 28861.....
7071	2021	Binder Guide (upper) Screw Washer for 26694.....
7071	2021	Binder Pressure Spring Screw Washer for 25650, 25653, 25656 and 26694.....
7071	2021	Binder Ribbon Tension Screw Washer for 26250, 26402, 26466, 28657 and 28784
7071	2021	Binder Screw Washer for 28828.....
7071	2021	" Shank Thumb Screw Washer for 120166.....
7071	2645	Binder Strip Guide Screw Washer for 28861.....
7071	2021	Box Plaiter Centre Guide Holder Screw Washer for 28352.....
7071	1379	Edge Folder Thumb Screw Washer for 36293.....
7071	2021	Guide Thumb Screw Washer for 28969...
7071	2021	Strip Folder Holder and Guide Screw Washer for 35351.....
7071	2636	Tucker Edge Guide Slide Thumb Screw Washer for 26597.....
7071	2636	Tucker Tuck Guide Plate Thumb Screw Washer for 26683.....
7071	2021	Welt Guide Screw Washer for 26150.....
7125	1231	Rock Shaft Lifting Bracket Hook for 4880
7298	2014	Presser Foot Hinge Pin for 19336, 20270 and 120144.....
7336	772	Thread Take-up Spring Regulator for 24984, 44118 and 44147.....
7476	2038	Binder Folder Guide Block Rivet for 36457
7476	2442	Tuck Guide Rivet for 26637.....
7553	771	Shuttle Bobbin Case Position Finger for 12417, 19293 and 24074.....
7806	2645	Binder Ribbon Guide Screw Washer for 28794.....
7958	5843	Driving Attachment Balance Wheel Friction Ring Stop Pin for 16592.....
7958	8380	Pitman Pin for 25279.....
8238	1353	Tension Spring for 24984.....
8280	8378	Hand Attachment Crank Hinge Pin for 62587.....
8281	8378	Hand Attachment Crank Lock Pin for 8392.....
8282	8378	Hand Attachment Crank Lock Pin Spring for 8392.....

NO.	PLATE	NAME
8285	8378	Hand Attachment Driver Finger Hinge Pin for 62632
8286	8378	Hand Attachment Driver Finger Lock Spring for 62632
8313	8377	Hand Attachment Driver for 62632
8392	8377	" " Gear with 8281 and 8282, for 62587
8394	8378	Hand Attachment Pinion for 62676
8418	5842	Belt Guard Button for 8420
8419	5842	" " " Washer (leather) for 8420
8420	——	Belt Guard Button 8418 with 8419 and wood screw 1¼ in. No. 9 R. H. B., for 41931
8435	8377	Hand Attachment Crank Lever for 94005
8505	773	Face Plate Thread Guard (upper) Rivet for 2827
8505	773	Ruffler Ruffling Blade Rivet for 26010
8511	773	Thread Take-up Spring for 44147
8582	773	Arm Dowel Pin
8908	2045	Wrench for 1519, 1520 and 1620
8909	2045	" " 1513, 1517, 1518 and 1524
9079	2638	Driving Attachment Treadle Pitman Rod Clamp with 354c, for 14233 and 15130
9079	2638	Foot Lever Pitman Rod Clamp with 354c, for 24387
9079	8383	Treadle Pitman Rod Clamp with 354c, for 67177
9082	773	Driving Attachment Treadle Bearing Cotter Pin for 27642
9261	4761	Bed Frame Hinge Connection Pin for 24108
9545	1369	Face Plate Thread Retainer Disc Spring for 24031, obsolete
9558	2038	Binder Folder Steady Pin for 26695
9780	2038	" Guide (lower) Stud for 26696
10135	2061	Separating Blade Arm Latch Lever Spring for 35280
10141	2014	Bobbin Winder Tension Spring for 27308
10165	2633	Box Plaiter Centre Guide Stop Pin for 28344
10236	774	Driving Attachment Driving Friction Pulley Centre Bearing for 16594
10875	5841	Wrench for 46660 for 25284
*11104	——	Arm Shaft Bushing (front)
11119	773	" Oil Tube with 29599, for oiling 12408, 16569, 19365, 24068 and 24207

NO.	PLATE	NAME
11167	767	Lifting Presser Bar Spring (light) .051 wire, for 44-9, 44-23, 44-72 and 44-75 Machines
11167	767	Presser Bar Spring (light) .051 wire, for 44-1 to 44-3, 44-8, 44-13, 44-17, 44-20, 44-22, 44-24, 44-28, 44-29 and 44-74 Machines
11170	771	Lifting Presser Bar Spring Washer for 44-9, 44-23, 44-72 and 44-75 Machines
11170	771	Presser Bar Spring Washer for 44-1 to 44-3, 44-8, 44-13, 44-17, 44-20, 44-22, 44-24, 44-28, 44-29 and 44-74 Machines
11204	770	Thread Take-up Lever Link Hinge Pin...
11241	2003	Arm Spool Pin Washer (cloth)
11241	2003	Bobbin Winder Spool Washer (cloth) for 27308
11833	6255	Knife Grinder Knife Position Pin (upper) for 27681 and 27682
12139	2004	Lifting Presser Bar Spring (medium) .055 wire, for 44-9, 44-23, 44-72 and 44-75 Machines
12139	2004	Presser Bar Spring (medium) .055 wire, for 44-1 to 44-3, 44-8, 44-13, 44-17, 44-20, 44-22, 44-24, 44-28, 44-29 and 44-74 Machines
12142	780	Presser Foot for 12370 and 43979
12143	780	" " " 12369, 12457, 20106, 26377 and 26687
12144	780	Presser Foot for 12372, 12437, 12455, 12468, 12481, 20002, 20117, 20132, 20138, 20147, 20151, 20158, 20159, 20162, 20336, 44144, 44156 and 44177
12149	2014	Tension Thread Guard for 44-8, 44-9, 44-23, 44-28, 44-72 and 44-75 Machines
12150	773	Face Plate Thread Guard (lower) 44181 with 12152, for 16559, 19355, 20058 and 24031
12152	773	Face Plate Thread Guard (lower) Rivet for 12150
12152	1375	Edge Guide Slide Spring Cover Rivet for 24031 and 36760
12152	1376	Hemmer Slide Spring Cover Rivet for 28682
12166	773	Thread Take-up Lever Hinge Pin for 12410 and 24070
12168	2003	Bobbin Winder Bracket for 12172, 12202, 12337, 20309 and 20498

NO.	PLATE	NAME
12169	2003	Bobbin Winder Frame for 12171 and 12201
12170	773	" " Spring for 12172, 12202, 12337, 16522, 19260, 20309 and 20498
12171	2003	Bobbin Winder Frame complete for 12172, Nos. 333D, 5960, 5961, 5963, 12169 and 15077.....
12172	——	Bobbin Winder complete for 4370, Nos. 32D, 180F, 12168, 12170 and 12171.....
12178	774	Driving Attachment Driving Arm Friction Plug (wood) for 16522 and 19260.....
12189	768	Driving Attachment Starting Crank for 24530.....
12193	2004	Arm Side Cover.....
12201	2003	Bobbin Winder Frame complete for 12202, Nos. 333D, 5960, 5961, 5963, 12169 and 15077.....
12202	——	Bobbin Winder complete for 2135 and 2862, Nos. 32D, 180F, 12168, 12170 and 12201.....
*12204	——	Feed Lifting Rock Shaft Crank Connecting Rod Cap for 12430.....
12240	772	Lifting Lever Pin for 16512, 19331 and 24161.....
12241	772	Lifting Lever Link for 16512, 16587, 19331, 24161 and 24426.....
12242	1231	Rock Shaft Hanger with two wood screws 1 in. No. 10, for 2777, 4880 and 19168
12243	1231	Rock Shaft Lifting Bracket Hook for 4880
12258	1308	Presser Foot (wide) for 12369, 12457 and 20106.....
12259	780	Presser Foot for 12425 and 19474.....
12260	780	" " " 12437, 12450, 20147, 20348 and 44177.....
12261	1308	Presser Foot for 12481.....
12326	770	" " Guide Bracket with 453c, for 44-8 and 44-28 Machines.....
12327	770	Lifting Presser Bar Lifting and Releasing Lever Bracket for 44-9, 44-23, 44-72 and 44-75 Machines.....
12327	770	Presser Bar Lifting and Releasing Lever Bracket for 44-1 to 44-3, 44-8, 44-13, 44-17, 44-20, 44-22, 44-24, 44-28, 44-29 and 44-74 Machines.....
12329	772	Tension Releasing Lever Spring.....
12335	1308	Presser Foot (narrow) for 12369, 12457, 20106, 20115, 20116, 20137, 20163 and 20164.....

NO.	PLATE	NAME
12336	2003	Bobbin Winder Spindle, for spool, for 43982 and 43983
12337	——	Bobbin Winder (Hamburg) complete for 2135 and 2862, Nos. 32D, 180F, 12168, 12170 and 43982
12357	767	Arm Shaft Flanged Bushing (back)
12361	772	Machine Hinge Connection for 44140 and 44180
12365	1350	Crank Connecting Rod with 14013 and two 896E, for 375, obsolete
12368	767	Feed Bar for 44-1 to 44-3, 44-8, 44-9, 44-13, 44-17, 44-22, 44-24, 44-28 and 44-74 Machines
12368	767	Feed Bar (lower) for 44-72 and 44-75 Machines
12369	776	Feed Dog, 12 teeth (12 teeth to the inch) for 28657, 36293 and 44-1, 44-9, 44-13, 44-20 and 44-74 Machines
12370	778	Feed Dog, 15 teeth (16 teeth to the inch) for cloth, for 26466, 28776 and 44-1, 44-9 and 44-13 Machines
12371	779	Feed Dog, for shirt work, for 44-2 Machine, obsolete
12372	778	Feed Dog, 13 teeth (12 teeth to the inch) beveled for hemmer, for 26328 and 44-2 Machine
12376	770	Feed Lifting Rock Shaft Crank with 157J and 1813, for 24970
12376	770	Feed Lifting Rock Shaft Crank (front) with 157J and 1813, for 16505 and 16588
12381	767	Needle Bar (hollow) for 44-1 to 44-3, 44-9, 44-13, 44-17, 44-22, 44-24 and 44-74 Machines
12382	770	Needle Bar Connecting Link with 794E, for 44-1 to 44-3, 44-8, 44-9, 44-13, 44-17, 44-22 to 44-24, 44-28, 44-72, 44-74 and 44-75 Machines
*12383	——	Needle Bar Connecting Stud for 12384 and 20368
12384	770	Needle Bar Connecting Stud complete for 44-1 to 44-3, 44-8, 44-9, 44-13, 44-17, 44-22 to 44-24, 44-28, 44-72, 44-74 and 44-75 Machines, Nos. 453C, 1904 and 12383
12385	767	Needle Bar Crank with 855C and 858C, obsolete, use 20188

NO.	PLATE	NAME
12386	767	Oscillating Rock Shaft for 375 for 12387, obsolete.....
12387	——	Oscillating Rock Shaft complete, Nos. 4784, 12386 and 12388, obsolete.....
12388	767	Oscillating Rock Shaft Hinge Pin for 12387, 12498, 24044 and 24105.....
12390	771	Oscillating Shaft Crank complete, Nos. 457c, 1518e, 1902 and 19496, obsolete
12391	767	Lifting Presser Bar (hollow) for 44-9, 44-23 44-72 and 44-75 Machines.....
12391	767	Presser Bar (hollow) for 44-1 to 44-3, 44-8, 44-13, 44-17, 44-20, 44-22, 44-24, 44-28, 44-29 and 44-74 Machines.....
12392	——	Shuttle, 1 $\frac{11}{16}$ in. diam., Nos. 2996, 12393 and 12417, obsolete, use 19292.....
12393	771	Shuttle Body for 12392 and 19292.....
*12394	——	" Driver for 12444.....
12397	772	Tension Releasing Lever for 44-9, 44-23 and 44-28 Machines.....
12398	773	Tension Releasing Lever Hinge Pin.....
12399	——	Thread Retainer complete for 44-1 to 44-3, 44-8, 44-9, 44-13, 44-17, 44-20, 44-22 to 44-24, 44-28, 44-29 and 44-72 Machines, Nos. 12400 to 12402, obsolete.....

Nos. 12400 to 12402 for 12399, obsolete

12400	773	Thread Retainer Sleeve.....
12401	773	" " Spring.....
12402	773	" " Stud.....
12403	772	Arm Spool Pin and Thread Eyelet.....
12404	770	Thread Take-up Crank for 44-1 to 44-3, 44-8, 44-9, 44-13, 44-17, 44-22 to 44-24, 44-28, 44-72, 44-74 and 44-75 Machines
12405	774	Machine Rest, felt (Attachments and Accessories).....
12405	774	Bed Frame Cushion (felt) for 16554, obsolete.....
12408	770	Thread Take-up Lever for 12410.....
12409	770	" " " Link for 12410...
12410	——	Thread Take-up Lever complete for 44-1 to 44-3, 44-8, 44-9, 44-13, 44-17, 44-22 to 44-24, 44-28, 44-72, 44-74 and 44-75 Machines, Nos. 12166, 12408 and 12409
12411	776	Throat Plate, large needle hole, for 12369 and 12457.....
12412	778	Throat Plate, large needle hole, for 12370 and 43979.....

NO.	PLATE	NAME
12413	779	Throat Plate, large needle hole, for 12371, obsolete.....
12414	——	Throat Plate, large needle hole, for 12372 and 20002.....
12415	768	Lifting Lever Connecting Rod for 16512, 16587, 19331, 19373, 24161, 24426, 24427, 62573 and 62574.....
12416	774	Lifting Lever Connecting Rod Joint (Foot and Knee Lifters).....
12417	——	Shuttle Bobbin Case complete for 12392, Nos. 591F, 592E, 2523, 2526, 2975, 7553 and 15003, obsolete, use 19293.....
12424	2688	Feed (upper) Shaft Regulator Crank Roller Cap Screw Washer for 1942....
12424	773	Oscillating Shaft Crank Slide Block Cap Screw Washer for 19449 and 24050....
12425	779	Feed Dog, for cloth, for 26250, 44-1 and 44-13 Machines.....
12426	779	Throat Plate, large needle hole, for 12425
12428	767	Feed and Feed Lifting Eccentric with 446C, obsolete.....
12430	5764	Feed Lifting Rock Shaft Crank Connecting Rod with 12204 and two 966E, for 44-20 and 44-29 Machines.....
12431	——	Shuttle Race Slide for 12432.....
12432	2004	Shuttle Race Slide complete, Nos. 4307, 12431 and two 725E.....
12433	775	Feed Dog for 44-3 Machine.....
12434	775	Throat Plate, small needle hole, for 12433 and 19488.....
12435	780	Presser Foot with 228D, for 12433, 12460, 12471, 19488, 20041, 20115, 20116, 20137, 20163, 20164 and 25967.....
12437	777	Feed Dog, for cloth, four teeth at right of needle hole (square corner) for 44-2 Machine.....
12440	777	Throat Plate, small needle hole, for 12437
12441	——	" " " " " " 12371, obsolete.....
12442	778	Throat Plate, small needle hole, for 12372, 20002 and 26328.....
12443	772	Oscillating Rock Shaft Oil Pad for 16508, obsolete.....
12444	771	Shuttle Driver 12394 with two 1266C, for 44-1 to 44-3, 44-8, 44-9, 44-23, 44-28, 44-72 and 44-75 Machines.....

NO.	PLATE	NAME
12449	——	Throat Plate, small needle hole, for 12369 and 12457
12450	777	Feed Dog, 11 teeth (18 teeth to the inch) for cloth, for 26655, 35175 and 44-1, 44-13 and 44-20 Machines
12451	——	Throat Plate, small needle hole, for 12450 and 20348
12453	773	Arm Oil Tube for intermediate bearing
12454	773	" " " with 29599, for oiling 12409 and 24099
12455	779	Feed Dog, for shirt work, beveled for hemmer, for 44-2 Machine
12456	779	Throat Plate, small needle hole, for 12455
12457	776	Feed Dog, 16 teeth (16 teeth to the inch) for cloth, for 28657, 35245, 44-1, 44-9, 44-13 and 44-20 Machines
12459	773	Oscillating Rock Shaft Hinge Pin Oil Hole Stop Screw Washer (leather)
12460	775	Feed Dog for 44-3 and 44-17 Machines
12461	775	Throat Plate, small needle hole, for 12460
12462	781	Presser Foot, $\frac{3}{16}$ in. to $\frac{1}{4}$ in. gauge, for 44-3, 44-17 and 44-29 Machines
12463	781	Presser Foot with Strip Guide for 44-3, 44-17 and 44-29 Machines
12464	777	Throat Plate, large needle hole, for 12450 and 20348
12465	——	Throat Plate, large needle hole, for 12437
12466	——	" " small needle hole, for 12425
12468	777	Feed Dog, 16 teeth (16 teeth to the inch) for shirt work, beveled for hemmer, for 44-2 Machine
12469	——	Throat Plate, large needle hole, for 12468 and 20471
12470	777	Throat Plate, small needle hole, for 12468 and 20471
12471	775	Feed Dog for 44-3 Machine
12472	——	Throat Plate, medium needle hole, for 12471 and 20369
12473	775	Throat Plate, small needle hole, for 12471 and 20369
12474	1308	Presser Foot for 12372, 12481, 20002, 20138 and 20162
12480	767	Arm Side Cap for 44-1 to 44-3, 44-13, 44-17, 44-20, 44-22, 44-24, 44-29 and 44-74 Machines
12481	778	Feed Dog, 18 teeth (16 teeth to the inch) for 44-2 Machine

NO.	PLATE	NAME
12482	——	Throat Plate, large needle hole, for 12481 and 43978
12483	778	Throat Plate, small needle hole, for 12481 and 43978
12484	2003	Bobbin Winder Spring for 12172, 12202 and 12337, obsolete
12495	2014	Needle Bar Plug Screw Rivet for all machines except 44-20, 44-29 and 44-30, obsolete
12496	1350	Crank Connecting Rod with 14013 and two 896E, for 908, obsolete, use 20197
12497	1350	Oscillating Rock Shaft for 908 and 1902, for 12498, obsolete, use 24104
12498	——	Oscillating Rock Shaft complete, Nos. 4784, 12388 and 12497, obsolete, use 24105
14010	1206	Bed Frame Hinge Plate Rivet for 19218 and 19399, obsolete
*14013	——	Crank Connecting Rod Cap for 12365 and 12496, obsolete
14026	2061	Separating Blade Holder Stop Pin for 35280
14081	1230	Driving Attachment Treadle Pitman Rod (upper) for 14233
14233	1230	Driving Attachment Treadle Pitman complete, for bench stand, for 14234, Nos. 2762, 6055, 9079, 14081, 27637 and 27638
14234	——	Driving Attachment Treadle and Pitman complete for 16531 and 24073, Nos. 14233 and 27642
15003	771	Shuttle Bobbin Case Hinge for 12417 and 19293, Nos. 2972 to 2974, obsolete
15072	2014	Bobbin Winder Bobbin Position Pin for 15077, 24802 and 27538
15072	1388	Presser Foot Guide Hinge Pin for 28773
15072	2658	" " Knife Clamp Steady Pin for 28967
15077	773	Bobbin Winder Spindle with 15072, for 12171, 12201, 16515, 20308, 43982 and 43983
15098	771	Shuttle Tension Spring for 19293 and 24074
15130	1230	Driving Attachment Treadle Pitman complete for 15131, Nos. 2762, 2877, 6055, 9079, 27637 and 27638

NO.	PLATE	NAME
15131	——	Driving Attachment Treadle and Pitman complete for 16531 and 24073, Nos. 15130 and 27642
15132	773	Driving Attachment Driving Arm Brake Rivet for 16518
15140	1353	Shuttle Bobbin Case Latch for 15141
15141	——	" " " Hinge for 24056 and 24074, Nos. 2973, 2974 and 15140
15367	8378	Bobbin Winder Tension Disc Spring for 24806
*16501	——	Arm with 11104, for 44-1 to 44-3, 44-13, 44-17 and 44-74 Machines
16502	——	Arm Shaft for 44-1 Machine, obsolete
*16503	——	Bed for 44-1 to 44-3, 44-13, 44-17, 44-22, 44-24 and 44-74 Machines
16504	766	Feed Lifting Rock Shaft for 16505 and 16588
16505	——	Feed Lifting Rock Shaft complete for 44-1 to 44-3, 44-8, 44-9, 44-13, 44-17, 44-22 to 44-24 and 44-28 Machines, Nos. 3043, 12376 and 16504, obsolete, use 24970
16506	766	Feed Rock Shaft for 16507 and 24376
16507	——	Feed Rock Shaft complete for all machines except 44-23, Nos. 3043 and 16506, obsolete, use 24376
16508	772	Oscillating Rock Shaft Oil Pad Holder with 12443, obsolete
16509	766	Oscillating Shaft for 44-1 to 44-3, 44-8, 44-9, 44-13, 44-17, 44-22 to 44-24, 44-28, 44-72, 44-74 and 44-75 Machines
16510	766	Lifting Lever with 448C, for 16512, 19331 and 24161
16511	1349	Arm Shaft for 44-1 to 44-3, 44-8, 44-9, 44-13, 44-17, 44-23, 44-24, 44-72, 44-74 and 44-75 Machines
16512	——	Knee Lifter complete (power table) for 44-1 to 44-3, 44-17, 44-20, 44-22, 44-24 and 44-29 Machines, Nos. 76D, 766D, 802D, 1521E, 2777, 5598, 12240, 12241, 12415, 12416, 16510 and two 178E
16514	768	Bobbin Winder Frame for 16515
16515	768	Bobbin Winder Frame complete for 16522 and 19260, Nos. 333D, 5960, 5961, 5963, 15077 and 16514
16516	774	Bobbin Winder Stop Latch with 152F and 1550J, for 16522

NO.	PLATE	NAME
16518	1230	Driving Attachment Driving Arm with 2269, 2928 and two 15132, for 16522 and 19260
16519	1348	Driving Attachment Driving Arm Pitman for 16531 and 24073
16520	768	Driving Attachment Driving Arm Pitman Crank with 803c and 1520E, for 24530
16521	768	Driving Attachment Driving Arm Pitman Crank Spring for 24530
16522	——	Driving Attachment Driving Arm complete for 16531, Nos. 32D, 75D, 180F, 427E, 693D, 1508c, 1579c, 12170, 12178, 16515, 16516, 16518, 16530 and 27303
16524	——	Driving Attachment Balance Wheel Friction Ring (leather) for 16592
16525	1350	Driving Attachment Starting Crank Shaft for 24530
16528	1230	Drip Pan with four 1 in. wire nails, for 16531 and 24073
16530	1230	Driving Attachment Bracket for 16522 and 19260
16531	——	Driving Attachment with Bobbin Winder and Treadle complete for 44-1 to 44-3, 44-8, 44-9, 44-23, 44-28, 44-72 and 44-75 Machines, Nos. 210D, 692D, 14234 or 15131, 16519, 16522, 16592, 16594, 24355, 24530, 27072, 27308, two 65D and three 130D
16532	1369	Arm Dowel Pin, obsolete
16554	——	Bed Frame with two 16555, four each 180c, 12405 and six wood screws 1¼ in. No. 10, obsolete, use 24108
16555	1206	Bed Frame Hinge Plate for 16554, 19218 and 19399, obsolete
16556	2009	Feed Lifting Rock Shaft Crank (back) with 462c, for 16588
*16557	——	Arm with 11104, for 44-8 Machine
16558	——	Face Plate for 16559
16559	1351	Face Plate complete for 44-8 and 44-28 Machines, Nos. 2827, 12150 and 16558
16561	1352	Knife Bar with 2301, for 19104, obsolete
16562	1315	" " Crank with 191c, for 16589, obsolete
16563	1315	Knife Bar Driving Crank (forked) for 24110 and 24433
16564	1315	Knife Bar Driving Crank Bracket for 24110 and 24433

NO.	PLATE	NAME
16565	1369	Knife Bar Handle for 19104, 19300 and 19393, obsolete.....
16568	1352	Needle Bar with 620F, 1072F and 24391, for 44-8 and 44-28 Machines.....
16569	1315	Needle Bar Crank (eccentric) with 448C and 743C, for 44-8 and 44-28 Machines
16573	2039	Roller Arm for 19394..... .....
16585	1315	Lifting Lever with 448C, for 16587 and 24426.....
16586	5843	Lifting Lever Pin for 16587 and 24426...
16587	——	Knee Lifter complete (power table) for 44-8 and 44-28 Machines, Nos. 76D, 766D, 802D, 1521E, 2777, 5598, 12241, 12415, 12416, 16585, 16586 and two 178E
16588	——	Feed Lifting Rock Shaft complete, for 44-20 and 44-29 Machines, Nos. 2049, 12376, 16504 and 16556.....
16589	——	Knife Bar Crank complete for 24110, Nos. 897C, 1564D, 2297 and 16562, obsolete, use 24432.....
16592	1230	Driving Attachment Balance Wheel (friction) with 795S, 16524 and two 435C, for 16531 and 24073.....
16594	1230	Driving Attachment Driving Friction Pulley, $2\frac{5}{16}$ in. diam., with 861D and two 10236, for 16531 and 24073.....
*16596	——	Bed for 44-8 and 44-28 Machines.....
18055	1394	Presser Foot Hinge Pin for 28691.....
19045	——	Guide Disengaging Lever Handle for 36116
19066	1352	Spool Holder Spindle for 26764.....
19067	1352	" " " Thread Guiding Disc for 26764.....
19103	1271	Feed Dog, 12 teeth (16 teeth to the inch) for 44-8 Machine.....
19104	——	Knife Bar complete for 44-8 Machine, Nos. 621D, 2266, 16561, 16565, 19105 and two 335D, obsolete, use 19300.....
19105	——	Knife Holder with two 335D, for 19104 and and 19300, obsolete, use 19391.....
19106	——	Presser Foot for 44-8 Machine, obsolete, use 19392.....
19131	5737	Shuttle Bobbin for 20655 and 20758.....
19168	——	Rock Shaft complete for 24161, Nos. 2760, 2763, 2769, 6336 and two each 2770 and 12242.....
19187	——	Shuttle Race Body for 19188, obsolete...

NO.	PLATE	NAME
19188	1356	Shuttle Race complete for 44-3 Machine, Nos. 648D, 2531, 2533, 5709, 19187 and two each 662D and 2532, obsolete, use 24417
19218	——	Bed Frame with two 16555, four each 19219, 19220, six each 14010, wood screws 1¼ in. No. 10 and eight 158C, obsolete, use 24108
19219	1206	Bed Frame Cushion (leather) for 19218 and 19399, obsolete
19220	1206	Bed Frame Cushion Spring for 19218 and 19399, obsolete
19221	2045	Wrench for 936, 1516 and 1619
19223	——	Presser Foot Shank for 19225, 20134, 20311 and 24489
19224	——	Presser Foot Plate for 19225, obsolete
19225	1308	Presser Foot (hinged) complete for 12425, 19474 and 20119, Nos. 2532, 19223 and 19224, obsolete, use 24546
19226	1206	Bed Frame Hinge Connection for 19228 and 19398, obsolete
19227	1369	Bed Frame Hinge Connection Cap for 19228, obsolete, use 19397
19228	——	Bed Frame Hinge Connection complete, Nos. 211F, 19226 and 19227, obsolete, use 19398
19229	2004	Needle Bar (hollow) for high lift, for 44-1 to 44-3, 44-23, 44-72 and 44-75 Machines
19258	2009	Bobbin Winder Stop Latch with 152F and 1550J, for 19260
19260	——	Driving Attachment Driving Arm complete for 24073, Nos. 32D, 75D, 180F, 427E, 693D, 1508C, 1579C, 12170, 12178, 16515, 16518, 16530, 19258 and 27303
19292	771	Shuttle, 1 $\frac{11}{16}$ in. diam., for 44-1 to 44-3, 44-8, 44-23, 44-28, 44-72 and 44-75 Machines, Nos. 2996, 12393 and 24074
19293	771	Shuttle Bobbin Case complete for 19292, Nos. 591F, 592E, 2523, 2975, 7553, 15003 and 15098, obsolete, use 24074
19297	1315	Knife Bar with 2301, for 19300, 19393 and 24128
19298	1369	Knife Bar Lifting Spring for 44-8 Machine, obsolete
19299	——	Knife Bar Lifting Spring Hook for 19393, obsolete

NO.	PLATE	NAME
19300	——	Knife Bar complete for 44-8 Machine, Nos. 621D, 16565, 19105, 19297 and two 335D, obsolete, use 19393.....
19331	——	Foot Lifter complete for 44-1 to 44-3, 44-13, 44-17, 44-20, 44-22, 44-24 and 44-29 Machines, Nos. 76D, 766D, 802D, 1521E, 4880, 4885, 5598, 5670, 12240, 12241, 12415, 12416, 16510 and two 178E
19334	——	Presser Foot Plate for 19336.....
19335	——	" " Shank for 19336, 20361 and 120144.....
19336	1308	Presser Foot (hinged) complete for 12370, 20009, 26604, 35100 and 43979, Nos. 7298, 19334 and 19335.....
*19353	——	Arm with 11104, for 44-9 Machine.....
19354	——	Face Plate for 19355.....
19355	1311	Face Plate complete for 44-9, 44-23, 44-72 and 44-75 Machines, Nos. 2827, 12150 and 19354.....
19356	1312	Lifting Presser Bar Bell Crank for 24716, 24901 and 44-23 Machine.....
19357	1312	Lifting Presser Bar Bell Crank Connecting Link for 24716, 24901 and 44-23 Machine.....
19358	1312	Lifting Presser Bar Bell Crank Driving Arm for 19361.....
19359	1312	Lifting Presser Bar Bell Crank Driving Arm Shaft for 19361, 24352 and 62555
19360	1311	Lifting Presser Bar Bell Crank Driving Arm Shaft Bracket for 19361 and 24352
19361	——	Lifting Presser Bar Bell Crank Driving Arm Shaft Bracket complete for 44-9 Machine, Nos. 2049 and 19358 to 19360
19362	1313	Lifting Presser Bar Bell Crank Driving Arm Eccentric Connection for 44-9, 44-23 and 44-72 Machines.....
19363	1312	Lifting Presser Bar Guide Bracket with 453C, for 44-23 Machine and obsolete for 44-9 and 44-75 Machines.....
19364	1312	Lifting Presser Foot for 19370 for 44-9 and for 24345 for 44-23 Machine.....
19365	1311	Needle Bar Crank and Lifting Eccentric with 448C and 743C, for 44-9, 44-23 and 44-72 Machines.....
19366	1313	Vibrating Presser Bar for 24716.....
19367	1313	Feed Bar (upper) Cap for 44-72 and 44-75 Machines.....

NO.	PLATE	NAME
19367	1313	Vibrating Presser Bar Cap for 44-9 Machine.....
19368	1313	Vibrating Presser Bar Cushion (rawhide) for 44-9 Machine.....
19369	1313	Vibrating Presser Bar Spring for 44-9 Machine.....
19370	1312	Vibrating Presser Foot for 12370 and 43979 for 44-9 Machine.....
19371	1311	Lifting Lever with 448c, for 19373, 24427, 24482, 62573, 62574 and 62697.....
19372	1313	Lifting Lever Pin for 19373, 24427, 24482 and 62697.....
19373	——	Knee Lifter complete (power table) for 44-9 and 44-23 Machines, Nos. 76D, 766D, 802D, 1521E, 2777, 5598, 12415, 12416, 19371, 19372, 21301 and two 178E
19374	1313	Vibrating Presser Foot for 12369 and 12457 for 44-9 Machine.....
19375	1313	Lifting Presser Foot for 19374 and 19376, for 44-9 Machine.....
19376	1313	Vibrating Presser Foot for 26956 and for 20106 for 44-9 Machine.....
19391	8376	Knife Holder with 620F, 2291 and two 223F, for 19393 and 24128.....
19392	1271	Presser Foot, $\frac{3}{16}$ in. gauge and above, for 19103 and 24573.....
19393	——	Knife Bar complete for 44-8 Machine, Nos. 621D, 16565, 19297, 19299, 19391, 24109 and three 335D, obsolete.....
19394	——	Roller Presser complete, 1¼ in. fine roller, for 26150, Nos. 1928 and 16573.....
19397	1206	Bed Frame Hinge Connection Cap for 19398, obsolete.....
19398	——	Bed Frame Hinge Connection complete, for 19399, Nos. 211F, 19226 and 19397, obsolete.....
19399	1231	Bed Frame complete, Nos. 970D, two each 16555, 19398, four each 19219, 19220, six each 14010, wood screws 1¼ in. No. 10 and eight 158c, obsolete, use 24108
19400	1268	Feed Dog, for shirt work, for 44-13 Machine, obsolete, use 20117.....
19401	——	Shuttle Driver for 44-13 Machine, obsolete, use 19406.....
19402	——	Shuttle Race Body for 19404, obsolete...
19403	2006	" " Cap for 19404 and 19490, obsolete.....

NO.	PLATE	NAME
19404	1356	Shuttle Race complete for 44-13 Machine, Nos. 648D, 662D, 2419, 2533, 4621, 19402, 19403 and two 2532, obsolete, use 24325
19405	——	Throat Plate, small needle hole, for 20117
19406	2012	Shuttle Driver with two 1266C, for 44-13, 44-17, 44-22, 44-24 and 44-74 Machines
19408	1268	Feed Dog, for shirt work, for 44-13 Machine, obsolete, use 20138.....
19409	——	Throat Plate, large needle hole, for 20138 and 20162.....
19410	1263	Throat Plate, small needle hole, for 20138 and 20162.....
19411	1268	Feed Dog, for shirt work, for 44-13 Machine, obsolete, use 20147.....
19412	1260	Throat Plate, large needle hole, for 20147 and 44177.....
19413	——	Throat Plate, small needle hole, for 20147 and 44177.....
19414	1268	Feed Dog, for shirt work, for 44-13 Machine, obsolete, use 20151.....
19415	1262	Throat Plate, large needle hole, for 20151 and 44144.....
19416	——	Throat Plate, small needle hole, for 20151 and 44144.....
19417	1268	Feed Dog, for shirt work, for 44-13 Machine, obsolete, use 20158.....
19418	1262	Throat Plate, large needle hole, for 20158 and 44156.....
19419	——	Throat Plate, small needle hole, for 20158 and 44156.....
19447	1353	Oscillating Shaft Crank complete for 44-1 to 44-3, 44-8, 44-9, 44-13, 44-17, 44-22 to 44-24, 44-28, 44-72, 44-74 and 44-75 Machines, Nos. 457C, 1518E, 19449 and 19496.....
19448	1353	Oscillating Shaft Crank Slide Block for 19449 and 24050.....
19449	1353	Oscillating Shaft Crank Slide Block complete for 19447 and 44135, Nos. 229D, 988C, 12424 and 19448.....
19474	1258	Feed Dog, for corset work, for 26402, 35208, 35209, 35236, 35241, 35324, 35325, 35345, 35351 and 44-1 Machine
19475	1258	Throat Plate, large needle hole, for 19474
19488	775	Feed Dog for 44-17 Machine.....
19489	——	Shuttle Race Body for 19490, obsolete...

NO.	PLATE	NAME
19490	——	Shuttle Race complete for 44-17 Machine, Nos. 648D, 662D, 2419, 2533, 4621, 19403, 19489 and two 2532, obsolete, use 24327
19496	——	Oscillating Shaft Crank for 12390 and 19447
19497	1261	Throat Plate, large needle hole, for 20117
20002	778	Feed Dog, 18 teeth (16 teeth to the inch) beveled for hemmer, for 44-2 Machine
20009	1258	Feed Dog, for tailor work, for 44-1 Machine, obsolete
20010	1258	Throat Plate, large needle hole, for 20009, obsolete, use 44137
20018	1258	Feed Dog, for finishing knit underwear, for 44-1 Machine
20019	1258	Throat Plate, large needle hole, for 20018
20020	1308	Presser Foot for 20018
20022	5742	Machine Rest (felt) for machine on stand (Trimmings for End and Back Leaf Table)
20023	2004	Lifting Presser Bar Spring (heavy) .063 wire, for 44-9, 44-23, 44-72 and 44-75 Machines
20023	2004	Presser Bar Spring (heavy) .063 wire, for 44-1 to 44-3, 44-8, 44-13, 44-17, 44-20, 44-22, 44-24, 44-28, 44-29 and 44-74 Machines
20024	——	Throat Plate, small needle hole, for 20009, obsolete, use 44138
20037	2009	Tension Releaser for 44147
20041	1266	Feed Dog for 44-17 Machine
20042	1266	Throat Plate, large needle hole, for 20041
20043	——	" " small needle hole, for 20041
20057	——	Face Plate for 20058
20058	1340	Face Plate complete for 44-1 to 44-3, 44-13, 44-17, 44-20, 44-22, 44-24, 44-29 and 44-74 Machines, Nos. 2827, 12150 and 20057
20059	1341	Presser Bar Guide Bracket with 453C, for 44-1 to 44-3, 44-13, 44-17, 44-20, 44-22, 44-24, 44-29 and 44-74 Machines
20060	1311	Slack Thread Regulator for 44-1 to 44-3, 44-13, 44-17, 44-20, 44-24, 44-29 and 44-74 Machines

NO.	PLATE	NAME
		Nos. 20061 to 20063 for 44-1 to 44-3, 44-13, 44-17, 44-20, 44-22, 44-24 and 44-29 Machines, OBSOLETE
20061	1353	Tension Screw Stud Bushing.....
20062	1353	" " " Flange.....
20063	1353	" " " " Collar.....
20106	1259	Feed Dog for 28784 and 44-9 and 44-13 Machines.....
20107	1259	Throat Plate, small needle hole, for 20106
20115	1266	Feed Dog, $\frac{1}{16}$ in. stitch (7 teeth front and 5 teeth back of needle) for 44-29 Machine.....
20116	1266	Feed Dog, ⅛ in. stitch, 16 teeth to the inch (6 teeth front and 5 teeth back of needle) for 44-29 Machine.....
20117	1261	Feed Dog, 16 teeth (16 teeth to the inch) for shirt work, beveled for hemmer, for 44-13 and 44-20 Machines.....
20118	1308	Presser Foot, for general work, for 12450
20119	1259	Feed Dog, for heavy work on duck, overalls, etc., for 44-1 and 44-13 Machines
20120	1259	Throat Plate, large oblong needle hole, for 20119.....
20123	1266	Throat Plate for 20115, 20116, 20137, 20163 and 20164.....
20124	1261	Throat Plate, large needle hole, for 20117 and 20132.....
20125	——	Throat Plate, small needle hole, for 20117 and 20132.....
20132	1261	Feed Dog, 22 teeth (22 teeth to the inch) for shirt work, beveled for hemmer, for 44-20 Machine.....
20133	——	Presser Foot Plate for 20134.....
20134	1308	Presser Foot (hinged) complete, $\frac{3}{16}$ in. to ¼ in. gauge, for 44-3, 44-17 and 44-29 Machines, Nos. 19223, 20133 and 26276
20135	1264	Throat Plate, large needle hole, for 12450 and 20348.....
20136	——	Throat Plate, small needle hole, for 12450 and 20348.....
20137	1266	Feed Dog, ⅛ in. stitch, 22 teeth to the inch (8 teeth front and 5 teeth back of needle) for 44-29 Machine.....
20138	1263	Feed Dog, 13 teeth (12 teeth to the inch) for shirt work, beveled for hemmer, for 44-13, 44-20 and 44-24 Machines.....

NO.	PLATE	NAME
20139	1263	Throat Plate, large needle hole, for 20138 and 20162
20140	——	Throat Plate, small needle hole, for 20138 and 20162
20142	1260	Feed Dog, 13 teeth (16 teeth to the inch) for general work, for 44-20 Machine
20143	1260	Throat Plate, large needle hole, for 20142 and 62529
20144	——	Throat Plate, small needle hole, for 20142 and 62529
20147	1260	Feed Dog, 12 teeth (14 teeth to the inch) for 44-13 and 44-20 Machines
20148	1260	Throat Plate, large needle hole, for 20147 and 44177
20149	——	Throat Plate, small needle hole, for 20147 and 44177
20150	1308	Presser Foot for 20142 and 62529
20151	1262	Feed Dog, 13 teeth (14 teeth to the inch) for shirt work, beveled for hemmer, for 44-13 and 44-20 Machines
20152	1262	Throat Plate, large needle hole, for 20151 and 44144
20153	——	Throat Plate, small needle hole, for 20151 and 44144
20154	1266	Throat Plate Thread Guard for 20123, obsolete
20155	——	Presser Foot Plate for 20157
20156	——	" " Shank for 20157
20157	1309	Presser Foot (hinged) complete for 12433, 12460, 12471, 19488, 20041, 20115, 20116, 20137, 20163, 20164, 25967 and 26279 to 26283, Nos. 228D, 2532, 20155 and 20156
20158	1262	Feed Dog, 17 teeth (16 teeth to the inch) for shirt work, for 44-13 Machine
20159	1261	Feed Dog, for shirt work, for 44-20 Machine
20160	1261	Throat Plate, large needle hole, for 20159
20161	——	" " small needle hole, for 20159
20162	1263	Feed Dog, 17 teeth (16 teeth to the inch) for shirt work, beveled for hemmer, for 44-13 and 44-20 Machines
20163	1266	Feed Dog, $\frac{1}{16}$ in. stitch, $\frac{1}{64}$ in. higher (otherwise same as 20115) for 44-29 Machine
20164	1266	Feed Dog, $\frac{1}{8}$ in. stitch, $\frac{1}{64}$ in. higher (otherwise same as 20116) for 44-29 Machine

NO.	PLATE	NAME
20187	——	Throat Plate, small oblong needle hole, for 20119
20188	767	Needle Bar Crank with 858c and 1065c, for 44-1 to 44-3, 44-13, 44-17, 44-22, 44-24 and 44-74 Machines
20190	1263	Throat Plate, large needle hole, for 12369 and 12457
20191	——	Throat Plate, small needle hole, for 12369 and 12457
20197	1350	Crank Connecting Rod with 20198 and two 896E, for 44-1 to 44-3, 44-8, 44-9, 44-13, 44-17, 44-22 to 44-24, 44-28, 44-72, 44-74 and 44-75 Machines
*20198	——	Crank Connecting Rod Cap for 20197
20240	8375	Lifting Presser Bar Lifter for 44-72 Machine
20247	2687	Feed (upper) Shaft Regulator Crank with 1518E, 1942 and two 190D, for 24473
20249	2687	Feed (upper) Shaft Bracket for 44-75 Machine
20249	2687	Feed (upper) Shaft Bracket (back) for 44-72 Machine
20251	2688	Feed (upper) Shaft Collar with 456c, for 44-72 and 44-75 Machines
20254	2687	Feed (upper) Shaft Crank (back) with 191c, for 44-72 and 44-75 Machines
20255	8381	Lifting Lever Connecting Rod for 24482 and 62697
20268	——	Presser Foot Plate for 20270
20269	——	" " Shank for 20270
20270	1308	Presser Foot (hinged) complete for 12369, 12457 and 20106, Nos. 7298, 20268 and 20269
20275	1259	Feed Dog, for umbrella work, for 44-1 Machine
20276	1259	Presser Foot for 20275
20277	1259	Throat Plate, large needle hole, for 20275
20283	1315	Feed and Feed Lifting Eccentric with 446c, for 44-1 to 44-3, 44-8, 44-9, 44-13, 44-17, 44-22 to 44-24, 44-28, 44-72, 44-74 and 44-75 Machines
20284	1350	Feed Forked Connection for 44-1 to 44-3, 44-8, 44-9, 44-13, 44-17, 44-22 to 44-24, 44-28, 44-72, 44-74 and 44-75 Machines
20307	8381	Bobbin Winder Frame for 20308

NO.	PLATE	NAME
20308	1311	Bobbin Winder Frame complete for 20309, Nos. 333D, 5960, 5961, 5963, 15077 and 20307
20309	——	Bobbin Winder complete for 12358, Nos. 32D, 180F, 12168, 12170 and 20308
20310	——	Presser Foot Plate for 20311
20311	781	Presser Foot (hinged) complete for 12372, 12437, 12455, 2468, 12481, 20002 and 20336, Nos. 2532, 19223 and 20310
20314	1353	Tension Releaser for 44-1 to 44-3, 44-13, 44-17, 44-20, 44-22, 44-24 and 44-29 Machines, obsolete
20325	1264	Feed Dog, 18 teeth (16 teeth to the inch) for shirt work, for 44-20 Machine
20326	1264	Throat Plate, large needle hole, for 20325
20327	——	" " small needle hole, for 20325
20336	1264	Feed Dog, for shirt work, beveled for hemmer, for 44-2 Machine
20337	——	Throat Plate, large needle hole, for 20336
20338	1264	" " small needle hole, for 20336
20342	781	Presser Foot for 12450 and 20348
20343	781	" " with guide on bottom to the right of needle hole, for 44-1, 44-13 and 44-29 Machines
20344	——	Presser Foot Plate for 20346
20345	——	" " Shank for 20346
20346	781	Presser Foot (spring hinged) complete for 44-2 and 44-20 Machines, Nos. 2532, 20344, 20345 and 26231
20348	777	Feed Dog, 22 teeth (36 teeth to the inch) for chiffon, for 44-1, 44-13 and 44-20 Machines
20349	1267	Feed Dog for 44-2 Machine
20350	1267	Throat Plate, large needle hole, for 20349
20351	——	" " small needle hole, for 20349
20352	1267	Feed Dog, for general muslin work, for 44-1 Machine
20353	1267	Throat Plate, large needle hole, for 20352
20354	——	" " small needle hole, for 20352
20360	——	Presser Foot Plate for 20361
20361	781	Presser Foot (hinged) plain bottom, complete, for 44-3, 44-17 and 44-29 Machines, Nos. 19335, 20360 and 26276
20362	——	Throat Plate, small needle hole, for 20275
20367	770	Needle Bar Connecting Stud Slide Block for 20368, obsolete

NO.	PLATE	NAME
20368	770	Needle Bar Connecting Stud complete, Nos. 453c, 12383 and 20367, obsolete, use 12384
20369	775	Feed Dog, 16 teeth (18 teeth to the inch) for 44-3 Machine
20458	780	Presser Foot for 44136
20461	2045	Wrench for 1582 and 1701
20468	8375	Feed Dog, for tucking, for 44-20 Machine
20469	8375	Throat Plate, large needle hole, for 20468
20470	——	" " small needle hole, for 20468
20471	777	Feed Dog, 22 teeth (22 teeth to the inch) for shirt work, beveled for hemmer, for 44-2 Machine
20472	——	Presser Foot Plate for 20474
20473	——	" " Shank for 20474
20474	8375	Presser Foot (spring hinged) complete, for fine silk, etc., for 44-20 Machine, Nos. 2532, 20472, 20473 and 26231
20498	——	Bobbin Winder (Hamburg) complete for 4370, Nos. 32D, 180F, 12168, 12170 and 43983
20595	2012	Shuttle Bobbin Case Position Finger for 20651, obsolete
20596	2012	Shuttle Body for 20655, obsolete
20649	5737	" Bobbin Case Latch for 20650
20650	——	Shuttle Bobbin Case Hinge for 20651 and 20756, Nos. 2973, 2974 and 20649
20651	2012	Shuttle Bobbin Case complete for 20655, Nos. 591F, 592E, 2523, 2975, 20595, 20650 and 20654, obsolete
20654	5737	Shuttle Tension Spring for 20651 and 20756
20655	2012	Shuttle, $1\frac{11}{16}$ in. diam., Nos. 19131, 20596 and 20651, for 44-13, 44-17, 44-22 and 44-24 Machines, obsolete
20755	5737	Shuttle Bobbin Case Position Finger for 20756
20756	5737	Shuttle Bobbin Case complete for 20758, Nos. 591F, 592E, 2523, 2975, 20650, 20654 and 20755
20757	5737	Shuttle Body for 20758
20758	5737	Shuttle, $1\frac{11}{16}$ in. diam., for 44-13, 44-17, 44-22, 44-24 and 44-74 Machines, Nos. 19131, 20756 and 20757
21301	1353	Lifting Lever Link for 19373, 24427, 24482, 62573, 62574 and 62697
22003	2045	Wrench for 1550 and 1749

NO.	PLATE	NAME
22356	8380	Ruffling Blade Holder for 44-75 Machine
22357	8380	" " " Hinge Stud for 44-75 Machine.....
22361	8380	Ruffling Blade Holder Spring Stop for 44-75 Machine.....
23219	2645	Presser Foot Edge Guide Position Pin for 28858.....
24008	——	Shuttle Race Body for 62623, obsolete...
24009	2006	" " Cap for 24012, 24120, 24121, 24998, 62513 and 62623.....
24010	1357	Shuttle Race complete for 44-13 Machine, Nos. 648D, 2419, 2533, 62623 and two 2532, obsolete, use 24325.....
24011	——	Shuttle Race Body for 24012, obsolete...
24012	1357	Shuttle Race complete for 44-17 Machine, Nos. 648D, 2419, 2533, 24009, 24011 and two each 1053D and 2532, obsolete, use 24327 .....
24019	2014	Thread Take-up Spring, obsolete, use 8511
*24025	——	Arm with 11104, for 44-20 and 44-29 Machines.....
24026	1339	Arm Shaft for 44-20 and 44-29 Machines
*24027	——	Bed for 44-20 and 44-29 Machines.....
24028	1339	Crank Connecting Rod with 24085 and two 896E, for 44-20 and 44-29 Machines
24030	——	Face Plate for 24031, obsolete.....
24031	1351	Face Plate complete for 44-20 Machine, Nos. 934E, 9545, 12150, 12152, 24030, 24033, 24072 and two 24032, obsolete
24032	1369	Face Plate Thread Retainer Disc for 24031, obsolete.....
24033	1369	Face Plate Thread Retainer Thread Guard for 24031, obsolete.....
24034	1340	Feed Bar for 44-20 and 44-29 Machines
24035	1340	" and Feed Lifting Eccentric with 448C, for 44-20 and 44-29 Machines.....
24036	1340	Feed and Feed Lifting Eccentric Sleeve
24037	1339	" Forked Connection for 44-20 and 44-29 Machines.....
24039	1369	Needle Bar Bushing for 44-20 Machine, obsolete, use 24090.....
24040	1341	Needle Bar Connecting Link with 794E, for 44-20 and 44-29 Machines.....
24041	1341	Needle Bar Connecting Stud with 207E, for 44-20 and 44-29 Machines.....

NO.	PLATE	NAME
24042	1340	Needle Bar Crank with 855c, 858c, 1036c and 1037c, for 44-20 Machine, obsolete, use 24052
24043	1340	Oscillating Rock Shaft for 24044
24044	——	Oscillating Rock Shaft complete for 44-20 and 44-29 Machines, Nos. 4784, 12388 and 24043
24045	1339	Oscillating Shaft for 44-20 and 44-29 Machines
24046	1341	Oscillating Shaft Bushing (back) for 44-20 and 44-29 Machines
24047	1341	Oscillating Shaft Bushing (front) for 44-20 and 44-29 Machines
24048	——	Oscillating Shaft Crank for 24049
24049	1343	Oscillating Shaft Crank complete for 44-20 and 44-29 Machines, Nos. 462c, 1636e, 24048 and 24050
24050	1343	Oscillating Shaft Crank Slide Block complete for 24049, Nos. 229d, 1035c, 12424 and 19448
24051	1343	Shuttle Bobbin for 24059
24052	1340	Needle Bar Crank with 858c, 1036c, 1037c and 1065c, for 44-20 and 44-29 Machines
24055	1343	Shuttle Bobbin Case Position Finger for 24056
24056	1343	Shuttle Bobbin Case complete for 24059, Nos. 591f, 592e, 2523, 2975, 15141, 24055 and 24058
24057	1343	Shuttle Body for 24059
24058	1343	" Tension Spring for 24056
24059	1343	Shuttle, 1 $\frac{11}{16}$ in. diam., for 44-20 and 44-29 Machines, Nos. 24051, 24056 and 24057
*24060	——	Shuttle Driver for 24061
24061	1343	" " 24060 with two 462c, for 44-20 and 44-29 Machines
24062	1342	Shuttle Race Back for 24065 and 24438
24063	——	" " Body for 24065, obsolete
24064	1342	" " Cap for 24065 and 62510
24065	1342	Shuttle Race complete for 44-20 and 44-29 Machines, Nos. 648d, 2533, 24062 to 24064 and two each 1053d and 2532, obsolete, use 24438
24066	1340	Slack Thread Regulator for 44-20 and 44-29 Machines, obsolete, use 20060
24067	1369	Thread Take-up Crank for 44-20 Machine, obsolete

NO.	PLATE	NAME
24068	1341	Thread Take-up Lever for 24070.....
24069	1369	" " Crank Lever Link for 44-20 Machine, obsolete, use 24099.....
24070	——	Thread Take-up Lever complete for 44-20 and 44-29 Machines, Nos. 12166, 24068 and 24099.....
24071	1343	Thread Take-up Spring for 24984.....
24072	1369	Face Plate Thread Retainer Disc Cover for 24031, obsolete.....
24073	——	Driving Attachment with Bobbin Winder and Treadle complete for 44-13, 44-17, 44-20, 44-22, 44-24, 44-29 and 44-74 Machines, Nos. 210D, 692D, 14234 or 15131, 16519, 16592, 16594, 19260, 24355, 24530, 27072, 27308, two 65D and three 130D.....
24074	771	Shuttle Bobbin Case complete for 19292 and 24890, Nos. 591F, 592E, 2523, 2975, 7553, 15098 and 15141.....
24078	1343	Thread Guard (side of arm) for 44-20 and 44-29 Machines, and obsolete for 44-1 to 44-3, 44-13, 44-17, 44-22 and 44-24 Machines.....
24079	2644	Drip Pan with four 1 in. wire nails.....
*24085	——	Crank Connecting Rod Cap for 24028...
24090	1341	Needle Bar Bushing with 29532, for 44-20 and 44-29 Machines, obsolete, use 24442
24097	1341	Thread Take-up Crank for 44-20 and 44-29 Machines.....
24099	1341	Thread Take-up Lever Link for 24070...
24101	——	Needle Clamp Body for 24103.....
24102	1353	" " Thread Guide for 24103...
24103	1353	Needle Clamp (high lift) complete for 19229 for 44-1 to 44-3, 44-23, 44-72 and 44-75 Machines, Nos. 651D, 808F, 24101 and 24102.....
24104	1350	Oscillating Rock Shaft for 24105.....
24105	——	Oscillating Rock Shaft complete for 44-1 to 44-3, 44-8, 44-9, 44-13, 44-17, 44-22 to 44-24, 44-28, 44-72, 44-74 and 44-75 Machines, Nos. 4784, 12388 and 24104
24106	4761	Bed Frame Cushion (felt) for 24108.....
24107	4761	" " Hinge Connection for 24108.
24108	3538	" " with 970D, two each 9261, 24107, four each 158E, 24106 and six wood screws 1¼ in. No. 12.....
24109	8376	Knife Holder Handle for 19393 and 24128

NO.	PLATE	NAME
24110	——	Knife Bar Driving Crank Bracket complete for 44-8 and 44-28 Machines, Nos. 2022, 16563, 16564 and 16589, obsolete, use 24433
24117	2006	Shuttle Bobbin Case Guide Plate for 24120 and 24121, obsolete
24118	——	Shuttle Race Body for 24120, obsolete
24119	——	" " " " 24121, obsolete
24120	2006	Shuttle Race complete for 44-13 Machine, Nos. 907D, 2419, 2533, 24009, 24117, 24118, two 2532 and four 1053D, obsolete, use 24325
24121	1358	Shuttle Race complete foi 44-17 Machine, Nos. 907D, 2419, 2533, 24009, 24117, 24119, two 2532 and four 1053D, obsolete, use 24327
24122	1317	Knife Bar Lifting Spring for 44-8 and 44-28 Machines
24123	1317	Knife Bar Lifting Spring Case for 44-8 and 44-28 Machines
24124	1317	Knife Bar Lifting Spring Guide for 24906
24125	1317	" " " " " Bracket for 24906
24128	——	Knife Bar complete for 44-8 and 44-28 Machines, Nos. 621D, 19297, 19391, 24109, 24906 and three 335H
24131	2014	Arm Oil Tube with 29599, for oiling 20283 and 24035
24161	——	Knee Lifter complete (bench stand) for 44-1 to 44-3, 44-13, 44-17, 44-20, 44-22, 44-24 and 44-29 Machines, Nos. 76D, 766D, 802D, 1521E, 5598, 12240, 12241, 12415, 12416, 16510, 19168 and two 178E
24195	1349	Arm Shaft for 44-22 and 44-28 Machines
24198	1369	Ruffling Arm with 190D, for 44-22 Machine, obsolete, use 26890

Nos. 24199 to 24201 for 44-22 and 44-28 Machines

24199	1323	Ruffling Arm Shaft
24200	1324	" " " Bracket (right)
24201	1324	" " " " (left)
24203	1371	Ruffler Ruffling Blade Holder for 28816
24203	1344	Ruffling Blade Holder for 28845
24204	1344	" " " Spring for 28845 and 44-75 Machine

NO.	PLATE	NAME
24204	1371	Ruffler Ruffling Blade Holder Spring for 28816
24205	1371	Ruffler Ruffling Blade Holder Spring Stop for 28816
24205	1344	Ruffling Blade Holder Spring Stop for 28845
24206	1371	Ruffler Ruffling Blade Holder Stud for 28816
24206	1344	Ruffling Blade Holder Stud for 28845
24207	1323	" Eccentric with two 453c, for 44-22 and 44-28 Machines
24208	1323	Ruffling Eccentric Collar with 453c, for 44-22 and 44-28 Machines
24209	1324	Ruffling Eccentric Connection for 44-22 Machine, obsolete
24210	1324	Ruffling Eccentric Connection Washer for 44-22 and 44-28 Machines
24211	1323	Ruffling Regulator with 225F, for 44-22 and 44-28 Machines
24219	1323	Ruffling Eccentric Connection with 24220 and two 742E, for 44-22 and 44-28 Machines
*24220	——	Ruffling Eccentric Connection Cap for 24219
24296	1348	Balance Wheel (power) light rim, $2\frac{3}{16}$ in. pulley, with two 448c, for 44-1 to 44-3, 44-8, 44-9, 44-13, 44-17, 44-22, 44-23, 44-24, 44-28, 44-72 and 44-75 Machines
24297	1340	Balance Wheel Oil Cover
*24302	——	Arm with 11104, for 44-22 Machine
24303	1344	Feed Dog for 26018 and 44-22 Machine
24304	1344	Presser Foot for 44-22 Machine
24305	1344	Ruffling Blade for 44-22 Machine
24306	1344	Throat Plate for 24303
24307	1369	Ruffling Arm with 190D, for 44-22 Machine, obsolete, use 26890
24323	2046	Shuttle Bobbin Case Position Plate for 24325 and 24327
24324	——	Shuttle Race Body for 24998
24325	2046	Shuttle Race complete for 44-13, 44-22, 44-24 and 44-74 Machines, Nos. 907D, 2419, 2533, 24323, 24998 and two each 391D and 2532
24326	——	Shuttle Race Body for 62513
24327	1359	Shuttle Race complete for 44-17 Machine, Nos. 907D, 2419, 2533, 24323, 62522 and two 391D

NO.	PLATE	NAME
24328	1339	Balance Wheel, light rim, 2¼ in. pulley, with two 448c, for 44-20 and 44-29 Machines
*24335	——	Arm with 11104, for 44-24 Machine
*24340	——	" " " " 44-23 Machine
*24341	——	Bed for 44-23 Machine
24342	1311	Feed Bar (lower) for 44-23 Machine
24343	1354	" " (upper) with 620c, for 44-23 Machine
24344	1267	Feed Dog for 26956, 35072 and 44-72 Machine
24344	1267	Feed Dog (lower) for 44-23 Machine
24345	1354	" " (upper) for 44-23 Machine
24346	1349	" Rock Shaft for 24347 and 24377
24347	——	Feed Rock Shaft complete for 44-23 Machine, Nos. 3043 and 24346, obsolete, use 24377
24348	1354	Feed Pressure Spring for 44-23 Machine
24349	1354	" (upper) Lifting Bar for 44-23 Machine
24350	1354	Feed (upper) Lifting Bar Hinge Pin for 44-23 Machine
24351	1354	Lifting Presser Bar Bell Crank Driving Arm for 24352 and 62555
24352	——	Lifting Presser Bar Bell Crank Driving Arm Shaft Bracket complete for 44-23 and 44-72 Machines, Nos. 2049, 19359, 19360 and 24351
24353	1267	Throat Plate, large needle hole, for 24344
24354	——	" " small needle hole, for 24344
24355	1315	Driving Attachment Balance Wheel Oil Cover for 16531 and 24073
24376	——	Feed Rock Shaft complete for 44-1 to 44-3, 44-8, 44-9, 44-13, 44-17, 44-20, 44-22, 44-24, 44-28, 44-29 and 44-74 Machines, Nos. 16506 and 29633
24377	——	Feed Rock Shaft complete for 44-23 Machine, Nos. 24346 and 29633
24378	2637	Foot Lever with two 1157c, for 24379
24379	2637	" " 24378 with 5671, 24380, 24381 and four wood screws 1 in. No. 12, for 24387
24380	2637	Foot Lever Bracket for 24379
24381	2637	" " Foot Rest with 24382, for 24379
24382	2638	" " " " Pin for 24381

NO.	PLATE	NAME
		Nos. 24383 to 24386 for 24387
24383	2637	Foot Lever Pitman Rod (lower) 17 in. long.....
24384	2638	Foot Lever Pitman Rod (lower) Stop Collar with 1157c.....
24385	2637	Foot Lever Pitman Rod (upper) 17 in. long, with 2761.....
24386	2637	Foot Lever Pitman Rod (upper) Guide Bracket with three wood screws 1 in. No. 12.....
24387	——	Foot Lever complete, Nos. 9079, 24379, 24383, 24385, 24386 and two 24384....
24391	8376	Needle Bar Thread Guard for 16568.....
*24407	——	Arm with 11104, for 44-28 Machine.....
24408	1271	Feed Dog for 44-28 Machine.....
24409	1344	Ruffling Blade for 44-28 Machine,.....
24410	1352	Ruffling Separating Blade on Shank complete for 44-22 and 44-28 Machines, Nos. 24718, 43919 and two 4604.....
24411	1344	Presser Foot for 24408.....
24412	1361	Shuttle Bobbin Case Position Plate for 24415, 24417, 24419 and 24438.....
24413	——	Shuttle Race Body for 25000 and 62502..
24414	1362	" " Cap for 24417 and 25000...
24415	1361	Shuttle Race complete for 44-1, 44-2, 44-23, 44-28, 44-72 and 44-75 Machines, Nos. 907d, 2531, 2533, 24412, 25000 and two each 391d and 2532.....
24416	——	Shuttle Race Body for 24417.....
24417	1362	Shuttle Race complete for 44-3 Machine, Nos. 907d, 2531, 2533, 24412, 24414, 24416 and two each 391d, 1053d and 2532.....
24418	1362	Shuttle Race Cap for 62502.....
24419	1362	Shuttle Race complete for 44-8 and 44-9 Machines, Nos. 907d, 2531, 2533, 24412, 62517 and two 391d.....
24426	——	Foot Lifter complete for 44-8 and 44-28 Machines, Nos. 76d, 766d, 802d, 1521e, 4880, 4885, 5598, 5670, 12241, 12415, 12416, 16585, 16586 and two 178e.....
24427	——	Foot Lifter complete for 44-9 and 44-23 Machines, Nos. 76d, 766d, 802d, 1521e, 4880, 4885, 5598, 5670, 12415, 12416, 19371, 19372, 21301 and two 178e.....

NO.	PLATE	NAME
24429	1271	Throat Plate complete for 24408, Nos. 236F, 5730, 5731 and two 578D.....
24431	1352	Knife Bar Crank with 191C, for 24432...
24432	——	Knife Bar Crank complete for 24433, Nos. 1162C, 1564D, 2297 and 24431.....
24433	——	Knife Bar Driving Crank Bracket complete for 44-8 and 44-28 Machines, Nos. 2022, 16563, 16564 and 24432.....
24437	——	Shuttle Race Body for 62510.....
24438	1364	Shuttle Race complete for 44-20 and 44-29 Machines, Nos. 907D, 2533, 24062, 24412, 62519 and two 391D.....
24442	2647	Needle Bar Bushing with 29532, for 44-20 and 44-29 Machines.....
24451	2647	Needle Bar for 44-20 and 44-29 Machines
24452	2647	" " Gib for 24453.....
24453	2647	" Clamp with 196F and 24452, for 44-20 and 44-29 Machines.....
*24454	——	Bed for 44-9 Machine.....
*24469	——	Arm with 11104, for 44-72 Machine.....
*24470	——	Bed for 44-72 and 44-75 Machines.....
24471	2688	Feed Bar (upper) for 24901.....
24472	2687	" Rock Shaft for 24473.....
24473	——	Feed Rock Shaft complete for 44-72 and 44-75 Machines, Nos. 20247, 24472 and 29633.....
24474	2687	Feed (upper) Shaft for 44-72 Machine, obsolete.....
24475	2687	Feed (upper) Shaft Bracket (front) for 44-72 Machine.....
24476	2687	Feed (upper) Shaft Crank (front) with two 460C and four 454C, for 62674.....
24477	2687	Feed (upper) Shaft Crank (front) Connection for 62674.....
24478	2688	Feed (upper) Shaft Crank (front) Connection Hinge Pin for 44-72 Machine, obsolete.....
24479	2688	Feed (upper) Shaft Crank (front) Hinge Pin for 62674 and 44-75 Machine.....
24480	2688	Feeding Foot, 16 teeth to the inch, with two 1019F, for 35072 and 44-72 Machine
24481	2688	Lifting Presser Foot for 35072 and 44-72 Machine.....

NO.	PLATE	NAME
24482	——	Knee Lifter complete (power table) for 44-72 Machine, Nos. 76D, 766D, 802D, 1521E, 2777, 5598, 12416, 19371, 19372, 20255, 21301 and two 178E.....
24488	——	Presser Foot Plate for 24489.....
24489	1309	Presser Foot (hinged) complete, for heavy work, Nos. 2532, 19223 and 24488.....
24528	8381	Driving Attachment Driving Arm Pitman Crank Spring Adjusting Collar with three 448C, for 24529.....
24529	8381	Driving Attachment Starting Crank Shaft Bracket with 24528, for 24530.....
24530	——	Driving Attachment Starting Crank Shaft Bracket complete for 16531 and 24073, Nos. 12189, 16520, 16521, 16525, 24529 and two 2022.....
24544	——	Presser Foot Plate for 24546 and 24983..
24545	——	" " Shank for 24546, obsolete..
24546	780	Presser Foot (spring hinged) complete for 12425, 19474 and 20119, Nos. 24544, 24545, 26231 and 62527, obsolete, use 24983.....
24549	8379	Feed (upper) Shaft for 44-72 Machine....
24550	8375	" " " Crank (front) Connection Hinge Pin for 44-72 Machine.....
24572	2067	Throat Plate, small needle hole, for 19474 for 35324, 35347 and 35351.....
24573	1271	Feed Dog, 24 teeth (32 teeth to the inch) for 44-8 Machine.....
24585	8375	Feed Regulator Thumb Screw Stop for 44-3, 44-17 and 44-29 Machines.....
24589	5736	Lifting Presser Bar Guide Bracket with 453C, for 24716 and 24901.....
24590	5736	Lifting Presser Bar Guide Bracket Support for 44-9 and 44-72 Machines.....
24716	——	Lifting Presser Bar Guide Bracket complete for 44-9 Machine, Nos. 19356, 19357, 19366, 24589 and three 199D...
24718	1352	Ruffling Separating Blade for 24410.....
24722	1271	Presser Foot, $\frac{1}{16}$ in. to $\frac{11}{64}$ in. gauge, for 19103 and 24573.....
24725	8375	Feeding Foot, 36 teeth to the inch, with two 1019F, for 44-72 Machine.....
24797	8377	Hand Attachment Body Bracket with 453C, for 62587.....
24798	8378	Hand Attachment Driver Finger for 62632
24799	8377	Bobbin Winder Frame for 24800.....

NO.	PLATE	NAME
24800	——	Bobbin Winder Frame complete for 62587, Nos. 333D, 5960, 5961, 5963, 24799 and 24802
24801	8378	Bobbin Winder Frame Hinge Stud for 62587
24802	8378	Bobbin Winder Spindle with 15072, for 24800
24803	8377	Bobbin Winder Stop Latch for 62587
24804	8377	" " " " Arm with 453C, for 62587
24805	8378	Bobbin Winder Tension Bracket for 24806
24806	8378	Bobbin Winder Tension Bracket complete for 24807, Nos. 2455, 2457, 15367 and 24805
24807	——	Hand Attachment complete with Bobbin Winder for 44-74 Machine, Nos. 205D, 692D, 24806 and 62587
24889	8375	Shuttle Body for 24890
24890	8375	Shuttle, $1\frac{11}{16}$ in. diam., for 44-9 Machine, Nos. 2996, 24074 and 24889
24901	——	Lifting Presser Bar Guide Bracket 24589 with 19356, 19357, 24471 and three 199D, for 44-72 and 44-75 Machines
*24906	——	Knife Bar Lifting Spring Guide 24124, with 2523 and 24125, for 24128
24908	8383	Drip Pan with two wood screws ½ in. No. 5 R. H. B., for 24108
24969	2551	Feed Lifting Rock Shaft for 24970
24970	——	Feed Lifting Rock Shaft complete for 44-1 to 44-3, 44-8, 44-9, 44-13, 44-17, 44-22 to 44-24, 44-28, 44-72, 44-74 and 44-75 Machines, Nos. 12376 and 24969
24982	——	Presser Foot Shank for 24983
24983	781	Presser Foot (spring hinged) complete for 12425, 12481, 19474 and 20119, Nos. 24544, 24982, 26231 and 62527
24984	——	Tension complete for 44-20 and 44-29 Machines, Nos. 7336, 8238, 24071, 32572, 32574, 44141 and two 2102
24998	——	Shuttle Race Body 24324 with 24009 and two 1053D, for 24325
25000	——	Shuttle Race Body 24413 with 24414 and two 1053D, for 24415

NO.	PLATE	NAME
		Nos. 25001 to 25003 (Trimmings for End and Back Leaf Table)
25001	3825	Back Leaf Bracket with two wood screws 1 in. No. 10
25002	3825	Back Leaf Scroll Bracket with ¾ in. No. 9 and two 1 in. No. 12 wood screws
25003	3825	Back Leaf Sliding Hinge, Nos. 25149, three 25151 and six wood screws ¾ in. No. 8
25016	——	Belt, size ¼ in., length 69½ in., with 25127, for 25265 and 25284
25057	3825	End Leaf Support complete, Nos. 25143, 25168, 25169 and two wood screws ⅝ in. No. 7 (Trimmings for End and Back Leaf Table)
25060	3825	End Leaf Support Button with wood screw 1½ in. No. 12 R. H. B. (Trimmings for End and Back Leaf Table)
25082	8382	Treadle for 25279
25086	3825	Wrench for 1507 and 1670 for 25265, 25279 and 25284
25127	3826	Belt Hook for 25016, 25490 and 46657
25143	5742	End Leaf Support Lever Hinge Pin for 25057
25149	3825	Back Leaf Sliding Hinge Rod for 25003
25151	3825	" " " " Plate for 25003
25168	3825	End Leaf Support Bracket for 25057
25169	3825	" " " Lever for 25057
25200	3825	Wrench for 972 for 25265 and 25284
25265	——	Stand (iron work) rocking treadle, ball bearing pitman, complete, Nos. 25086, 25200, 25301, 46520, 46524, 46533, two 46522 and four 748E
25279	——	Stand (iron work) complete, for electric motor, Nos. 7958, 25082, 25086, 46533, two 46522 and four 748E
25284	——	Stand (iron work) rocking treadle, ball bearing pitman, complete, for foot power and S. D. 11 or S D. 12 electric motors, Nos. 10875, 25086, 25200, 25301, 46524, 46533, 46656, two 46522 and four 748E
25301	3825	Band Wheel, 16 in. diam., with 972c, for 25265 and 25284
*25360	——	Pitman Rod Ball for 46523
*25360	——	" " (lower) Ball for 46658
25361	3826	" " Ball Screw Bearing for 46630

NO.	PLATE	NAME
25361	3826	Pitman Rod (lower) Ball Screw Bearing for 46630
25362	3826	Pitman Ball, size $\frac{3}{16}$ in., for 46520 and 46656
25371	3826	Pitman Rod Ball Bushing for 46520
25371	3826	" " (lower) Ball Bushing for 46656
25490	——	Belt, size ¼ in., length 36 in., with 25127, for 25279
25644	2024	Binder Bed with 25645, for 25650
25645	2024	" Folder for 25644

Nos. 25646 to 25648 for 25650, 25653 and 25656

25646	——	Binder Folder Guide (lower) with 25855
25647	2024	" " " (upper)
25648	2024	" Pressure Spring
25650	2024	Binder (adjustable, size 1) complete, Nos. 334D, 1577D, 7071, 25644 and 25646 to 25648
25651	——	Binder Bed with 25652, for 25653
25652	——	" Folder for 25651
25653	——	Binder (adjustable, size 2) complete, Nos. 334D, 1577D, 7071, 25646 to 25648 and 25651
25654	——	Binder Bed with 25655, for 25656
25655	——	" Folder for 25654
25656	——	Binder (adjustable, size 3) complete, Nos. 334D, 1577D, 7071, 25646 to 25648 and 25654
25669	——	Binder Folder Slide with 25670 and 25671, for 36457
25670	2038	Binder Folder Slide Block for 25669
25671	2038	" " " " Rivet for 25669
25672	6254	" " " Carrier with 656E, for 36463
25673	6254	Binder Folder Slide Carrier Adjusting Thumb Nut Guide for 36463
25677	6254	Binder Pressure Spring for 36463
25698	2024	" Folder for 26694
25703	2024	" Pressure Spring with 26698, for 26694
25705	——	" on Shank, for ⅜ in. tape
25706	——	" " " " $\frac{7}{16}$ in. tape
25707	2605	" " " " ½ in. tape
25708	——	" " " " $\frac{9}{16}$ in. tape
25709	——	" " " " ⅝ in. tape
25710	——	" " " " $\frac{11}{16}$ in. tape
25711	——	" " " " ¾ in. tape
25712	——	" " " " $\frac{13}{16}$ in. tape

NO.	PLATE	NAME
25713	——	Binder on Shank for 7/8 in. tape.....
25714	——	" " " " 15/16 in. tape.....
25715	——	" " " " 1 in. tape.....
25721	2021	" Folder for 26250, 26466, 28657 and 28784.....
25722	2021	Binder Ribbon Tension complete for 26250, 26466, 28657 and 28784, Nos. 26614, 26616 and four 26615.....
25733	2022	Binder Folder, for 1/2 in. binding, for 26402
25734	2022	Binder Ribbon Tension complete for 26402, Nos. 26617, 26618 and seven 26486.....
25744	1314	Binder Folder and Ribbon Tension with nine 26486, for 1/2 in. binding, for 26701
25745	——	Binder Folder and Ribbon Tension with nine 26486, for 1/8 in. binding, for 26701
25788	2026	Corder Arm with 25789, for 25792.....
25789	2026	" " Tip for 25788.....
25789	1385	" Bow Tip for 26938.....
25790	2026	" Arm Hinge Pin for 25792.....
25791	2026	" " Bracket for 25792.....
25792	2026	Corder Arm and Bracket complete for 26169, 26328, 28750 and 28788, Nos. 190D, 879D, 25788, 25790 and 25791
25855	2038	Binder Folder Guide (lower) Screw Stud for 25646.....
25866	2045	Guide, for flush throat plate.....
25873	2045	" (combination).....
25874	2045	" for raised throat plate.....
25888	2028	Hemmer Tongue.....
		Nos. 25919 TO 25921 FOR 12372, 12455, 20002, 20117 AND 20151
25919	——	Hemmer (foot) 5/64 in. hem.....
25920	2028	" " 1/8 in. hem.....
25921	——	" " long, 1/8 in. hem, for shirts
		Nos. 25922 TO 25924 FOR 12369 AND 12457
25922	2028	Hemmer (foot) 3/16 in. hem.....
25923	——	" " long, 3/16 in. hem, for shirts
25924	——	" " 1/4 in. hem.....
25967	1387	Presser Foot Strip Gauge for 12435 and 20157.....
25983	2021	Presser Foot for 26250, 26466 and 28657...
25984	2025	" " " 26328.....
25985	2029	" " (single toe) for gathering....

NO.	PLATE	NAME
25990	2029	Quilter complete, Nos. 25991 and 25992
25991	2029	" Guide for 25990
25992	2029	" " Holder with two 207F, for 25590 and 28660
25993	984	Ruffler Frame with 25994 to 25996 and 26001, for 26230
		Nos. 25994 TO 25996 FOR 25993
25994	2014	Ruffler Frame Stud
25995	2014	" " Block
25996	2014	" " " Rivet
		Nos. 25997 TO 26000 FOR 26230
25997	984	Ruffler Driving Lever
25998	984	" " " Spring
25999	984	" Ruffling Blade
26000	984	" " " Lever
26001	2014	" " " " Stop Pin for 25993
26002	2014	Ruffler Ruffling Blade Clamp for 26230
26005	984	" Driving Lever for 26018
26007	984	" Foot for 26018
26010	984	" Ruffling Blade with 8505, for 26018
26011	984	" " " Lever with 26189 and 26629, for 26018
26016	984	Ruffler Frame for 26018
26017	984	" Needle Clamp with 808F, for 26018
26018	984	Ruffler (power) complete, Nos. 69D, 207F, 811D, 812B, 1621E, 1666D, 26005, 26007, 26010, 26011, 26016, 26017 and 35019
26026	2045	Screw Driver, machine (Attachments and Accessories)
26080	1383	Throat Plate Needle Plate for 26760 and 28342
26089	2036	Tucker Frame for 26517
26090	2036	" Rocking Bar for 26517
26092	2671	Presser Foot Graduated Adjustable Guide Clamping Lever Spring Rivet for 28953
26092	2038	Tucker Tuck Marking Plate Rivet for 26101
		Nos. 26093 TO 26098 FOR 26517
26093	2036	Tucker Stop Bracket
26094	2036	" Tuck Guide
26095	2036	" " Marking Plate
26096	2036	" " Marker Guide Clamp

NO.	PLATE	NAME
26097	2036	Tucker Tuck Marker Guide Rod.....
26098	2036	" " Smoothing Spring.....
		Nos. 26099 to 26101 for 26377 and 26687
26099	2037	Tucker Bed.....
26100	2037	" Cloth Guide.....
26101	2037	" " " Slide with 26102 and two 26092.....
26102	2037	Tucker Tuck Marking Plate for 26101...
		Nos. 26105 to 26107 for 26377 and 26687
26105	2037	Tucker Tuck Marking Bar Bracket.....
26106	2038	" " " " " Hinge Pin.....
26107	2037	Tucker Tuck Marking Bar Lifting Spring
26108	2037	" " " " Pressure Spring for 26377.....
26109	2037	Tucker Tuck Marking Bar Pressure Spring Clamp with 196F, for 26377 and 26687
26111	2037	Tucker Tuck Smoothing Spring for 26377 and 26687.....
26123	2037	Tucker Tuck Marking Bar Pressure Spring for 26687.....
26129	2036	Tucker Foot for 26517.....
26138	2039	Welt Guide Carrier Slide Switch Cam with Shaft for 26150.....
26139	2039	Welt Guide Carrier Slide Switch Cam Shaft Head with Lever with 337D, for 26150.....
26143	2039	Welt Guide Bed for 26150.....
26144	2039	" " Cap for 26150.....
		Nos. 26145 to 26147 for 26148
26145	2039	Welt Guide Carrier.....
26146	——	" " " Slide.....
26147	2039	" " " Tongue.....
26148	——	Welt Guide Carrier complete for 26150, Nos. 233D, 26145 to 26147 and 26149..
26149	2039	Welt Guide Width Guide for 26148.....
26150	2039	Welt Guide (adjustable) with Switch complete, Nos. 240D, 910F, 2613S, 26139, 26143, 26144, 26148, 26344 and three 238D.....
26160	——	Hemmer (foot) plain bottom, $\frac{3}{32}$ in. hem
26161	2028	" " " " $\frac{1}{8}$ in. hem
26162	——	" " " " $\frac{3}{16}$ in. hem
26163	——	" " " " $\frac{1}{4}$ in. hem

NO.	PLATE	NAME
26166	2025	Feed Dog for 26169
26167	2025	Presser Foot for 26169, 28750 and 28788
26168	2025	Throat Plate for 26166 for 26169
26169	——	Corder complete, for top and bottom cording, Nos. 25792, 26166 to 26168 and two 135D
26173	1394	Strip Folder Lock Stud for 28707
26174	1394	" " " " Spring for 28707
26189	2014	Ruffler Ruffling Blade Lever Protector Rivet for 26011
26229	984	Ruffler Ruffling Presser Foot for 26230
26230	984	Ruffler (power) complete, Nos. 69D, 207F, 560B, 1582D, 1603E, 25993, 25997 to 26000, 26002, 26229, 26719 and two 337D
26231	2014	Presser Foot Spring for 20346, 20474, 24546, 24983 and 28691
26249	2021	Throat Plate for 12425 for 26250
26250	——	Binder (English) small "D" feed, complete, Nos. 190D, 207F, 12425, 25721, 25722 25983, 26249 and two 7071
26276	1394	Presser Foot Hinge Pin for 20134, 20361 and 44161

Nos. 26279 TO 26283 FOR 12435 AND 20157

26279	——	Presser Foot Extension, $\frac{1}{16}$ in.
26280	——	" " " $\frac{1}{8}$ in.
26281	1387	" " " $\frac{1}{4}$ in.
26282	——	" " " $\frac{3}{8}$ in.
26283	——	" " " $\frac{1}{2}$ in.
26328	——	Corder complete, for top cording, Nos. 12372, 12442, 25792, 25984 and two 135D
26344	2039	Welt Guide Carrier Slide Stop for 26150
26361	——	Seamer Edge Guide for 26658
26368	2037	Tucker Tuck Marking Bar for 26369
26369	——	Tucker Tuck Marking Bar complete for 26377 and 26687, Nos. 26368 and 26370 to 26372

Nos. 26370 TO 26372 FOR 26369

26370	2038	Tucker Tuck Marking Pin
26371	2038	" " " " Guide Pin
26372	2038	" " " " Spring

NO.	PLATE	NAME
26377	2037	Tucker (power) complete, Nos. 220D, 291D, 334D, 401E, 12143, 26099 to 26101, 26105 to 26109, 26111, 26369, 26378 and three 4604.....
26378	2037	Tucker Leveling Plate for 26377.....
26400	2022	Presser Foot for 26402.....
26401	2022	Throat Plate for 19474 for 26402.....
26402	——	Binder (English) for cut cloth, complete, Nos. 207F, 19474, 25733, 25734, 26400, 26401, two 190D and three 7071.....
26403	2029	Feller (foot).....
26428	2028	Hemmer (foot) ⅛ in. hem, for 12437 and 20147.....
26437	2629	Tuck Folder Sliding Bracket with 2301, for 26895.....
26438	2632	Box Plaiter Sliding Bracket Cap for 28352
26438	2629	Tuck Folder Sliding Bracket Cap for 26895 and 26899.....
26439	2442	Box Plaiter Sliding Bracket Locking Pin Bushing with 46SC, for 28352.....
26439	2442	Tuck Folder Sliding Bracket Locking Pin Bushing with 46SC, for 26895 and 26899
26449	2630	Tuck Folder Sliding Bracket with 2301, for 26899.....
26450	2630	Tuck Guide (under) for 26637.....
26451	2630	" " (upper) for 26637.....
26459	5806	Hemmer Spring Rivet for 28670.....
26465	2023	Throat Plate, large needle hole, for 12370 for 26466.....
26466	——	Binder (English) large "D" feed, complete, Nos. 190D, 207F, 12370, 25721, 25722, 25983, 26465 or 35741 and two 7071...
26485	2045	Screw Driver, shuttle tension (Attachments and Accessories) .....
26486	2022	Binder Ribbon Tension Pin for 26953....
26486	2022	" " " " (straight) for 25734, 25744, 25745 and 28337.....
26502	2629	Tuck Folder (upper, left) for 26895.....
26514	2036	Tucker Rocking Bar Lifting Spring for 26517.....
26517	2036	Tucker complete, Nos. 233B, 561B, 658B, 5604, 26089, 26090, 26093 to 26098, 26129, 26514, 26555 and 26775.....
26555	2036	Tucker Rocking Bar Protector for 26517
26568	2635	" Edge Guide for 26597.....
26569	2635	" " " Slide for 26597.
26570	2634	" Tuck Guide Plate for 26683.....

NO.	PLATE	NAME
26571	2634	Tucker Tuck Guide Plate Arm with 5944, for 26683
26592	2629	Tuck Guide for 26895
26597	——	Tucker Edge Guide complete for 26685, Nos. 287D, 7071, 26568 and 26569
26603	1381	Feed Dog for 26604, 28678, 28731, 35100, 35226, 35354, 35681, 35855, 35863, 120247 and 120248
26604	2033	Universal Felling Attachment complete
26605	2033	Throat Plate, large needle hole, for 26603, 28360 and 120001
26606	——	Throat Plate, small needle hole, for 26603, 28360 and 120001
26607	1387	Presser Foot Body for 26609 to 26611 and 35016
26608	1387	Presser Foor Plate (glass) for 26609
26609	——	Presser Foot (glass plate) complete, Nos. 26607 and 26608
26610	1387	Hemmer, $\frac{1}{8}$ in. hem, for 26607
26611	——	" $\frac{3}{16}$ in. hem, for 26607
		Nos. 26614 TO 26616 FOR 25722
26614	2021	Binder Ribbon Tension Pin (bent)
26615	2021	" " " " (straight)
26616	2021	" " " Plate
26617	2022	" " " Pin (bent) for 25734 and 28337
26618	2022	Binder Ribbon Tension Plate for 25734
26629	2014	Ruffler Ruffling Blade Lever Protector for 26011
26636	2630	Tuck Guide Division Block for 26637
26637	——	Tuck Guide complete for 26899, Nos. 26450, 26451 26636 and three 7476
26638	2029	Presser Foot (double toe) for gathering
26639	——	" " with 228D, for 26641
26640	2029	" " Adjustable Guide for 26641
26641	2029	" " 26639 with Adjustable Guide, No. 26640, for tailor work
		Nos. 26642 TO 26645 FOR 26646
26642	——	Presser Foot
26643	2029	" " Guide
26644	1394	" " " Hinge Pin
26645	1394	" " " Spring
26646	2029	Presser Foot (spring guide) complete, Nos. 337D and 26642 to 26645

NO.	PLATE	NAME
26648	1385	Presser Foot for 26938
26650	2029	" " for braiding
26651	2032	" " " folding umbrella straps
26652	——	Hemmer, $\frac{3}{32}$ in. hem, for 26655
26653	2032	" Shank for 26655, 26660, 26662, 26664, 26666, 26935, 28948, 36521 and 36712
26653	2032	Seamer Shank for 26658
26654	2032	Hemmer Rivet for 26655, 26660, 26662, 26664, 26666, 26935, 28948, 36521 and 36712
26654	2032	Seamer Rivet for 26658
26655	2031	Hemmer on Shank complete, Nos. 26652 to 26654
26656	2030	Presser Foot for 26655
26657	——	Seamer, for umbrella work, for 26658
26658	2032	Seamer complete, Nos. 26361, 26653, 26654 and 26657
26659	——	Hemmer for 26660
26660	2031	Hemmer on Shank complete, $\frac{3}{32}$ in. hem, for umbrella work, Nos. 26653, 26654 and 26659
26661	——	Hemmer (wide) for 26662
26662	2031	Hemmer on Shank complete, Nos. 26653, 26654 and 26661
26663	——	Hemmer for 26664
26664	2030	Hemmer on Shank complete, for raw edge silk, Nos. 26653, 26654 and 26663
26665	——	Hemmer, $\frac{1}{8}$ in. hem, for 26666
26666	2030	Hemmer on Shank complete, Nos. 26653, 26654 and 26665
		Nos. 26668 TO 26671 FOR 26724
26668	2035	Ruffler Driving Lever Spring
26669	2035	" Frame
26670	2034	" Guide (left) with 26679 and two 662D
26671	2035	" " (right) with 26679 and two 662D
26675	2035	" Ruffling Blade for 26724
26676	2035	" " " Clamp for 26724
26678	2035	" " " Lever Disengaging Lever for 26724
26679	2035	Ruffler Separating Blade for 26670 and 26671
26681	2039	Presser Foot for 26150

NO.	PLATE	NAME
26683	——	Tucker Tuck Guide Plate complete for 26685, Nos. 58D, 287D, 732D, 7071, 26570, 26571, 26684 and two wood screws 1 in. No. 12.....
26684	2634	Tucker Tuck Guide Plate Bracket for 26683.....
26685	——	Tucker (long arm) complete for 44-1 and 44-13 Machines, Nos. 939D, 26597, 26683 and 26686.....
26686	2636	Presser Foot for 26685.....
26687	——	Tucker (power) complete for 44-20 Machine, Nos. 220D, 291D, 334D, 401E, 12143, 26099 to 26101, 26105 to 26107, 26109, 26111, 26123, 26369 and three 4604.....
26694	2024	Binder (adjustable) complete, for cap front, for 44-13 Machine, Nos. 334D, 1566D, 25698, 25703, 26695 to 26697, two 152F and three 7071.....
		Nos. 26695 TO 26697 FOR 26694
26695	2024	Binder Bed with 9558.....
26696	2024	" Guide (lower) with 1141D and 9780
26697	2024	" " (upper).....
26698	2024	" Pressure Spring Lifting Button for 25703.....
26699	1314	Feed Dog for 26701.....
26700	1314	Throat Plate with Extension for 26699 for 26701.....
26701	——	Binder (English) complete for 44-9 Machine, Nos. 671D, 25744, 25745, 26699, 26700, 26702 and 26703.....
26702	1314	Lifting Presser Foot for 26701 and 28784
26703	1314	Vibrating Presser Foot for 26701 and 28784
26718	1370	Ruffler Needle Clamp Body for 26719....
26719	984	Ruffler Needle Clamp complete for 26230, 26724 and 28816, Nos. 1115F, 1943 and 26718.....
26722	2035	Ruffler Driving Lever for 26724.....
26723	2034	" Ruffling Blade Lever for 26724....
26724	2034	Ruffler (power) complete with right and left guides, separating blades and disengaging lever to throw ruffling blade out of action, Nos. 102D, 223D, 812B, 1101C, 1621E, 1640C, 2301, 26668 to 26671, 26675, 26676, 26678, 26719, 26722, 26723 and two 337D.....

NO.	PLATE	NAME
26755	953	Adjustable Edge and Strip Guide with Separating Blade complete for 44-22 Machine, obsolete.....
26760	1383	Throat Plate with 337D and 26080, for 12369 or 12457, for underbraiding, for 44-1 and 44-13 Machines.....
26763	1352	Spool Holder Bracket with 219F and 287D, for 26764.....
26764	1352	Spool Holder (disc) complete for 44-3, 44-17 and 44-29 Machines, Nos. 691F, 19066, 19067 and 26763.....
26775	2036	Tucker Driving Lever for 26517.....
26776	1374	Seaming Guide complete (used with Universal Felling Attachment No. 26604) Nos. 104D, 212D and 26777 to 26783...
		Nos. 26777 to 26783 for 26776
26777	1374	Seaming Guide Arm.....
26778	1374	" " " Guide (upper).....
26779	1374	" " " " " Spring
26780	1374	" " " Hinge Stud.....
26781	1374	" " " Locking Stud.....
26782	1374	" " " " " Spring
26783	1374	" " Bracket with 196F.....
26795	5839	Corder Cord Guide for 120207.....
26796	5839	" " " Arm with 26798 and three 6037, for 120207.....
26798	5839	Corder Cord Guide Bracket for 26796....
26801	1387	Presser Foot Adjustable Guide for 26802
26802	1387	" " with two adjustable guides, No. 26801 and two 725D.....
26803	1375	Edge Guide Bed with 2362, for 26810....
		Nos. 26805 to 26808 for 26810
26805	1375	Edge Guide Slide Cap (left).....
26806	1375	" " " " (right).....
26807	1375	" " " Lever.....
26808	1375	" " " Spring.....
26809	1375	" " " " Cover for 36760
26810	1375	Edge Guide (roller) complete, Nos. 94D, 233D, 26803, 26805 to 26808, 36760, two 207F and four 220D.....
26888	1344	Ruffling Arm (lower) for 26890.....
26889	1344	" " (upper) with 190D and 219F, for 26890.....
26890	1344	Ruffling Arm (adjustable) for 28845, Nos. 2291, 26888, 26889 and two 207F.....

NO.	PLATE	NAME
26891	2631	Throat Plate, small needle hole, for 20138, for 26895 and 26899
26892	2629	Tuck Folder (under, right) for 26895
26893	2629	" " Arm with 2301, for 26895 and 26899
26894	2629	Tuck Folder Guide (under, left) with 4621, for 26895
26895	——	Tuck Folding Attachment complete, for folding the tuck to the right, beginning at the left hand side of the goods, for 44-24 Machine, Nos. 514C, 1564D, 2296, 2297, 4621, 26437 to 26439, 26502, 26592, 26891 to 26894, two each 337D, 658D, three 233D and four 401E
26896	2630	Tuck Folder (under, right) for 26899
26897	2630	" " (upper, left) for 26899
26898	2630	" " Guide (under, left) with 4621, for 26899
26899	——	Tuck Folding Attachment complete, for folding the tuck to the right, beginning at the right hand side of the goods, for 44-24 Machine, Nos. 514C, 1564D, 2296, 2297, 4621, 26438, 26439, 26449, 26637, 26891, 26893, 26896 to 26898, two each 337D, 401E, 658D, 756E and three 233D
26934	——	Hemmer (narrow) for 26935
26935	1386	Hemmer on Shank complete, Nos. 26653, 26654 and 26934
26936	1387	Presser Foot, for etching
26937	1385	Corder Bow for 26938
26938	1385	Corder (bow) complete, for top cording, Nos. 4604, 25789, 26648 and 26937
26948	2601	Edge Folder on Shank, to turn edge of yoke and insert body of shirt
*26951	——	Binder Folder (lower) for 26953
*26952	——	" " (upper) for 26953
		Nos. 26953 TO 26955 FOR 26956 AND 35072
26953	1379	Binder Folder with Ribbon Tension complete, Nos. 26951, 26952, two each 193F, 7071 and nine 26486
26954	1378	Lifting Presser Foot
26955	1378	Throat Plate with Extension for 24344
26956	——	Binder (adjustable) complete for 44-9 and 44-23 Machines, Nos. 283D, 19376, 24344 and 26953 to 26955

NO.	PLATE	NAME
26977	1391	Presser Foot with Graduated Adjustable Guide, Nos. 26978 and 335D, for tailor work.....
26978	1391	Presser Foot Graduated Adjustable Guide for 26977.....
27072	——	Driving Attachment Shaft Driving Pulley (sectional, grooved) 12 in. diam., $1\frac{3}{16}$ in. bore, with two 597C, for 16531 and 24073
27302	1162	Bobbin Winder Frame for 27647, 27650, 27651, 27700 and 27875.....
27303	773	Bobbin Winder Frame Spring for 27647, 27650, 27651, 27700 and 27875.....
27303	773	Bobbin Winder Stop Latch Spring for 16522 and 19260.....
27306	1162	Bobbin Winder Spool Pin for 27308.....
27307	1162	" " " Stand for 27308....
27308	1162	Bobbin Winder Spool Stand complete for 16531, 24073, 27544, 27554, 27588, 27701 and 27876, Nos. 418E, 1562J, 2106, 10141, 11241, 27306, 27307 and two each 2455 and wood screws 1 in. No. 10....
27312	2003	Bobbin Winder Stop Latch for 27647 and 27650.....
27323	1105	Knife Grinder Knife Holder Guide Bar for 60583.....
27538	1162	Bobbin Winder Spindle with 15072, for 27647, 27650, 27651, 27700 and 27875
27540	2445	Bobbin Winder Base for 27647 and 27875
27541	2445	" " Pulley for 27647 and 27875
27544	——	Bobbin Winder (swinging automatic, right hand) complete for 2996, for stand, Nos. 27308 and 27647.....
27552	1162	Bobbin Winder Base for 27650, 27651 and 27700.....
27553	1162	Bobbin Winder Pulley for 27650, 27651 and 27700.....
27554	——	Bobbin Winder (swinging automatic, right hand) complete for 2996, for power table, Nos. 27308 and 27650.....
27564	1104	Knife Grinder Frame with 27574, for 60583
27565	1104	" " Emery Wheel, 2 in. diam., for 60934.....
27567	1105	Knife Grinder Emery Wheel Shaft for 60934.....
27568	1105	Knife Grinder Emery Wheel Shaft Oil Hole Cover (rubber) for 60583.....

NO.	PLATE	NAME
27569	1105	Knife Grinder Emery Wheel Shaft Pulley for 60934
27572	1104	Knife Grinder Knife Holder Guide Bar Bracket with 27574, for 60583
27573	1105	Knife Grinder Knife Holder Guide Bar Bracket Spring for 60583
27574	1105	Knife Grinder Knife Holder Guide Bar Bracket Spring Hook for 27564 and 27572
27587	1162	Bobbin Winder Stop Latch for 27651 and 27875
27588	——	Bobbin Winder (swinging automatic, right hand) complete for 19131, for power table, Nos. 27308 and 27651
27623	2836	Thread Unwinder Spool Pin for 41527 and 41531
27636	363	Driving Attachment Treadle for 27642
27637	1230	" " " Pitman Rod (lower) for 14233 and 15130
27638	5841	Driving Attachment Treadle Pitman Rod (lower) Spring for 14233 and 15130
27642	——	Driving Attachment Treadle complete for 14234 and 15131, Nos. 2878, 9082, 27636 and four wood screws 1 in. No. 16
27647	2445	Bobbin Winder for 27544, Nos. 35D, 1620J, 27302, 27303, 27312, 27538, 27540, 27541, 50356D and two wood screws 1 in. No. 7
27650	——	Bobbin Winder for 27554, Nos. 35D, 1620J, 27302, 27303, 27312, 27538, 27552, 27553, 50356D and two wood screws 1 in. No. 7
27651	1162	Bobbin Winder for 27588, Nos. 35D, 1620J, 27302, 27303, 27538, 27552, 27553, 27587, 50356D and two wood screws 1 in. No. 7
27657	——	Knife Grinder Knife Holder Body for 27658
27658	1105	Knife Grinder Knife Holder complete for 5726 for 27661, Nos. 899D, 27657 and 27660
27659	1105	Knife Grinder Knife Holder Stop Collar with 237F, for 60583
27660	6255	Knife Grinder Knife Position Pin for 27658
27660	6255	" " " " " (lower) for 27681 and 27682

NO.	PLATE	NAME
27661	——	Knife Grinder complete for 5726, Nos. 27662, 60583, either 27658, 27681 or 27682 and three wood screws 1 in. No. 10
27662	1104	Wrench for 1508 and 1516 for 27661.....
27679	——	Knife Grinder Knife Holder Body for 27681.....
27680	——	Knife Grinder Knife Holder Body for 27682.....
27681	6255	Knife Grinder Knife Holder complete for 27661, Nos. 899D, 11833, 27660 and 27679.....
27682	6255	Knife Grinder Knife Holder complete for 27661, Nos. 899D, 11833, 27660 and 27680.....
27699	2003	Bobbin Winder Stop Latch for 27700....
27700	——	Bobbin Winder for 27701, Nos. 35D, 1620J, 27302, 27303, 27538, 27552, 27553, 27699, 50356D and two wood screws 1 in. No. 7.....
27701	——	Bobbin Winder (swinging automatic, right hand) complete for 24051 for 44-20 Machine, Nos. 27308 and 27700.....
27739	2836	Thread Unwinder Thread Cone (wood) for 41529 and 41533.....
27822	1105	Knife Grinder Emery Wheel Clamping Nut Washer for 60934.....
27875	——	Bobbin Winder for 27876, Nos. 35D, 1620J, 27302, 27303, 27538, 27540, 27541, 27587, 50356D and two wood screws 1 in. No. 7.....
27876	——	Bobbin Winder (swinging automatic, right hand) complete for 19131, for stand, Nos. 27308 and 27875.....
27940	2836	Thread Unwinder Spool Stand with 453C, for 41529 and 41533.....
28084	——	Machine Rest Pin for 12405.....
28334	1380	Binder Folder for 28678 and 28776.....
28336	——	" Ribbon Tension Plate for 28337..
28337	1380	Binder Ribbon Tension complete for 28678 and 28776, Nos. 26617, 28336 and eight 26486.....
28342	1383	Throat Plate with 337D and 26080, for 12450, for underbraiding, for 44-1 and 44-13 Machines.....
		Nos. 28343 TO 28351 FOR 28352
28343	2632	Box Plaiter Centre Guide.....

NO.	PLATE	NAME
28344	2632	Box Plaiter Centre Guide Holder with 10165
28345	2632	Box Plaiter Folder Blade (left)
28346	2632	" " " " (right)
28347	2632	" " Sliding Bracket (left)
28348	2632	" " " " (right)
28349	2632	" " " " Arm (left) with 2301
28350	2632	Box Plaiter Sliding Bracket Arm (right) with 2301
28351	2632	Box Plaiter Sliding Bracket Extension Bracket
28352	——	Box Plaiter complete for 44-13 and 44-20 Machines, Nos. 28343 to 28351, two each 190D, 200F, 514C, 914F, 1564D, 2296, 2297, 7071, 26438, 26439, four 401E and six 233D
28353	2633	Presser Foot with 28354, 28355 and two 665D, for 28352
28354	2633	Presser Foot Guide (left) for 28353
28355	2633	" " " (right) for 28353
28358	2624	Edge Folder (suspended) left hand, to turn edge under, for 44-22 Machine
28359	1395	Edge Folder (double) with Separating Blade on Shank, lower folder to turn the edge of the goods under, for 44-22 Machine
28360	2033	Feed Dog (15 conical teeth) for 26604 and 35100
28366	2645	Binder Folder for 28794
28549	1395	Edge Folder (double) with Separating Blade on Shank, lower folder to turn the edge of the goods up, for 44-22 Machine
		Nos. 28590 TO 28594 FOR 28816
28590	1371	Ruffler Driving Lever
28591	1371	" " " Spring
28592	1371	" " " " Collar
28593	1371	" Frame
28594	1371	Presser Foot (left)
28596	1371	" " (right) Shank for 28814
28597	1371	" " " " Cap for 28816
28600	1371	Ruffler Ruffling Blade Lever for 28816
28601	1371	" Starting Lever with 190D, for 28816
28603	1370	Feed Dog for 28816

NO.	PLATE	NAME
28605	1372	Edge Folder (upper, right hand) with left hand lower guide and separating blade on shank, to fold top band only, for making yokes, for 28816.....
28607	1371	Ruffler Ruffling Blade Holder Stop for 28816.....
28611	1396	Binder on Shank, for suspender webs....
28612	1396	Presser Foot for 28611.....
28613	1396	Strip Folder on Shank, for overall shoulder straps.....
28614	1396	Presser Foot for 28613 and 35166.....
28615	1397	Edge Folder with Cord Guide on Shank, to insert and sew on insertion in one operation.....
28616	1397	Presser Foot (grooved) for 28615.....
28617	1398	Strip Folder on Shank, for inserting folded strip, for trimming mantles.....
28618	1398	Presser Foot (grooved) for strip, for 28617
28619	1399	Binder (horn) on Shank.....
28620	1399	Presser Foot for 28619.....
28621	1397	Piping Attachment and Strip Folder on Shank, for car seat cushions.....
28622	1397	Presser Foot (grooved) for 28621.....
28623	2602	Hemmer and Corder on Shank, to take goods from above to cord bottom.....
28624	2602	Presser Foot with groove on bottom to the right of needle hole, for 28623.....
28625	2627	Edge Folder (double) with Strip Folder and Cord Tube on Shank, for inserting cord, folding strip and stitching between the two folded edges of the goods.....
28626	1391	Presser Foot with groove on bottom to the right of needle hole, for 28625.....
28627	2600	Hemmer on Shank, for ⅜ in. hem, for Marseilles quilts.....
28628	2600	Presser Foot for 28627.....
28629	1384	Feed Dog for 28788.....
28630	1384	Throat Plate for 28629 for 28788.....
28631	2602	Binder on Shank.....
28632	2602	" " " to turn edges under....
28633	1399	" " " " " top edge only, for binding coats.....
28634	2602	Binder on Shank, to turn top edge only, for raw edge binding.....
28635	1398	Binder on Shank, for ⅞ in. binding.....
28636	2601	" " " to turn top edge only, for bottoms of men's trousers.....

NO.	PLATE	NAME
28637	2626	Binder on Shank, for bias binding, to turn top edge only, with guide for inserting canvas strips
28638	2600	Binder on Shank, for dress shields
28639	2603	" " " to turn top edge only, for suspenders
28640	2627	Binder on Shank, for 1¼ in. binding, for soft blankets
28641	2603	Binder on Shank, for $\frac{11}{16}$ in. binding
28642	2603	" (horn) on Shank
28643	2603	" on Shank with guide (wire) for mattress work
28646	2604	Edge Folder (double) on Shank, for men's skeleton coat seams, to turn to outside.
28647	2626	Strip Folder on Shank
28648	2626	" " " " for making straps.
28649	2604	Edge Folder on Shank
28650	2604	Hemmer on Shank, for hemming heavy Canton flannel
28651	2605	Hemmer on Shank, for turning tops and bottoms of canvas leggings
28652	2605	Hemmer on Shank, $1\frac{9}{16}$ in. to 2 in. hem
28653	——	" " " $2\frac{9}{16}$ in. to 3 in. hem
28654	1383	Throat Plate, for underbraiding, for 12369 and 12457
28655	1382	Throat Plate, small needle hole, for 12369 or 12457, for 28657
28656	——	Throat Plate, large needle hole, for 12369 or 12457, for 28657
28657	——	Binder (English) complete, Nos. 190D, 207F, 12369 or 12457, 25721, 25722, 25983, 28655 or 28656 and two 7071
28658	1377	Guide (roller) with 1852
28659	1392	Quilter Guide for 28660
28660	1392	Quilter complete, Nos. 25992 and 28659
28661	2028	Hemmer (foot) $\frac{3}{16}$ in. hem, for gusset work
28662	2028	" " ⅛ in. hem, slotted for lace
28663	2028	" " $\frac{1}{16}$ in. hem, for 12372, 12455, 20002, 20117 and 20151
28664	——	Hemmer (foot) $\frac{3}{32}$ in. hem, slotted for lace
28665	2606	Binder (foot)
28666	2606	" " right hand
28667	2606	" " left hand
28668	2606	Presser Foot (strip folding)
28669	2606	Hemmer Spring for 28670
28670	2606	" (foot) ¼ in. hem, with 28669 and two 26459

NO.	PLATE	NAME
28671	1392	Hemstitcher.....
28672	1391	Presser Foot, two grooves to the right of needle hole, for cording.....
28673	2607	Lap Seam Feller (right hand) on Shank, to fold top only.....
28674	2607	Lap Seam Guide on Shank.....
28675	1391	Presser Foot (pointed toe) for stitching box plaiting on body of material.....
28676	1381	Presser Foot for 28678 and 28776.....
28677	1381	Throat Plate for 26603 and 120001 for 28678.....
28678	——	Binder (English) complete, Nos. 193F, 7071, 26603 or 120001, 28334, 28337, 28676, 28677 and two 233D.....
28679	1376	Hemmer Bed with 28681, for 28688.....
28680	1376	" Folder (left) for 28688.....
28681	1376	" " (right) for 28679.....
		Nos. 28682 TO 28686 FOR 28688
28682	1376	Hemmer Slide with 28687 and two each 2362 and 12152.....
28683	1376	Hemmer Slide Cap (left).....
28684	1376	" " " (right).....
28685	1376	" Folder Disengaging Lever.....
28686	1376	" Slide Spring.....
28687	1376	" " " Cover for 28682...
28688	1376	Hemmer complete with Lever, for opening the folder and releasing the hem so that it can be finished without removing the hemmer from machine, for skirts, overalls or similar closed articles, Nos. 94D, 28679, 28680, 28682 to 28686, two 207F and three 233D.....
28689	——	Presser Foot Plate for 28691.....
28690	——	" " Shank for 28691.....
28691	1391	Presser Foot (spring hinged) complete for 28688, Nos. 18055, 26231, 28689 and 28690.....
28692	2607	Presser Foot for 28693.....
28693	2607	Binder on Shank, for binding the arm holes in cotton garments.....
28698	2608	Strip Folder on Shank with cord tube....
28699	2608	Presser Foot, grooved to the right of needle hole, for 28698.....
28700	2609	Hemmer (short head) on Shank, for hemming stable blankets.....

NO.	PLATE	NAME
28701	1391	Presser Foot (tube) for laying braid on stable blankets, for 28700
28702	2609	Edge Folder on Shank with Understrip Edge Folder, for strip when stitched to project over edge of goods
28703	2609	Presser Foot for 28702
28704	2610	Binder on Shank
28705	2627	Strip Folder with Arm for 28707
28706	2627	" " Hinge Bracket with 448c and 2273, for 28707
28707	2627	Strip Folder (foot, hinged) complete, for folding and stitching plait on shirt bosom, Nos. 96D, 228D, 26173, 26174, 28705 and 28706
28708	2611	Strip Folder on Shank, for folding strip and stitching down centre
28709	2628	Edge Folder (double) on Shank, for canvas
28710	2612	Hemmer on Shank, ⅛ in. hem
28711	2607	" " " $\frac{3}{16}$ in. hem, for hemming towels
28712	2612	Strip Guide on Shank
28713	1391	Presser Foot, for soft hat binding, for 36463
28714	2611	Presser Foot (strip folding) for shirt-waist work
28715	1391	Presser Foot (tube) for laying fringe-edged braid
28716	2610	Presser Foot (strip folding) for raw edge strip to turn edges under, for ⅜ in. to 1 in. strip
28717	1388	Binder (foot) right
28719	2613	Hemmer on Shank, ¼ in. to ½ in. hem
28720	2613	Hemmer on Shank, ¾ in. to 1 in. hem, complete, Nos. 120287 and 120288
28721	——	Hemmer on Shank, 1¼ in. to 2 in. hem
28722	2613	" " " for heavy woven goods
28723	2614	" " " with guide for hemming and stitching on lace in one operation
28724	2614	Binder on Shank, for binding the neck of knit underwear
28725	1388	Presser Foot Spring Guide for 28726
28726	1388	Presser Foot (right hand, spring guide) with 665D and 28725, for $\frac{1}{32}$ in. to ¼ in. gauge
28728	2628	Strip Folder on Shank, to turn in the raw edge on lower fold

NO.	PLATE	NAME
28730	2615	Binder on Shank.....
28731	2616	" " " to turn under both edges of binding ⅛ in.....
28732	2627	Binder on Shank, to turn under both edges of binding.....
28733	2614	Binder on Shank, for binding corset covers
28734	2615	" " " with ribbon guide, for dress shields.....
28735	2616	Edge Folder on Shank, for seaming umbrellas.....
28736	2617	Hemmer on Shank, for umbrella work...
28737	2615	" " " " soft material, to turn the hem under.....
28738	2617	Hemmer on Shank, ⅜ in. hem, to turn the hem under.....
28739	2626	Hemmer on Shank, 3 in. hem, for sheets and pillow slips, to turn the hem under
28740	2617	Piping Attachment on Shank.....
28741	2028	Hemmer (foot) ⅛ in. hem, for bagging...
28742	1388	" " to make stitch in centre of hem.....
28743	1388	Presser Foot (grooved) with tube, for cording.....
28744	1389	Presser Foot (strip folding) grooved, with two cord tubes, for making double corded strip.....
28745	1389	Presser Foot (strip folding) to fold both edges of strip.....
28746	1388	Presser Foot (tube) for guiding and stitching the left hand edge of ribbon.....
28747	1389	Presser Foot, for bias binding, the velveteen to project $\frac{3}{16}$ in.....
28748	1384	Feed Dog for 28750.....
28749	1384	Throat Plate for 28748 for 28750.....
28750	——	Corder complete, for top and bottom cording, for 44-20 Machine, Nos. 25792, 26167, 28748, 28749 and two 135D.....
28751	2618	Binder and Guide on Shank, for binding upper edge of button-hole strip and guiding strip and body, for shirt waists....
28752	2618	Presser Foot for 28751.....
28753	2618	Edge Folder and Guide on Shank, for top fold only.....
28754	2628	Strip Folder on Shank, for suspender straps, to turn both edges.....

NO.	PLATE	NAME
28755	2621	Edge Folder (left hand) on Shank, with right hand upper guide and separating blade, for 44-22 Machine.....
28756	2619	Edge Folder (left hand) on Shank with right hand lower guide, for 44-22 Machine.....
28758	2620	Edge Folder (double) with separating blade on Shank, lower folder to turn the edges of the goods up, for 44-22 Machine
28760	2627	Edge Folder (right hand) on Shank with left hand lower guide, for 44-22 Machine
28761	1390	Presser Foot with 219F and 28762, for stitching ribbon and net material, for 44-22 Machine.....
28762	1390	Presser Foot Ribbon Guide for 28761....
28763	2621	Edge Folder (left hand) on Shank with right hand lower guide, for 44-22 Machine.....
28764	2622	Strip Folder on Shank with left hand upper guide.....
28765	2622	Binder and Folder on Shank, for folding and binding sleeves.....
28766	2622	Presser Foot for 28765.....
28767	2620	Edge Folder (double) on Shank, the under fold to extend $\frac{1}{16}$ in. beyond edge of the upper fold.....
28768	1390	Presser Foot (strip folding) for folding a 2½ in. strip to a 1 in: strip to be stitched on shirt bosoms, for imitation tuck....
28769	1390	Binder (foot) to turn top only.....
		Nos. 28770 TO 28772 FOR 28773
28770	——	Presser Foot.....
28771	1388	" " Guide.....
28772	1388	" " " Spring.....
28773	1388	Presser Foot (spring guide) for gores, Nos. 337D, 2113, 15072 and 28770 to 28772
28775	1382	Throat Plate for 12370 for 28776.....
28776	——	Binder (English) large "D" feed, complete, for carpets, Nos. 193F, 7071, 12370, 28334, 28337, 28676, 28775 and two 233D.....
28777	2623	Hemmer (double) on Shank, for headings
28778	2623	Presser Foot for 28777.....
28779	2623	Ruffling Blade for 28777.....
28783	1382	Throat Plate for 20106 for 28784.....

NO.	PLATE	NAME
28784	——	Binder (English) complete for 44-9 Machine, Nos. 190D, 207F, 20106, 25721, 25722, 26702, 26703, 28783 and two 7071
28788	——	Corder complete, for top and bottom cording, Nos. 25792, 26167, 28629, 28630 and two 135D.....
28790	2645	Feed Dog for 28794 and 28861.....
28791	2645	Lifting Presser Foot for 28794.....
28792	2645	Throat Plate for 28790 for 28794 and 28861.....
28793	2645	Vibrating Presser Foot for 28794.....
28794	——	Binder complete, for circular binding, for sandal slippers, shoe tongues, etc., for 44-9 Machine, Nos. 207F, 337D, 7071, 7806, 28366, 28790 to 28793 and 36620
28795	——	Hemmer (foot) plain bottom, $\frac{1}{16}$ in. hem..
28803	2619	Piping Attachment on Shank, for flannel, without cord.....
28804	2619	Binder on Shank, for binding dress shields
28811	2625	Edge Folder (suspended, right hand) complete, for turning edge and ruffling folded edge on skirts, for 44-22 Machine
28813	1371	Presser Foot (right) Plate for 28814.....
28814	——	Presser Foot (right) complete for 28816, Nos. 2521, 2532, 28596 and 28813.....
28815	1371	Ruffler Ruffling Blade for 28816.....
28816	1370	Ruffler (power) complete, with lever for throwing ruffling blade into action, for intermittent ruffling, such as yoking shirts, etc., Nos. 185H, 226D, 560C, 706D, 1049D, 1101C, 1550J, 1603E, 1647C, 2656, 24203 to 24206, 26719, 28590 to 28594, 28597, 28600, 28601, 28607, 28814, 28815, two 665D and three 198D.....
28817	1370	Throat Plate for 28603.....
28818	1372	Double Edge Folder (right hand) with separating blade, for ruffling shirt body and putting in yoke, for 28816.....
		Nos. 28823 TO 28827 FOR 28828
28823	2646	Binder on Shank.....
28824	2646	Feed Dog.....
28825	2646	Lifting Presser Foot.....
28826	2646	Throat Plate for 28824.....
28827	2646	Vibrating Presser Foot.....

NO.	PLATE	NAME
28828	——	Binder complete, for circular binding (bias binding) for suspender ends and tabs, with movable folder for finishing off, for 44-9 Machine, Nos. 207F, 7071 and 28823 to 28827.....
28830	1387	Presser Foot (grooved) for cording, for carriage work.....
28833	2649	Edge Folder (left hand) on Shank, with right hand upper folder and separating blade, for 44-22 Machine.....
28838	2650	Edge Guide (suspended, left hand) for 44-22 Machine.....
28845	——	Ruffling Arm (adjustable) complete for 44-22 and 44-28 Machines, Nos. 226D, 1550J, 24203 to 24206, 26890 and two 665D.....
28848	2648	Strip Folder on Shank, for folding overall straps.....
28849	1387	Presser Foot with guide on bottom to the left of needle hole, for 28848.....
28851	2648	Binder on Shank, for 3 in. strip of bobbinette material, to bind ¾ in. wide.....
28857	2645	Binder Folder for 28861.....
28858	2645	Presser Foot with 242D, 23219 and 28859, for 28861.....
28859	2645	Presser Foot Edge Guide for 28858.....
28860	2645	" " Strip Guide for 28861.....
28861	——	Binder complete, for circular binding (bias folded strips) for ladies' lawn ties, etc., for 44-13 Machine, Nos. 28790, 28792, 28857, 28858, 28860 and two each 207F and 7071.....
28862	2649	Edge Folder (double) on Shank, right hand upper, left hand lower, with separating blade for wrappers, for 44-22 Machine.
28903	2782	Edge Folder (left hand) with right hand upper guide on shank, to turn up the body of bobbinette curtains and sew on insertion in one operation.....
28908	2658	Presser Foot Spring Guide for 28909.....
28909	2658	" " (left hand, spring guide) with 665D and 28908.....
28910	2659	Binder on Shank.....
28920	1387	Presser Foot, for braiding, to stitch braid on right hand edge.....
28935	2661	Hemmer on Shank, for bobbinette material to turn the hem under.....

NO.	PLATE	NAME
28938	2658	Presser Foot for 28724.....
28941	2661	Binder (horn) on Shank, for bias binding, to turn under both edges of binding...
28944	2665	Presser Foot (strip folding) for making raw edge straps of bias chiffon.....
28945	2666	Strip Folder on Shank, for making overall straps.....
28947	——	Hemmer for 28948.....
28948	1386	Hemmer on Shank complete, for one fold, with right hand lower guide, for lace, Nos. 26653, 26654 and 28947.....
		Nos. 28949 TO 28952 FOR 28953
28949	——	Presser Foot.....
28950	2658	" " Graduated Adjustable Guide
28951	2671	" " " " " Clamping Lever.....
28952	2671	Presser Foot Graduated Adjustable Guide Clamping Lever Spring.....
28953	2658	Presser Foot with Graduated Adjustable Guide complete, for tailor work, Nos. 2653, 26092 and 28949 to 28952.....
28958	2668	Edge Folder and Binder (combination) for seaming ladies' skirts and making imitation plait.....
		Nos. 28964 TO 28966 FOR 28967
28964	——	Presser Foot Body.....
28965	2658	" " Knife.....
28966	2658	" " " Clamp.....
28967	2658	Presser Foot complete, for grooving insoles, Nos. 198D, 15072 and 28964 to 28966.....
28969	2669	Guide (adjustable, hinged) complete, Nos. 286D, 940D, 7071, 28971 to 28973 and 35610.....
28970	2659	Binder on Shank, for bias binding, to turn both edges under.....
28971	2669	Binder Shank for 120165.....
28971	2669	Edge Folder Shank for 36292.....
28971	2669	Guide for 28969.....
28972	5839	Binder Arm for 120166.....
28972	5810	Edge Folder Holder for 36293.....
28972	2669	Guide Holder for 28969.....
28973	5839	Binder Hinge Plate for 120166.....
28973	5810	Edge Folder Holder Shank for 36293....
28973	2669	Guide Holder Shank for 28969.....

NO.	PLATE	NAME
28974	2661	Piping Attachment on Shank
28975	2658	Presser Foot for 28974
29532	1341	Needle Bar Oil Cup for 24090 and 24442
29549	1353	Tension Releasing Lever for 44-1 to 44-3 Machines, obsolete
29599	2014	Arm Oil Tube Packing (felt) for 11119, 12454 and 24131
29633	1354	Feed Rock Shaft Crank with 157J, for 24376, 24377 and 24473
32572	5806	Tension Releasing Disc for 24984 and 44118
32574	5806	Tension Releasing Pin for 24984 and 44118
33892	——	" Screw Stud 413C with 1560C, for 44147
		Nos. 35002 TO 35006 FOR 35137
35002	2671	Presser Foot Extension
35003	2671	" " Graduated Adjustable Guide (long, left)
35004	2671	Presser Foot Graduated Adjustable Guide (long, right)
35005	2671	Presser Foot Graduated Adjustable Guide (short, right)
35006	2671	Presser Foot Graduated Adjustable Guide (short, right) flush
35016	——	Hemmer, $\frac{1}{16}$ in., for 26607
35018	2045	Tape Delivery Wire (Attachments and Accessories)
35018	5643	Tubular Trimming Attachment Tape Delivery Wire for 35883
35019	984	Driving Lever Spring for 26018
35022	1386	Hemmer on Shank, $\frac{1}{16}$ in. hem, with right hand lower guide, for lace
35023	2672	Hemmer on Shank, $\frac{1}{16}$ in. hem, with left hand lower guide, for lace
		Nos. 35026 TO 35029 FOR 35030
35026	2673	Corder on Shank
35027	2674	Feed Dog
35028	2674	Presser Foot
35029	2674	Throat Plate for 35027
35030	——	Corder complete, for edge cording plush, Nos. 35026 to 35029
35040	2658	Presser Foot for 28804
35062	2676	Binder (horn) on Shank, for $\frac{7}{8}$ in. to $1\frac{1}{2}$ in. wide, for tape, for mattresses
35063	2676	Presser Foot for 35062, 35104 and 35236

NO.	PLATE	NAME
35064	2661	Hemmer on Shank, 1 in. to 2 in. hem, for general work
35065	2677	Binder on Shank, for strip to turn in upper edge only, for skirt facings, etc.
35066	5644	Presser Foot for 35065, 35067, 35208, 35241, 35325, 35681, 35863, 120247 and 120248
35067	2678	Binder (horn) on Shank, for strip, to turn both edges in, for ladies' collars, etc.
35069	2666	Binder (foot) for strip, to turn the upper edge in, for skirt facings, etc.
35072	——	Binder (adjustable) complete for 44-72 Machine, Nos. 283D, 24344, 24480, 24481, 26953 and 26955
35082	2680	Binder on Shank, for raw edge bias binding, for wrappers etc.
35100	2682	Universal Felling Attachment with First Seam Guide complete
35104	2684	Hemmer on Shank, for bottom of shirt waists, for inserting drawing or shirring string
35129	2682	Presser Foot (strip folding) for covering cord with folded strip
		Nos. 35134 TO 35136 FOR 35137
35134	2671	Presser Foot
35135	2671	" " Graduated Adjustable Guide Clamp
35136	2671	Presser Foot Graduated Adjustable Guide Clamp Lever
35137	——	Presser Foot with Extension and Graduated Adjustable Guide complete, Nos. 337B, 35002 to 35006, 35134 to 35136 and 36696
35166	2694	Hemmer on Shank, 1 in. hem, to turn the goods under
35172	2682	Presser Foot (tube) for guiding and stitching the right hand edge of ribbon
35175	2690	Edge Folder on Shank
35176	2690	Presser Foot for 35175
35177	2691	Edge Folder (double) on Shank, for oil cloth and leather, for 44-9 Machine
35178	2692	Feed Dog for 35177
35179	2692	Lifting Presser Foot for 35177
35180	2692	Throat Plate for 35178
35181	2692	Vibrating Presser Foot for 35177

NO.	PLATE	NAME
35182	2684	Binder on Shank, for cut strip, with heavy cord stitch in centre of strip, for ladies' dressing sacques, etc.
35183	2683	Presser Foot for 35182
35184	2682	" " " darning
35189	2697	Feed Dog for 28967
35190	2697	Guide for 28967
35191	2697	Throat Plate, for underbraiding, for 35189
35208	1971	Binder on Shank, to turn in both edges of bias or straight binding, for skirts, wrappers, shirtwaists, etc.
35209	1972	Binder on Shank, to turn in both edges, for bias binding, for binding the inside of small circle, corsets, etc., for 44-9 Machine
35210	2683	Lifting Presser Foot for 35209
35211	2683	Vibrating Presser Foot for 35209
35226	1972	Binder on Shank, for mattress work
35231	2683	Presser Foot for 35226
35232	2674	Lifting Presser Foot for 35226 for 44-9 Machine
35233	2674	Vibrating Presser Foot for 35226 for 44-9 Machine
35236	1971	Hemmer on Shank, for bottom of shirtwaists
35241	2695	Hemmer on Shank, for Canton flannel, etc.
35242	2698	Feed Dog for 35243
35243	2698	Presser Foot (strip folding) with tube, for inserting cord, for making loops for dressing gowns
35244	2698	Throat Plate for 35242
35245	2699	Piping Attachment on Shank
35246	2699	Presser Foot for 35245
35253	2693	Edge Folder (double) on Shank, for joining yokes to the back of shirts
35254	2693	Presser Foot for 35253
35255	2693	Feed Dog for 35253
35256	2693	Throat Plate for 35255

Nos. 35272 TO 35274 FOR 35280

35272	2061	Separating Blade Arm
35273	2061	" " " Bracket
35274	2061	" " " Latch Lever with 35275
35275	2061	Separating Blade Arm Latch Lever Stud for 35274

NO.	PLATE	NAME
35276	2061	Separating Blade Holder for 35280.....
35277	2061	" " " Spring for 35280
35279	2062	" " for 35280.....
35280	——	Separating Blade (hinged) complete for 44-22 Machine, Nos. 76D, 108D, 4604, 10135, 14026, 35272 to 35274, 35276, 35277, 35279, two each 102D, 239D and 337D.....
		Nos. 35282 TO 35286 FOR 35280
35282	2064	Edge Guide (upper, left hand).....
35283	2062	" Folder (lower, right hand) on Shank
35284	2064	" " (upper, left hand).....
35285	2062	Presser Foot.....
35286	2062	Ruffling Blade.....
35322	2697	Lifting Presser Foot for 35324.....
35323	2697	Vibrating Presser Foot for 35324.....
35324	2684	Strip Folder on Shank, for making four-ply bands, for ladies' stock collars, etc.
35325	2067	Binder on Shank, to turn top edge only, for shirt bosoms, skirt trimmings, etc.
35345	953	Strip Folder on Shank, for making straps
35346	2669	Presser Foot for 35345.....
		Nos. 35347 TO 35350 FOR 35351
35347	970	Strip Folder (double, hinged) for turning in the right hand edges of strips, for making strip, for 35348.....
35348	970	Strip Folder, for turning in the upper and lower edges of strip made on 35347....
35349	970	Strip Folder Holder and Guide.....
35350	946	Presser Foot.....
35351	——	Attachment complete, for making two-piece apron straps, cloth suspenders, etc., Nos. 19474, 24572, 35347 to 35350 and two each 190D and 7071.....
35352	970	Binder Folder on Shank for 35354.....
35353	970	" " Hinge Plate for 35354.....
35353	932	Hemmer Folder Hinge Plate for 35681...
35354	970	Binder on Shank (hinged) complete, for mattress work, Nos. 1425B, 2749, 35352 and 35353.....
35444	——	Presser Foot Body for 35447.....
35445	——	" " Tension Plate with 35446, for 35447.....
35446	2669	Presser Foot Tension Plate Guide Pin for 35445.....

NO.	PLATE	NAME
35447	2669	Presser Foot (tension plate) complete for 35354, Nos. 93F, 2656, 35444 and 35445
35454	2616	Presser Foot for 28731
35475	976	Hemmer on Shank, $\frac{5}{32}$ in. hem, with right hand lower guide, for lace
35580	——	Feed Dog (sharp teeth) for 36117
35581	——	Presser Foot for 35580
35582	——	Throat Plate for 35580
35583	——	" " Guide for 35582
35610	2669	Edge Folder Holder Friction Washer for 36293
35610	2669	Guide Holder Friction Washer for 28969
35679	932	Hemmer Folder on Shank for 35681
35681	932	Hemmer on Shank (hinged) complete, for mattress work, Nos. 1425B, 35353, 35679 and 36006
35682	——	Hemmer (foot) $\frac{1}{8}$ in. hem, with guide on bottom to the right of needle hole
35690	1246	Presser Foot (strip folding) for making straps from 1 in. to $1\frac{1}{2}$ in. wide
35700	1250	Hemmer (left hand) with right hand lower guide on Shank, for 44-22 Machine
35710	1252	Hemmer (foot) $\frac{3}{32}$ in. hem, with guide on bottom to the right of needle hole
35711	1252	Feed Dog for 35712
35712	1252	Throat Plate, small needle hole, for 35711, for 35682, 35710, 35997 and 36072
35716	1253	Binder on Shank, to turn in both edges of binding, for blankets, for 44-72 Machine
35741	——	Throat Plate, small needle hole, for 12370, for 26466
35832	2669	Presser Foot, for heavy work, for 35104
35838	5696	Guide Bed for 36117
35840	——	" Disengaging Lever Handle Washer for 36116
35841	5696	Guide Disengaging Lever Spring for 36117
35855	1253	Strip Folder on Shank, for collar bands
35856	2669	Presser Foot for 35855
35863	5644	Hemmer on Shank, for canvas work
35877	——	Presser Foot (strip folding) for raw edge strip, to turn edges under, for $1\frac{1}{16}$ in. to 2 in. strips
		Nos. 35879 TO 35882 FOR 35883
35879	5643	Tubular Trimming Attachment Strip Wire
35880	5643	Feed Dog
35881	5643	Presser Foot (strip folding) with tube

NO.	PLATE	NAME
35882	5643	Throat Plate for 35880.....
35883	——	Tubular Trimming Attachment complete, for making ⅛ in., $\frac{5}{32}$ in. and $\frac{3}{16}$ in. trimmings, Nos. 35018 and 35879 to 35882
35922	2619	Ruffling Blade for 28756.....
35995	5645	Presser Foot with right hand folder, for folding and stitching facing to shoe lining.....
35997	——	Hemmer (foot) $\frac{3}{16}$ in. hem, with guide on bottom to the right of needle hole.....
36006	932	Hemmer Folder Hinge Screw Washer for 35681.....
36022	5645	Presser Foot with 665D and 36023, for blind stitch cording, for 12 to 44 ligne cord, for ornamental cording on skirts, suits, etc.....
36023	5645	Presser Foot Cord Guide for 36022.....
36072	——	Hemmer (foot) ¼ in. hem, with guide on bottom to the right of needle hole.....
36085	——	Hemmer (foot) $\frac{1}{16}$ in. hem, slotted for lace
36113	5696	Guide Tip for 36115.....
36115	5696	" on Slide with 36113, for 36117....
36116	5696	" Disengaging Lever with 2113, 19045 and 35840, for 36117.....
36117	5696	Guide with Disengaging Lever complete, for machine-turned work, for 44-29 Machine, Nos. 990F, 35838, 35841, 36115 and 36116.....
36129	5812	Piping Attachment (double, adjustable) on Shank with upper edge folder.....
36131	5812	Presser Foot for 36129.....
36182	5808	" " with 665D and 36183, for blind stitch braiding, for soutache braid.....
36183	5808	Presser Foot Braid Guide for 36182.....
		Nos. 36185 TO 36187 FOR 36188
36185	6252	Edge Guide Arm with 1988.....
36186	6252	" " " Friction Washer.....
36187	6252	" " Bed with four 465F.....
36188	6252	Edge Guide (roller) complete, for glove work, Nos. 1425D and 36185 to 36187
36292	5810	Edge Folder (double) on Shank 28971, for 36293.....
36293	5810	Edge Folder (double hinged, adjustable) complete, Nos. 286D, 940F, 7071, 28972, 28973, 35610 and 36292.....
36294	5810	Presser Foot for 36293.....

NO.	PLATE	NAME
36309	——	Hemmer (foot) $\frac{7}{32}$ in. hem, with guide on bottom to the right of needle hole.....
		Nos. 36340 TO 36343 FOR 36344
36340	5807	Binder Bed with two each 1036C and 1266C
36341	5807	" Edge Guide.....
36342	5807	" Guide (lower).....
36343	5807	" " (upper).....
36344	5807	Binder (adjustable) complete, for leather binding, canvas bags, leggings, etc., Nos. 286D, 671D and 36340 to 36343.....
36456	6254	Binder Bed for 36463.....
36457	6254	" Folder with 25669, 36458 and two 7476, for 36463.....
36458	6254	Binder Folder Guide Block for 36457....
		Nos. 36459 TO 36462 FOR 36463
36459	6254	Binder Guide (back, lower).....
36460	6254	" " (back, upper).....
36461	6254	" " (front, lower).....
36462	6254	" " (front, upper).....
36463	6254	Binder (adjustable) complete, for soft hats, Nos. 401E, 1536D, 25672, 25673, 25677, 36456, 36457, 36459 to 36462, two 233D and three 334D.....
36520	——	Hemmer, ¼ in. hem, for 36521.....
36521	5811	Hemmer on Shank complete, Nos. 26653, 26654 and 36520.....
36524	——	Hemmer (foot) $\frac{5}{32}$ in. hem, with guide on bottom to the right of needle hole.....
36576	5808	Presser Foot Finger Guard for 36623.....
36578	2045	Oiler (copper plated) with 36579 (Attachments and Accessories).....
36579	2045	Oiler Spout, 3½ in. long, with 120117, for 36578.....
36589	——	Presser Foot for 28700.....
36620	2645	Binder Ribbon Guide for 28794.....
36622	5808	Presser Foot for 36623.....
36623	5808	" " 36622 with 36576 and two 50202D.....
36696	2671	Presser Foot Graduated Adjustable Guide Clamp Steady Pin for 35137.....
36700	5808	Binder (foot) left.....
		Nos. 36704 TO 36708 FOR 36709
36704	5659	Binder.....
36705	5659	Feed Dog.....

NO.	PLATE	NAME
36706	5659	Lifting Presser Foot.....
36707	5659	Throat Plate for 36705.....
36708	5659	Vibrating Presser Foot.....
36709	——	Binder complete, for binding slipper and sandal straps, for 44-9 Machine, Nos. 36704 to 36708 and two 228D.....
36711	——	Hemmer, ¼ in. hem, for 36712.....
36712	5811	Hemmer on Shank complete, for umbrella work, Nos. 26653, 26654 and 36711....
36760	1375	Edge Guide Slide with 26809, 51809 and two 12152, for 26810.....
		Nos. 36761 TO 36766 FOR 36767
36761	5660	Binder.....
36762	5660	Feed Dog, for narrow binding.....
36763	5660	Lifting Presser Foot.....
36764	5660	Throat Plate for 36762.....
36765	5660	Vibrating Presser Bar.....
36766	5660	" " Foot.....
36767	——	Binder complete, for binding sandals and pumps, for 44-9 Machine, Nos. 36761, 36762 or 120072, 36763 to 36766 and two 228D.....
36776	——	Hemmer on Shank, 2¼ in. to 3 in. hem
		Nos. 36818 TO 36820 FOR 36821
36818	5809	Finger Guard.....
36819	5809	" " Friction Washer.....
36820	5809	" " Holder with 196J.....
36821	5809	Finger Guard complete, Nos. 36818 to 36820 and 50316J.....
36906	5813	Throat Plate with under guide, for rick-rack, for 19474.....
		Nos. 36980 TO 36983 FOR 12437 AND 20147
36980	——	Hemmer (foot) $\frac{3}{32}$ in. hem.....
36981	——	" " $\frac{5}{32}$ in. hem.....
36982	——	" " $\frac{3}{16}$ in. hem.....
36983	——	" " ¼ in. hem.....
		Nos. 36995 TO 36997 FOR 44-9 MACHINE
36995	5659	Binder on Shank, for ⅜ in. binding.....
36996	——	" " " " $\frac{7}{16}$ in. binding.....
36997	——	" " " " $\frac{5}{16}$ in. binding.....
39395	5839	Hemmer Block Pin for 120073.....
41400	8381	Machine Rest Pin (wood) 3⅛ in. long (Attachments and Accessories).....

NO.	PLATE	NAME
41514	2836	Thread Unwinder Spool Weight, 4 in. diam., with 41515, for 41529 and 41533
41515	5742	Thread Unwinder Spool Weight Centre Pin for 41514
41526	2836	Thread Unwinder Spool Rest for 60701...
41527	——	" " " " 60701 with 27623, for 41529
41529	2836	Thread Unwinder complete, for one large spool or one large cone of thread, Nos. 27739, 27940, 41514, 41527, 41630, 41640 and three wood screws 1 in. No. 12
41530	2837	Thread Unwinder Spool Rest for 60455...
41531	——	" " " " 60455 with two 27623, for 41533
41533	2837	Thread Unwinder complete, for two large spools or two large cones of thread, Nos. 27940, 41531, 41631, 41640, two each 27739, 41514 and three wood screws 1 in. No. 12
41569	5842	Thread Unwinder Thread Guard Eyelet for 41630 and 41631
41630	2836	Thread Unwinder Thread Guard with 208E and 41569, for 41529
41631	2837	Thread Unwinder Thread Guard with 208E and two 41569, for 41533
		Nos. 41637 TO 41639 FOR 41640
41637	2836	Thread Unwinder Thread Guard Rod (lower)
41638	2836	Thread Unwinder Thread Guard Rod (upper)
41639	2836	Thread Unwinder Thread Guard Rod Coupling with two 456C
41640	——	Thread Unwinder Thread Guard Rod complete, 30 in. long, for 41529 and 41533, Nos. 41637 to 41639
41929	8383	Belt Guard for 41931
41930	5842	" " Hinge for 41931
41931	——	Belt Guard complete, Nos. 8420, 41929, two 41930 and four wood screws ¾ in. No. 9
43919	1352	Ruffling Separating Blade Shank for 24410
43944	5806	Tension Releasing Lever for 44-1 to 44-3, 44-8, 44-13, 44-17, 44-20, 44-22, 44-24, 44-29, 44-72, 44-74 and 44-75 Machines
43945	5806	Tension Spring for 44118
43946	5806	Thread Take-up Spring for 44118

NO.	PLATE	NAME
43976	2551	Feed Lifting Rock Shaft Crank Connecting Rod with 43977 and two 966E, for 44-1 to 44-3, 44-8, 44-9, 44-13, 44-17, 44-22 to 44-24, 44-28, 44-72, 44-74 and 44-75 Machines.....
*43977	——	Feed Lifting Rock Shaft Crank Connecting Rod Cap for 43976.....
43978	778	Feed Dog, 24 teeth (22 teeth to the inch) beveled for hemmer, for 44-2 Machine
43979	778	Feed Dog, 21 teeth (22 teeth to the inch) for cloth, for 44-1, 44-9 and 44-13 Machines.....
43981	6119	Bobbin Winder Frame for 43982 and 43983
43982	6119	Bobbin Winder Frame complete for 12337, Nos. 5960, 5961, 5963, 12336, 15077 and 43981.....
43983	6119	Bobbin Winder Frame complete for 20498, Nos. 5960, 5961, 5963, 12336, 15077 and 43981.....
44009	8375	Slack Thread Regulator for 44-22 Machine
44118	——	Tension complete for 44-1 to 44-3, 44-8, 44-13, 44-17, 44-22, 44-24, 44-72, 44-74 and 44-75 Machines, Nos. 7336, 32572, 32574, 43945, 43946, 44141 and two 2102
44134	——	Oscillating Shaft Crank for 44135.....
44135	5806	Oscillating Shaft Crank complete for 44-1 to 44-3, 44-8, 44-9, 44-13, 44-17, 44-22 to 44-24, 44-28, 44-72, 44-74 and 44-75 Machines, Nos. 1518E, 19449, 44134 and two 453C.....
44136	5805	Feed Dog, for tailor work, for 44-1 Machine
44137	5805	Throat Plate, large needle hole, for 44136
44138	——	" " small needle hole, for 44136
44139	772	Machine Hinge Plate for 44140 and 44180
44140	——	Machine Hinge complete, Nos. 12361, 44139 and wood screw 1¼ in. No. 14 (Attachments and Accessories).....
44141	——	Tension Screw Stud 50327C with 1560C, for 24984 and 44118.....
44144	1262	Feed Dog, 22 teeth (24 teeth to the inch) beveled for hemmer, for 44-13 and 44-20 Machines.....
44147	——	Tension complete for 44-9, 44-23 and 44-28 Machines, Nos. 2923, 7336, 8511, 20037, 33892 and two 2921.....

NO.	PLATE	NAME
44156	1262	Feed Dog, 24 teeth (24 teeth to the inch) for 44-13 Machine.....
		Nos. 44158 to 44160 for 44161
44158	5842	Feed Dog.....
44159	——	Presser Foot Plate.....
44160	——	" " Shank.....
44161	5842	Presser Foot (hinged) complete, Nos. 26276, 44159 and 44160.....
44162	5842	Throat Plate for 44158.....
44177	1260	Feed Dog, 19 teeth (22 teeth to the inch) for 44-13 and 44-20 Machines.....
44180	——	Machine Hinge complete, Nos. 687E, 6055, 12361 and 44139 (Attachments and Accessories).....
44181	——	Face Plate Thread Guard (lower) for 12150
		Nos. 46506 to 46509 for 46520 and 46656
46506	3826	Pitman Ball Bearing Adjusting Screw Ring
46507	3826	" " " " " " Locking Washer (brass).....
46508	3826	Pitman Ball Bearing Ring.....
46509	3826	" " Case.....
46519	3825	Band Wheel Crank for 46520 and 46656
46520	——	Band Wheel Crank and Pitman (ball bearing) complete for 25265, Nos. 1520R, 25371, 46506 to 46509, 46519, 46523, 46630, 46655 and six 25362.....
46522	3825	Leg for 25265, 25279 and 25284.....
46523	3825	Pitman Rod with 25360, for 46520.....
46524	3825	Treadle for 25265 and 25284.....
46528	6142	Brace Section (left) with 46629, for 46662
46533	6142	Brace with 46661 and two 46629, for 25265, 25279 and 25284.....
46629	——	Treadle Screw Centre 297C with 1507J, for 46528, 46533 and 46663.....
46630	——	Pitman Rod Ball Screw Bearing 25361, with 1670E, for 46520.....
46630	——	Pitman Rod (lower) Ball Screw Bearing 25361 with 1670E, for 46656.....
46655	3826	Pitman Ball Separator for 46520 and 46656.....
46656	——	Band Wheel Crank and Pitman (ball bearing) complete for 25284, Nos. 1520R, 25371, 46506 to 46509, 46519, 46630, 46655, 46658J to 46660J and six 25362.

NO.	PLATE	NAME
46657	——	Belt, size ¼ in., length 36½ in., with 25127, from motor to machine, for 25284
		Nos. 46658 to 46660 for 46656
46658	5843	Pitman Rod (lower) with 25360
46659	5841	" " (upper)
46660	5843	" " Coupling
46661	——	Band Wheel Crank Screw Centre 296c with 1507J, for 46533 and 46663
46662	6142	Brace (sectional) complete for 25265, 25279 and 25284, Nos. 46528, 46663 and three 880E
46663	6142	Brace Section (right) with 46629 and 46661, for 46 62
50169D	5839	Hemmer Guide Screw for 120078
50202D	5808	Presser Foot Finger Guard Screw for 36623
50316J	5809	Finger Guard Hinge Screw for 36821
50327C	5806	Tension Screw Stud for 44141
50356D	5806	Bobbin Winder Frame Hinge Screw for 27647, 27650, 27651, 27700 and 27875
50402C	8380	Ruffling Regulator Crank Connecting Rod Hinge Screw (upper) for 44-75 Machine
50403D	8380	Ruffling Regulator Thumb Screw for 44-75 Machine
50429C	——	Thread Retainer Set Screw
50441D	5839	Hemmer Block Hinge Screw for 120078
51809	1375	Edge Guide Slide Roller and Stud for 36760
52454	5842	Thread Retainer
56813	——	Feed Bar Screw Centre 313c with 1519J, for 44-1 to 44-3, 44-8, 44-9, 44-13, 44-17, 44-20 44-22, 44-24, 44-28, 44-29 and 44-74 Machines
56813	——	Feed Bar (lower) Screw Centre 313c with 1519J, for 44-72 and 44-75 Machines
56814	——	Feed Lifting Rock Shaft Screw Centre 307c with 1513J
56814	——	Feed Rock Shaft Screw Centre 307c with 1513J
56848	——	Bell Crank 5596 with 5599 and 5601, for 5598
60455	——	Thread Unwinder Spool Rest 41530 with 1149c and two 155c, for 41531
60583	——	Knife Grinder for 27661, Nos. 261D, 27323, 27564, 27572, 27573, 27659, 60934, two 27568 and four each 310F and 1516D

NO.	PLATE	NAME
60701	——	Thread Unwinder Spool Rest 41526 with 155c and 1149c, for 41527
60934	——	Knife Grinder Emery Wheel Shaft 27567 with 1508E, 27565, 27569 and 27822, for 60583
62502	——	Shuttle Race Body 24413 with 24418 and two 1053D, for 62517
62510	——	Shuttle Race Body 24437 with 24064 and two 1053D, for 62519
62513	——	Shuttle Race Body 24326 with 24009 and two 1053D, for 62522
62517	——	Shuttle Race Body 62502 with two 2532, for 24419
62519	——	Shuttle Race Body 62510 with two 2532, for 24438
62522	——	Shuttle Race Body 62513 with two 2532, for 24327
62527	5806	Presser Foot Hinge Pin for 24546 and 24983
62529	1260	Feed Dog, 18 teeth (22 teeth to the inch) for general work, for 44-20 Machine

Nos. 62548 to 62574 for 44-75 Machine

*62548	——	Arm with 11104
62549	8376	Feed Dog
62550	8379	" (upper) Shaft Crank (front) Connection with two 452c
62551	8380	Feed (upper) Shaft Crank (front) Connection Hinge Pin
62552	8380	Feeding Foot (upper) with two 460c
62553	8379	Lifting Presser Bar Bell Crank Driving Arm Eccentric Connection
62554	8379	Lifting Presser Bar Bell Crank Driving Arm Shaft Bracket for 62555
62555	——	Lifting Presser Bar Bell Crank Driving Arm Shaft Bracket complete, Nos. 2049, 19359, 24351 and 62554
62556	8376	Lifting Presser Bar Lifter
62557	8380	" " Foot
62558	8379	Needle Bar Crank and Lifting Eccentric with 448c and 743c
62559	8380	Ruffling Blade
62560	8379	" Lever
62561	8380	" " Stud (eccentric)
62562	8380	" " " Collar with two 465c
62563	8379	" Regulator
62564	8379	" " Bracket

NO.	PLATE	NAME
62565	8379	Ruffling Regulator Crank with two 453c
62566	8379	" " " Connecting Rod
62567	8380	" " Thumb Screw Sleeve
62568	8380	" " " " Washer
62569	8380	" Smoothing Blade.....
62570	8376	Throat Plate with 62571 and two 1053D, for 62549.....
62571	8376	Throat Plate Separating Blade for 62570
62572	8381	Lifting Lever Pin for 62573 and 62574...
62573	——	Foot Lifter complete for 44-75 Machine, Nos. 76D, 766D, 802D, 1521E, 4880, 4885, 5598, 5670, 12415, 12416, 19371, 21301, 62572 and two 178E.....
62574	——	Knee Lifter complete (power table) for 44-75 Machine, Nos. 76D, 766D, 802D, 1521E, 2777, 5598, 12415, 12416, 19371, 21301, 62572 and two 178E.....
*62587	——	Hand Attachment complete with Bobbin Winder for 24807, Nos. 32D, 659D, 660D, 1317D, 8280, 8392, 24797, 24800, 24801, 24803, 24804, 62676, 94002, 94005, 94011 and two each 183D and 211A....
62599	8379	Feed (upper) Shaft for 44-75 Machine....
62600	8379	Lifting Presser Bar Guide Bracket Support for 44-75 Machine .....
62615	8379	Feed (upper) Shaft Crank (front) with four 454c, for 44-75 Machine.....
62623	——	Shuttle Race Body 24008 with 24009 and two 1053D, for 24010, obsolete.....
62632	——	Hand Attachment Driver 8313 with 240B, 8285, 8286 and 24798, for 62676.....
62674	——	Feed (upper) Shaft Crank (front) 24476 with 24477 and 24479, for 44-72 Machine.....
62676	——	Hand Attachment Driver 62632 with 2532 and 8394, for 62587.....
62697	——	Foot Lifter complete for 44-72 Machine, Nos. 76D, 766D, 802D, 1521E, 4880, 4885, 5598, 5670, 12416, 19371, 19372, 20255, 21301 and two 178E.....
67086	8383	Treadle Pitman Rod (upper) for 67177...
67175	5843	Hook for 67072.....
67176	8383	Treadle Pitman Rod (lower) for 67177...
67177	8383	Treadle Pitman complete for S. D. 11 and S. D. 12 Motors, for 25284, Nos. 9079, 67086 and 67176.....

NO.	PLATE	NAME
80023	8377	Hand Attachment Crank Handle (wood) for 94005
94002	8377	Hand Attachment Body for 62587
94005	——	Hand Attachment Crank complete for 62587, Nos. 8435, 80023 and 94012
94011	8377	Hand Attachment Gear Cover for 62587
94012	8377	" " Crank Handle Spindle for 94005
120001	1381	Feed Dog (spiked teeth) for 26604, 28678, 28731, 35100, 35226, 35354 and 120207
		Nos. 120015 to 120017 for 120019
120015	5688	Strip Folder Guide Wire with 120018
120016	8376	" " " " Clamp
120017	5688	" " " " Extension
120018	5688	" " " " " Clamp with 207B and 793B, for 120015
120019	5688	Strip Folder on Shank with 3146, 120015 to 120017 and two 703B, for 44-75 Machine
120072	5660	Feed Dog, for wide binding, for 36767
		Nos. 120073 to 120077 for 120078
120073	——	Hemmer Block with 39395
120074	——	" " Spring
120075	——	" Guide
120076	——	" Plate
120077	——	" Shank
120078	5839	Hemmer (foot) adjustable, complete, for tennis shoes, Nos. 219D, 651D, 50169D, 50441D and 120073 to 120077
120117	8381	Oiler Spout Washer (leather) for 36579
120135	5846	Edge Folder (double) for turning in two edges and inserting loops in one operation
120136	5846	Presser Foot for 120135
120143	——	" " Plate for 120144
120144	5847	Presser Foot (hinged) complete for 35065, 35067, 35208, 35241, 35325, 120247 and 120248, Nos. 7298, 19335 and 120143
120165	5839	Binder on 28971 for 120166
120166	5839	Binder (adjustable) complete, for sleeve facings on military coats, Nos. 286D, 940D, 7071, 28972, 28973 and 120165
120191	5845	Strip Folder on Shank, to turn in both edges

NO.	PLATE	NAME
120197	5848	Edge Folder (upper) with lower right hand guide on shank, for military uniforms
120206	5839	Corder Cord Guide Bed with 457c, for 120207
120207	5839	Corder (adjustable) complete, for short turns on cushions, Nos. 190D, 1044D, 26795, 26796 and 120206
120208	1381	Presser Foot (grooved) for 120207
120242	7790	Binder Bed with 1036c, for 120247 and 120248
120243	7791	Binder Folder (lower) for 120248
120244	7790	" " (upper) for 120247 and 120248
120245	7790	Binder Guide (centre) for 120247 and 120248
120246	7790	Binder Guide (lower) for 120247
120247	7790	Binder (adjustable) complete, to turn in upper edge only, for light or medium weight material, Nos. 286D, 120242 and 120244 to 120246
120248	7791	Binder (adjustable) complete, to turn in both edges, for light or medium weight material, Nos. 286D and 120242 to 120245
120257	5847	Binder with tension slots on Shank, for turning in both edges of bias cut binding, for light or medium weight material
120287	2613	Hemmer for 28720
120288	2613	" Shank for 28720
120289	——	" on Shank, 2 in. hem, to turn the goods under
200056E	3471	Bobbin Winder Stop Latch Screw for 225436
200082D	3471	Bobbin Winder Tension Bracket Screw for 225436
200299H	3471	Bobbin Winder Stop Latch Trip Lever Hinge Screw for 225436
200380C	3471	Bobbin Winder Pulley Set Screw for 202473
201499B	3471	Bobbin Winder Tension Stud for 225461
201572B	3471	" " " " Thumb Nut for 225462
202104	3471	Bobb n Winder Tension Bracket Screw Washer for 225436
202277	3471	Bobbin Winder Frame Oil Packing (wick) for 225453

NO.	PLATE	NAME
202407	3471	Bobbin Winder Tension Spring for 225462
202473	3470	" " Pulley with 200380C, for 225436
202478	3471	Bobbin Winder Stop Latch Trip Lever for 225436
225436	3469	Bobbin Winder (swinging automatic, right hand) complete for 2996, 19131 and 24051, for power table, Nos. 200056E, 200082D, 200299H, 202104, 202473, 202478, 225444, 225452 to 225456, 225458 to 225460, 225462, 225463 and two wood screws ¾ in. No. 13 R. H. B.
225438	3471	Bobbin Winder Frame Oil Well Cap for 225453
*225443	——	Bobbin Winder Spindle for 225452
225444	3471	" " Stop Latch for 225436
*225451	——	" " Bobbin Holder for 225452
		Nos. 225452 TO 225456 FOR 225436
225452	3470	Bobbin Winder Spindle 225443 with 225451
225453	3470	Bobbin Winder Frame with 202277 and 225438
225454	3471	Bobbin Winder Frame Hinge Pin
225455	3471	" " " Spring
225456	3471	" " " " Plunger
		Nos. 225458 TO 225460 FOR 225436
225458	3471	Bobbin Winder Stop Latch Thumb Lever
225459	3471	" " " " " " Hinge Stud
225460	3471	Bobbin Winder Stop Latch Thumb Lever Joint Stud
225461	3471	Bobbin Winder Tension Bracket with 201499B, for 225462
225462	——	Bobbin Winder Tension Bracket complete for 225436, Nos. 201572B, 202407, 225461 and two 2102
225463	3469	Bobbin Winder and Tension Bracket Base for 225436

ILLUSTRATIONS OF PARTS

FOR

MACHINES

Nos. 44-1 to 44-3, 44-8, 44-9, 44-13, 44-17, 44-20, 44-22 to 44-24, 44-28, 44-29, 44-72, 44-74, and 44-75

PLATE 363—ONE-FOURTH SIZE



PLATE 766—ONE-FOURTH SIZE



PLATE 767—ONE-HALF SIZE



PLATE 768—ONE-HALF SIZE



PLATE 770—FULL SIZE



PLATE 771—FULL SIZE



PLATE 772—FULL SIZE



PLATE 773—FULL SIZE



PLATE 774—FULL SIZE



PLATE 775—FULL SIZE



PLATE 776—FULL SIZE



PLATE 777—FULL SIZE



PLATE 778—FULL SIZE



PLATE 779—FULL SIZE



PLATE 780—FULL SIZE



PLATE 781—FULL SIZE

12406

12463

12462

12467

20311

20342

20343

20346

20361

20359

20328

24983

PLATE 782—FULL SIZE



PLATE 783—FULL SIZE



PLATE 932—FULL SIZE



PLATE 946—FULL SIZE





PLATE 953—ONE-HALF SIZE



PLATE 970—ONE-HALF SIZE



PLATE 976—FULL SIZE



PLATE 984—FULL SIZE



PLATE 1104—ONE-HALF SIZE



PLATE 1105—FULL SIZE



PLATE 1162—ONE-HALF SIZE



PLATE 1206—FULL SIZE



PLATE 1230—ONE-FOURTH SIZE



PLATE 1231—ONE-FOURTH SIZE



PLATE 1246—FULL SIZE



PLATE 1250—FULL SIZE



PLATE 1252—FULL SIZE

35711



35712



35710



PLATE 1253—ONE-HALF SIZE

35716

35855



PLATE 1258—FULL SIZE



PLATE 1259—FULL SIZE



PLATE 1260—FULL SIZE



PLATE 1261—FULL SIZE



PLATE 1262—FULL SIZE



PLATE 1263—FULL SIZE



PLATE 1264—FULL SIZE



PLATE 1266—FULL SIZE



PLATE 1267—FULL SIZE



PLATE 1268—FULL SIZE

19400



19408



19411



19414



19417



PLATE 1271—FULL SIZE



PLATE 1308—FULL SIZE



PLATE 1309—FULL SIZE



PLATE 1311—ONE-HALF SIZE



PLATE 1312—FULL SIZE



PLATE 1313—FULL SIZE



PLATE 1314—FULL SIZE



PLATE 1315—ONE-HALF SIZE



PLATE 1317—FULL SIZE



PLATE 1323—FULL SIZE



PLATE 1324—FULL SIZE



PLATE 1339—ONE-HALF SIZE



PLATE 1340—ONE-HALF SIZE



PLATE 1341—FULL SIZE



PLATE 1342—FULL SIZE

24065



24064

24062



PLATE 1343—FULL SIZE



PLATE 1344—FULL SIZE



PLATE 1348—ONE-FOURTH SIZE



PLATE 1349—ONE-HALF SIZE



PLATE 1350—ONE-HALF SIZE



PLATE 1351—ONE-HALF SIZE



PLATE 1352—ONE-HALF SIZE



PLATE 1353—FULL SIZE



PLATE 1354—FULL SIZE



PLATE 1356—FULL SIZE

19188



19404



PLATE 1357—FULL SIZE

24010



24012



PLATE 1358—FULL SIZE

24121



24148



24147

PLATE 1359—FULL SIZE

24157



24327



PLATE 1361—FULL SIZE



PLATE 1362—FULL SIZE



PLATE 1364—FULL SIZE

24438



PLATE 1366—FULL SIZE



PLATE 1369—FULL SIZE



PLATE 1370—FULL SIZE



PLATE 1371—FULL SIZE



PLATE 1372—ONE-HALF SIZE

28606



28605



28818



PLATE 1374—FULL SIZE



PLATE 1375—FULL SIZE



PLATE 1376—FULL SIZE



PLATE 1377—FULL SIZE



PLATE 1378—FULL SIZE



PLATE 1379—FULL SIZE



PLATE 1380—FULL SIZE



PLATE 1381—FULL SIZE



PLATE 1382—FULL SIZE



PLATE 1383—FULL SIZE



PLATE 1384—FULL SIZE



PLATE 1385—FULL SIZE



PLATE 1386—FULL SIZE

26935



28948



35022



PLATE 1387—FULL SIZE



PLATE 1388—FULL SIZE



PLATE 1389—FULL SIZE



PLATE 1390—FULL SIZE



PLATE 1391—FULL SIZE



PLATE 1392—FULL SIZE



PLATE 1394—FULL SIZE



PLATE 1395—FULL SIZE



PLATE 1396—FULL SIZE



PLATE 1397—FULL SIZE



PLATE 1398—FULL SIZE



PLATE 1399—FULL SIZE



PLATE 1971—ONE-HALF SIZE





PLATE 1972—FULL SIZE



PLATE 2003—ONE-HALF SIZE



PLATE 2004—ONE-HALF SIZE



PLATE 2006—FULL SIZE



PLATE 2009—FULL SIZE



PLATE 2012—FULL SIZE



PLATE 2014—FULL SIZE



PLATE 2021—FULL SIZE



PLATE 2022—FULL SIZE



PLATE 2023—FULL SIZE

26465



12370



PLATE 2024—FULL SIZE



PLATE 2025—FULL SIZE

26166



26168



26167



26381



25984

12436



PLATE 2026—FULL SIZE



PLATE 2028—FULL SIZE



PLATE 2029—FULL SIZE



PLATE 2030—FULL SIZE

26664



26666



26656



PLATE 2031—FULL SIZE



PLATE 2032—FULL SIZE



PLATE 2033—FULL SIZE



PLATE 2034—FULL SIZE



PLATE 2035—FULL SIZE



PLATE 2036—FULL SIZE



PLATE 2037—FULL SIZE



PLATE 2038—FULL SIZE



PLATE 2039—FULL SIZE



PLATE 2045—ONE-HALF SIZE



PLATE 2046—FULL SIZE

24325



24323



24009

19406



PLATE 2061—FULL SIZE



PLATE 2062—FULL SIZE



PLATE 2064—FULL SIZE



PLATE 2067—FULL SIZE



PLATE 2442—FULL SIZE



PLATE 2445—ONE-HALF SIZE



PLATE 2551—ONE-HALF SIZE



PLATE 2600—FULL SIZE



PLATE 2601—FULL SIZE



PLATE 2602—FULL SIZE



PLATE 2603—FULL SIZE



PLATE 2604—FULL SIZE



PLATE 2605—FULL SIZE



PLATE 2606—FULL SIZE



PLATE 2607—FULL SIZE



PLATE 2608—FULL SIZE



PLATE 2609—FULL SIZE



PLATE 2610—FULL SIZE



PLATE 2611—FULL SIZE



PLATE 2612—FULL SIZE



PLATE 2613—FULL SIZE



PLATE 2614—FULL SIZE



PLATE 2615—FULL SIZE



PLATE 2616—FULL SIZE



PLATE 2617—FULL SIZE



PLATE 2618—FULL SIZE



PLATE 2619—FULL SIZE



PLATE 2620—FULL SIZE



PLATE 2621—FULL SIZE



PLATE 2622—FULL SIZE



PLATE 2623—FULL SIZE



PLATE 2624—FULL SIZE



PLATE 2625—FULL SIZE

28811



PLATE 2626—ONE-HALF SIZE



PLATE 2627—ONE-HALF SIZE



PLATE 2628—ONE-HALF SIZE



PLATE 2629—ONE-HALF SIZE



PLATE 2630—ONE-HALF SIZE



PLATE 2631—FULL SIZE



PLATE 2632—ONE-HALF SIZE



PLATE 2633—FULL SIZE



PLATE 2634—ONE-FOURTH SIZE



PLATE 2635—ONE-HALF SIZE

26569



26568

26710

35159

PLATE 2636—FULL SIZE



PLATE 2637—ONE-FOURTH SIZE



PLATE 2638—FULL SIZE



PLATE 2644—ONE-FOURTH SIZE

24079



24080

PLATE 2645--FULL SIZE



PLATE 2646—FULL SIZE



PLATE 2647—FULL SIZE



PLATE 2648—ONE-HALF SIZE



PLATE 2649—FULL SIZE



PLATE 2650—FULL SIZE



PLATE 2658—FULL SIZE



PLATE 2659—FULL SIZE



PLATE 2661—ONE-HALF SIZE



PLATE 2665—FULL SIZE



PLATE 2666—FULL SIZE



PLATE 2668—FULL SIZE



PLATE 2669—FULL SIZE



PLATE 2671—FULL SIZE



PLATE 2672—FULL SIZE

35023



PLATE 2673—FULL SIZE



PLATE 2674—FULL SIZE



PLATE 2676—FULL SIZE



PLATE 2677—FULL SIZE



PLATE 2678—FULL SIZE



PLATE 2680—FULL SIZE



PLATE 2682—FULL SIZE



PLATE 2683—FULL SIZE

35183



35210

35211



35231



PLATE 2684—ONE-HALF SIZE



PLATE 2687—ONE-HALF SIZE



PLATE 2688—FULL SIZE



PLATE 2690—FULL SIZE



PLATE 2691—FULL SIZE



PLATE 2692—FULL SIZE

35178



35180



35179



35181



PLATE 2693—FULL SIZE



PLATE 2694—FULL SIZE



PLATE 2695—FULL SIZE



PLATE 2697—FULL SIZE



PLATE 2698—FULL SIZE



PLATE 2699—FULL SIZE



PLATE 2782—FULL SIZE



PLATE 2836—ONE-FOURTH SIZE



PLATE 2837—ONE-FOURTH SIZE



PLATE 3469—ONE-FOURTH SIZE



PLATE 3470—ONE-HALF SIZE

202473

225453

225452



PLATE 3471—FULL SIZE



PLATE 3538—ONE-FOURTH SIZE



PLATE 3825—ONE-NINTH SIZE



PLATE 3826—FULL SIZE



PLATE 4761—FULL SIZE



PLATE 5643—FULL SIZE



PLATE 5644—FULL SIZE



PLATE 5645—FULL SIZE



PLATE 5659—FULL SIZE







PLATE 5660—FULL SIZE



PLATE 5688—ONE-HALF SIZE



PLATE 5696—FULL SIZE



PLATE 5736—FULL SIZE



PLATE 5737—FULL SIZE



PLATE 5742—FULL SIZE



PLATE 5764—ONE-HALF SIZE



PLATE 5805—FULL SIZE

44137



44136

PLATE 5806—FULL SIZE




36344
36340
36343
286
36341
671
36342

PLATE 5808—FULL SIZE

PLATE 5809—FULL SIZE

PLATE 5810—FULL SIZE



PLATE 5811—FULL SIZE

36521

36712



PLATE 5812—FULL SIZE



PLATE 5813—FULL SIZE



PLATE 5839—FULL SIZE



PLATE 5841—ONE-HALF SIZE



PLATE 5842—FULL SIZE



PLATE 5843—FULL SIZE



PLATE 5845—ONE-HALF SIZE



PLATE 5846—FULL SIZE





PLATE 5847—FULL SIZE

120144

120257



PLATE 5848—FULL SIZE



120197

PLATE 6119—ONE-HALF SIZE



PLATE 6142—ONE-EIGHTH SIZE



PLATE 6252—FULL SIZE



PLATE 6254 — FULL SIZE



PLATE 6255—FULL SIZE







PLATE 7790—FULL SIZE



PLATE 7791—FULL SIZE



PLATE 8375—FULL SIZE



PLATE 8376—FULL SIZE



PLATE 8377—ONE-HALF SIZE



PLATE 8378—FULL SIZE



PLATE 8379—ONE-HALF SIZE



PLATE 8380—FULL SIZE



PLATE 8381—ONE-HALF SIZE



PLATE 8382—ONE-FOURTH SIZE



PLATE 8383—ONE-FOURTH SIZE



SINGER
SEWING
MACHINES
THE SINGER MANF. CO.